

5100 Master Series

MS-9665 (V1.X) Server Board



Copyright Notice

The material in this document is the intellectual property of **MICRO-STAR INTERNATIONAL**. We take every care in the preparation of this document, but no guarantee is given as to the correctness of its contents. Our products are under continual improvement and we reserve the right to make changes without notice.

Trademarks

All trademarks are the properties of their respective owners.

Intel® and Pentium® are registered trademarks of Intel Corporation.

AMD, Athlon™, Athlon™ XP, Thoroughbred™, and Duron™ are registered trademarks of AMD Corporation.

NVIDIA, the NVIDIA logo, DualNet, and nForce are registered trademarks or trademarks of NVIDIA Corporation in the United States and/or other countries.

PS/2 and OS®/2 are registered trademarks of International Business Machines Corporation.

Windows® 98/2000/NT/XP/VISTA are registered trademarks of Microsoft Corporation.

Netware® is a registered trademark of Novell, Inc.

Award® is a registered trademark of Phoenix Technologies Ltd.

AMI® is a registered trademark of American Megatrends Inc.

Revision History

Revision	Revision History	Date
V1.1	Updating CPU	July 2008

Technical Support

If a problem arises with your system and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance.

- 🔍 Visit the MSI website at <http://global.msi.com.tw/index.php?func=service> for FAQ, technical guide, BIOS updates, driver updates, and other information.
- 👤 Contact our technical staff at <http://ocss.msi.com.tw>.

Safety Instructions

1. Always read the safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Keep this equipment away from humidity.
4. Lay this equipment on a reliable flat surface before setting it up.
5. The openings on the enclosure are for air convection hence protects the equipment from overheating. DO NOT COVER THE OPENINGS.
6. Make sure the voltage of the power source and adjust properly 110/220V before connecting the equipment to the power inlet.
7. Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
8. Always Unplug the Power Cord before inserting any add-on card or module.
9. All cautions and warnings on the equipment should be noted.
10. Never pour any liquid into the opening that could damage or cause electrical shock.
11. If any of the following situations arises, get the equipment checked by service personnel:
 - ▶ The power cord or plug is damaged.
 - ▶ Liquid has penetrated into the equipment.
 - ▶ The equipment has been exposed to moisture.
 - ▶ The equipment does not work well or you can not get it work according to User's Manual.
 - ▶ The equipment has dropped and damaged.
 - ▶ The equipment has obvious sign of breakage.
12. DONOT LEAVE THIS EQUIPMENT INAN ENVIRONMENT UNCONDITIONED, STORAGE TEMPERATURE ABOVE 60°C (140°F), IT MAY DAMAGE THE EQUIPMENT.



CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.



警告使用者：

此為甲類資訊技術設備，於居住環境中使用時，可能會造成射頻擾動，在此情況下，使用者會被要求採取某些適當的對策



廢電池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part



15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below.

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.

VOIR LANOTICE D'INSTALLATION AVANT DE RACCORDER AU RESEAU.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and*
- (2) this device must accept any interference received, including interference that may cause undesired operation.*

WEEE (Waste Electrical and Electronic Equipment) Statement



ENGLISH

To protect the global environment and as an environmentalist, MSI must remind you that...

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2002/96/EC, which takes effect on August 13, 2005, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life. MSI will comply with the product take back requirements at the end of life of MSI-branded products that are sold into the EU. You can return these products to local collection points.

DEUTSCH

Hinweis von MSI zur Erhaltung und Schutz unserer Umwelt

Gemäß der Richtlinie 2002/96/EG über Elektro- und Elektronik-Altgeräte dürfen Elektro- und Elektronik-Altgeräte nicht mehr als kommunale Abfälle entsorgt werden. MSI hat europaweit verschiedene Sammel- und Recyclingunternehmen beauftragt, die in die Europäische Union in Verkehr gebrachten Produkte, am Ende seines Lebenszyklus zurückzunehmen. Bitte entsorgen Sie dieses Produkt zum gegebenen Zeitpunkt ausschließlich an einer lokalen Altgerätesammelstelle in Ihrer Nähe.

FRANÇAIS

En tant qu'écologiste et afin de protéger l'environnement, MSI tient à rappeler ceci...

Au sujet de la directive européenne (EU) relative aux déchets des équipements électriques et électroniques, directive 2002/96/EC, prenant effet le 13 août 2005, que les produits électriques et électroniques ne peuvent être déposés dans les décharges ou tout simplement mis à la poubelle. Les fabricants de ces équipements seront obligés de récupérer certains produits en fin de vie. MSI prendra en compte cette exigence relative au retour des produits en fin de vie au sein de la communauté européenne. Par conséquent vous pouvez retourner localement ces matériels dans les points de collecte.

РУССКИЙ

Компания MSI предпринимает активные действия по защите окружающей среды, поэтому напоминаем вам, что...

В соответствии с директивой Европейского Союза (ЕС) по предупреждению загрязнения окружающей среды использованным электрическим и электронным оборудованием (директива WEEE 2002/96/EC), вступающей в силу 13 августа 2005 года, изделия, относящиеся к электрическому и электронному оборудованию, не могут рассматриваться как бытовой мусор, поэтому производитель вышеперечисленного электронного оборудования обязан принимать его для переработки по окончании срока службы. MSI обязуется соблюдать требования по приему продукции, проданной под маркой MSI на территории ЕС, в переработку по окончании срока службы. Вы можете вернуть эти изделия в специализированные пункты приема.

ESPAÑOL

MSI como empresa comprometida con la protección del medio ambiente, recomienda:

Bajo la directiva 2002/96/EC de la Unión Europea en materia de desechos y/o equipos electrónicos, con fecha de rigor desde el 13 de agosto de 2005, los productos clasificados como "eléctricos y equipos electrónicos" no pueden ser depositados en los contenedores habituales de su municipio, los fabricantes de equipos electrónicos, están obligados a hacerse cargo de dichos productos al término de su periodo de vida. MSI estará comprometido con los términos de recogida de sus productos vendidos en la Unión Europea al final de su periodo de vida. Usted debe depositar estos productos en el punto limpio establecido por el ayuntamiento de su localidad o entregar a una empresa autorizada para la recogida de estos residuos.

NEDERLANDS

Om het milieu te beschermen, wil MSI u eraan herinneren dat...

De richtlijn van de Europese Unie (EU) met betrekking tot Vervuiling van Elektrische en Electronische producten (2002/96/EC), die op 13 Augustus 2005 in zal gaan kunnen niet meer beschouwd worden als vervuiling.

Fabrikanten van dit soort producten worden verplicht om producten retour te nemen aan het eind van hun levenscyclus. MSI zal overeenkomstig de richtlijn handelen voor de producten die de merknaam MSI dragen en verkocht zijn in de EU. Deze goederen kunnen geretourneerd worden op lokale inzamelingspunten.

SRPSKI

Da bi zaštitili prirodnu sredinu, i kao proizvođač koje vodi računa o ekologiji i prirodnoj sredini, MSI mora da vas podesti da...

Pre Direktivi Evropske unije ("EU") o odhaćenju električarske i električne opreme, Direktiva 2002/96/EC, koja stupa na snagu od 13. Avgusta 2005, proizvodi koji spadaju pod "električarsku i električnu opremu" ne mogu više biti odbačeni kao običan otpad i proizvođači ove opreme biće prinuđeni da uzmu na teret ove proizvode na kraju njihovog običajnog veka trajanja. MSI će poštovati zahtev o preuzimanju ovakvih proizvoda kojima je istekao vek trajanja, koji imaju MSI oznaku i koji su prodani u EU. Ove proizvode možete vratiti na lokalnim mestima za prikupljanje.

POLSKI

Aby chronić nasze środowisko naturalne oraz jako firma dbająca o ekologię, MSI przypomina, że...

Zgodnie z Dyrektywą Unii Europejskiej ("UE") dotyczącą odpadów elektrycznych i elektronicznych (Dyrektywa 2002/96/EC), która wchodzi w życie 13 sierpnia 2005, tzw. "produkty oraz wyposażenie elektryczne i elektroniczne" nie mogą być traktowane jako śmieci komunalne, tak więc producenci tych produktów będą zobowiązani do odbierania ich w momencie gdy produkt jest wycofywany z użycia. MSI wypełni wymagania UE, przyjmując produkty (sprzedawane na terenie Unii Europejskiej) wycofywane z użycia. Produkty MSI będzie można zwracać w wyznaczonych punktach zbiorczych.

TÜRKÇE

Çevreci özelliğiyle bilinen MSI dünyada çevreyi korumak için hatırlatır:

Avrupa Birliği (AB) Kararnamesi Elektrik ve Elektronik Malzeme Atığı, 2002/96/EC Kararnamesi altında 13 Ağustos 2005 tarihinden itibaren geçerli olmak üzere, elektrikli ve elektronik malzemeler diğer atıklar gibi çöpe atılmayacak ve bu elektronik cihazların üreticileri, cihazların kullanım süreleri bittikten sonra ürünleri geri toplamakla yükümlü olacaktır. Avrupa Birliği'ne satılan MSI markalı ürünlerin kullanım süreleri bittiğinde MSI ürünlerin geri alınması isteği ile işbirliği içerisinde olacaktır. Ürünlerinizi yerel toplama noktalarına bırakabilirsiniz.

ČESKY

Záleží nám na ochraně životního prostředí - společnost MSI upozorňuje...

Podle směrnice Evropské unie ("EU") o likvidaci elektrických a elektronických výrobků 2002/96/EC platné od 13. srpna 2005 je zakázáno likvidovat "elektrické a elektronické výrobky" v běžném komunálním odpadu a výrobci elektronických výrobků, na které se tato směrnice vztahuje, budou povinni odebírat takové výrobky zpět po skončení jejich životnosti. Společnost MSI uplní požadavky na odebrání výrobků značky MSI, prodávaných v zemích EU, po skončení jejich životnosti. Tyto výrobky můžete odevzdat v místních sběrnách.

MAGYAR

Annak érdekében, hogy környezetünket megvédjük, illetve környezetvédként fellépve az MSI emlékezteti Önt, hogy ...

Az Európai Unió („EU”) 2005. augusztus 13-án hatályba lépő, az elektronikus és elektronikus berendezések hulladékairól szóló 2002/96/EK irányelve szerint az elektronikus és elektronikus berendezések többé nem kezelhetőek lakossági hulladékként, és az ilyen elektronikus berendezések gyártói kötelessé válnak az ilyen termékek visszavételére azok hasznos élettartama végén. Az MSI betartja a termékvisszavételrel kapcsolatos követelményeket az MSI márkánév alatt az EU-n belül értékesített termékek esetében, azok élettartamának végén. Az ilyen termékeket a legközelebbi gyűjtőhelyre viheti.

ITALIANO

Per proteggere l'ambiente, MSI, da sempre amica della natura, ti ricorda che...

In base alla Direttiva dell'Unione Europea (EU) sullo Smaltimento dei Materiali Elettrici ed Elettronici, Direttiva 2002/96/EC in vigore dal 13 Agosto 2005, prodotti appartenenti alla categoria dei Materiali Elettrici ed Elettronici non possono più essere eliminati come rifiuti municipali: i produttori di detti materiali saranno obbligati a ritirare ogni prodotto alla fine del suo ciclo di vita. MSI si adeguerà a tale Direttiva ritirando tutti i prodotti marchiati MSI che sono stati venduti all'interno dell'Unione Europea alla fine del loro ciclo di vita. È possibile portare i prodotti nel più vicino punto di raccolta.

CONTENTS

Copyright Notice	ii
Trademarks	ii
Revision History	ii
Technical Support	ii
Safety Instructions	iii
FCC-B Radio Frequency Interference Statement	iv
WEEE (Waste Electrical and Electronic Equipment) Statement	v
Chapter 1 Getting Started	1-1
Mainboard Specifications	1-2
Mainboard Layout	1-5
Chapter 2 Hardware Setup	2-1
Quick Components Guide	2-2
CPU (Central Processing Unit)	2-3
Memory	2-6
Power Supply	2-8
Back Panel I/O	2-9
Connector	2-10
Jumper	2-18
Slot	2-19
Chapter 3 BIOS Setup	3-1
Entering Setup	3-2
The Menu Bar	3-4
Main	3-5
Advanced	3-6
Boot	3-18
Security	3-21
Chipset	3-22
Exit	3-25
Appendix A Intel ICH9R SATA RAID	A-1
ICH9R Introduction	A-2
BIOS Configuration	A-3
Installing Driver	A-9
Installing Software	A-11
RAID Migration Instructions	A-15
Appendix B LSI SAS RAID	B-1
1. Introduction to Integrated RAID	B-2
2. Integrated Mirroring Overview	B-3
3. Creating Integrated Mirroring Volumes	B-9
4. Integrated Striping Overview	B-16
5. Creating Integrated Striping Volumes	B-19

Chapter 1

Getting Started

Thank you for choosing the 5100 Master (MS-9665 v1. X), an excellent SSI CEB server board from MSI.

Based on the innovative **Intel® 5100 & ICH9R** chipsets for optimal system efficiency, the 5100 Master accommodates the latest Intel® Xeon® (Dual-Core Wolfdale-DP/Woodcrest & Quad-Core Clovertown/Harpertown) processors in Socket LGA771 and supports up to six DDR2 533/667MHz DIMM slots to provide the maximum of 48GB memory capacity.

In the entry-level and mid-range market segment, the 5100 Master can provide a high-performance solution for today's front-end and general purpose server/workstation, as well as in the future.

Mainboard Specifications

Processor
<ul style="list-style-type: none">- Supports Intel Xeon (Dual-Core Wolfdale-DP/Woodcrest & Quad-Core Clovertown/Harpertown) processors in Socket LGA771
FSB
<ul style="list-style-type: none">- FSB 1066/1333MHz
Chipset
<ul style="list-style-type: none">- Northbridge: Intel 5100- Southbridge: Intel ICH9R
Memory
<ul style="list-style-type: none">- 6 DDR2 533/667 DIMM slots- Maximum 48GB
LAN
<ul style="list-style-type: none">- Supports dual Gigabit Ethernet by Intel 82573V & 82566DM
SAS
<ul style="list-style-type: none">- 4 SAS ports by LSI Logic SAS1064E Host Controller- Data transfer rate at up to 3Gb/s
SATA
<ul style="list-style-type: none">- 6 SATAII ports support 6 SATAII devices- Data transfer rate at up to 3Gb/s
IDE
<ul style="list-style-type: none">- 1 IDE port by ITE IT8213F- Supports Ultra DMA 66/100/133 mode- Supports PIO, Bus Master operation mode
Floppy
<ul style="list-style-type: none">- 1 floppy port- Supports 1 FDD with 360KB, 720KB, 1.2MB, 1.44MB and 2.88MB
Graphics
<ul style="list-style-type: none">- XGI Volari Z7 graphics processor- 16MB graphics memory

Audio (Optional)

- Chip integrated by Realtek ALC888
- Flexible 2-channel audio with jack sensing
- Compliant with Azalia 1.0 Spec

IPMI (Optional)

- Hitachi H8S/2168 IPMI microcontroller

Slots

- 1 PCI-Express x16 slot
- 2 PCI-Express x8 slots (with x4 signal)
- 2 32-bit/33MHz PCI slots

Connectors

▶ **Back Panel**

- 1 PS/2 mouse & PS/2 keyboard port
- 1 serial port
- 1 VGA port
- 2 USB 2.0 ports
- 2 RJ-45 Gigabit LAN ports

▶ **Onboard Connectors**

- 2 USB 2.0 connectors
- 1 serial port connector
- 1 front panel audio connector
- 1 chassis intrusion connector
- 1 TPM connector
- 1 SPI Flash ROM connector (for debugging)

Form Factor

- SSI CEB: 12" X 10.5"

Mounting

- 7 mounting holes

System Management

H8S BMC chip and MSI iConsole AP support IPMI 2.0

► BMC Chip

- H8S 200-pin
- Host hardware interface: LPC interface
- Host software interface: KCS interface

► Memory Size

- 256 X 16 Bits SRAM

► Key Features

- IPMI 2.0 compliant
- Out-of-band LAN based management using RMCP
- FRU/SEL access
- Remote out-of-band alerts
- Event log
- Ability to update firmware inband unattended
- Remote access security (MD5)
- Out-of-band environmental monitoring and alerting
- Secure remote power control and system reset over Serial or shared NIC (RMCP)
- Supports onboard I2C Winbond 83793G & Winbond 83627 to extend hardware monitor feature
- Supports ASR (Automatic Server Restart)


► System Management

- Three SMBus 2.0 (I2C)
- One SMBus for Intel ESB2E
- One SMBus for IPMB
- One SMBus for Winbond 83793G & Winbond 83627
- CPU fan speed control dependent on system temperature
- System fan speed control dependent on system temperature

► Sensor Management

- Monitored Voltage: 12V, 5V, 3V, VBAT, VTT, Vcore, -12V
- Monitored Fan: 6 x System Fan, 2 x CPU Fan

Mainboard Layout



5100 Master (MS-9665 v1.X) SSI CEB Server Board


Chapter 2

Hardware Setup

This chapter provides you with the information about hardware setup procedures. While doing the installation, be careful in holding the components and follow the installation procedures. For some components, if you install in the wrong orientation, the components will not work properly.

Use a grounded wrist strap before handling computer components. Static electricity may damage the components.

Quick Components Guide



Important

CAUTION!!! Please note that the CPU1/CPU2 VRM & memory/south bridge area should be respectively kept under 105°C and 85°C. To ensure system stability, always protect the system with proper cooling. Otherwise, overheating may damage the system.

CPU (Central Processing Unit)

This mainboard supports the latest Intel® Xeon® (Dual-Core Wolfdale-DP/Woodcrest & Quad-Core Clovertown/Harpertown) processors in Socket LGA771. When you are installing the CPU, make sure that you install the cooler to prevent the CPU from overheating. If you do not have a CPU cooler, contact your dealer to purchase and install them before turning on the computer.




Important

1. *Overheating will seriously damage the CPU and system. Always make sure the cooling fan can work properly to protect the CPU from overheating.*
2. *Make sure that you apply an even layer of heat sink paste (or thermal tape) between the CPU and the heatsink to enhance heat dissipation.*
3. *While replacing the CPU, always turn off the power supply or unplug the power supply's power cord from the grounded outlet first to ensure the safety of CPU.*


Introduction to LGA 771 CPU

The pin-pad side of LGA 771 CPU.



Yellow triangle is the Pin 1 indicator


The surface of LGA 771 CPU. Remember to apply some silicone heat transfer compound on it for better heat dispersion.



Yellow triangle is the Pin 1 indicator

Installing the LGA771 CPU


1. Locate the CPU socket.
2. Raise the load lever up to its full extent.



3. Open the load plate.
4. After confirming the CPU direction (indicated below with red circles) for correct mating, put down the CPU in the socket housing frame. Be sure to grasp on the edge of the CPU base. Note that the alignment keys are matched.



5. Visually inspect if the CPU is seated well into the socket. If not, take out the CPU with pure vertical motion and reinstall.
6. Cover the load plate onto the package.
7. Press down the load lever lightly onto the load plate and then secure the lever with the hook under the retention tab.



Installing the Intel CPU Cooler


1. Flip over the mainboard and locate the position of the CPU sockets.
2. Install the backplates to the back of the CPU sockets with holes aligned.



CPU cooler backplate




3. Install the CPU(s) following the instructions on page 2-4.
4. Apply some heat paste all over the top of the CPU and place the cooler onto it.
5. Connect the CPU fan power cord to CPUFAN1.
Note: If dual processors are installed, connect the second CPU fan power cord to CPUFAN2.



6. Screw to secure the CPU cooler.
7. Install another CPU fan sink if necessary.




Mainboard photos shown in this section are for demonstration only and may differ from the actual look of your mainboard.



Memory

These DIMM slots are intended for system memory modules.



Dual-Channel Mode Population Rule


In Dual-Channel mode, the memory modules can transmit and receive data with two data bus lines simultaneously. Dual-Channel mode is enabled when the installed memory capacities of both DIMM channels are equal. If different speed DIMMs are used between channels, the slowest memory timing will be used.

Dual-Channel mode can be achieved with two, three or four DIMMs. To achieve Dual-Channel mode, the following conditions must be met:


- * Matched DIMM configuration in each channel
- * Same Density (512MB, 1GB, 2GB, etc.)
- * Matched in both Channel A and Channel B memory channels
- * Populate symmetrical memory slots

Configurations that do not match the above conditions will revert to Single-Channel mode.


2 DIMMs



3 DIMMs



4 DIMMs



5 DIMMs	2GB	DIMMB1
	2GB	DIMMA1
	1GB	DIMMB2
	2GB	DIMMA2
	1GB	DIMMB3
		DIMMA3
6 DIMMs	2GB	DIMMB1
	2GB	DIMMA1
	2GB	DIMMB2
	2GB	DIMMA2
	1GB	DIMMB3
	1GB	DIMMA3

Installing Memory Modules


1. Locate the DIMM slots on the mainboard. Flip open the retaining clip at each side of the DIMM slot.
2. Align the notch on the DIMM with the key on the slot. Insert the DIMM vertically into the DIMM slot. Then push it in until the golden finger on the DIMM is deeply inserted in the DIMM slot. The retaining clip at each side of the DIMM slot will automatically close if the DIMM is properly seated.



Important

You can barely see the golden finger if the DIMM is properly inserted in the DIMM slot.

3. Manually check if the DIMM has been locked in place by the retaining clips at the sides.
4. Follow the same procedures to install more DIMMs if necessary.





Power Supply

System Power Connector: JPWR1

This connector allows you to connect to an SSI power supply. To connect to the SSI power supply, make sure the plug of the power supply is inserted in the proper orientation and the pins are aligned. Then push down the power supply firmly into the connector.

12V CPU Power Connector: JPWR2

This connector provides 12V power output to the CPUs.



JPWR1 Pin Definition

PIN	SIGNAL	PIN	SIGNAL
1	+3.3V	13	+3.3V
2	+3.3V	14	-12V
3	GND	15	GND
4	+5V	16	PS-ON#
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	PWROK	20	Res
9	5VSB	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	+3.3V	24	GND

JPWR2 Pin Definition


PIN	SIGNAL	PIN	SIGNAL
1	GND	5	+12V
2	GND	6	+12V
3	GND	7	+12V
4	GND	8	+12V



Important

1. Make sure that all power connectors are connected to proper power supplies to ensure stable operation of the mainboard.
2. Power supply of 600 watts (and above) is highly recommended for system stability.
3. SSI 12V power connection should be greater than 18A.

Back Panel I/O



► Mouse/Keyboard

The standard PS/2® mouse/keyboard DIN connector is for a PS/2® mouse/keyboard.

► USB Port

The USB (Universal Serial Bus) port is for USB devices such as keyboard, mouse, or other USB-compatible devices.

► Serial Port


The serial port is a 16550A high speed communications port that sends/ receives 16 bytes FIFOs. You can attach a serial mouse or other serial devices directly to the connector.

► VGA Port

The DE-15 female connector is provided for monitor.

► LAN

The standard RJ-45 LAN jack is for connection to Local Area Network (LAN). You can connect a network cable to it.




RJ-45 LAN Jack

LED	Color	LED State	Condition
Left	Orange	Off	LAN link is not established.
		On (steady state)	LAN link is established.
		On (brighter & pulsing)	The computer is communicating with another computer on the LAN.
Right	Green	Off	10 Mbit/sec data rate is selected.
		On	100 Mbit/sec data rate is selected.
	Orange	On	1000 Mbit/sec data rate is selected.

Connector


Floppy Disk Drive Connector: FDD1

This connector supports 360KB, 720KB, 1.2MB, 1.44MB or 2.88MB floppy disk drive.



IDE Connector: IDE1

This connector supports IDE hard disk drives, optical disk drives and other IDE devices.



Important


If you install two IDE devices on the same cable, you must configure the drives separately to master / slave mode by setting jumpers. Refer to IDE device's documentation supplied by the vendors for jumper setting instructions.

Serial Attached SCSI Connector: SAS_1 ~ SAS_4

The SAS connector is a new generation serial communication protocol for devices designed to allow for much higher speed data transfers. It supports data transfer speeds up to 3 Gbit/s. SAS uses serial communication instead of the parallel method found in traditional SCSI devices but still uses SCSI commands for interacting with SAS devices. Each SAS connector can connect to 1 disk drive.

Serial ATA Connector: SATA1 ~ SATA6

This connector is a high-speed Serial ATA interface port. Each connector can connect to one Serial ATA device.



Important

Please do not fold the SATA/SAS accessory cable into 90-degree angle. Otherwise, data loss may occur during transmission.


Chassis Intrusion Switch Connector: JINT1

This connector connects to the chassis intrusion switch cable. If the chassis is opened, the chassis intrusion mechanism will be activated. The system will record this status and show a warning message on the screen. To clear the warning, you must enter the BIOS utility and clear the record.




Fan Power Connector: CPU_FAN1 / 2, SYS_FAN1 / 2 / 3 / 4 / 5

The fan power connectors support system cooling fan with +12V. When connecting the wire to the connectors, always note that the red wire is the positive and should be connected to the +12V; the black wire is Ground and should be connected to GND. If the mainboard has a System Hardware Monitor chipset onboard, you must use a specially designed fan with speed sensor to take advantage of the CPU fan control.



CPU_FAN1/2



SYS_FAN1/2/3/4/5



Important

1. Please refer to the recommended CPU fans at processor's official website or consult the vendors for proper CPU cooling fan.
2. Users are suggested to enter the BIOS Setup Utility to set up the Smart Fan Control function.

BMC Connector: J_BOOT1, J_BOOT2, J_H8_RST1, J_IPMB1, J_ICMB1, J1

These connectors are used to control the H8 BMC (Baseboard Management Controller).

J_BOOT1

1 

Pin Definition

PIN	SIGNAL
1	BOOT_TXD_CON
2	BOOT_RXD_CON
3	GND

J_BOOT2

1 

Pin Definition

PIN	SIGNAL
1	BootMode
2	GND

J_H8_RST1

1 

Pin Definition

PIN	SIGNAL
1	H8_RESET
2	GND

J_IPMB1



Pin Definition

PIN	SIGNAL
1	IPMB_DATA
2	GND
3	IPMB_CLK


J_ICMB1

1 

Pin Definition

PIN	SIGNAL
1	BMC_RXD0
2	BMC_TXD0
3	ICMB_EN

J1



Pin Definition

PIN	SIGNAL	PIN	SIGNAL
1	ETCK	2	GND
3	ETRST#	4	GND
5	ETDO	6	GND
7	H2C_RES#	8	3.3VDUAL
9	ETMS	10	GND
11	ETDI	12	GND
13	H8_RESET#	14	GND

Serial Port Connector: COM2

This connector is a 16550A high speed communications port that sends/receives 16 bytes FIFOs. You can attach a serial device to it.

Pin Definition

PIN	SIGNAL	DESCRIPTION
1	DCD	Data Carry Detect
2	SIN	Serial In or Receive Data
3	SOUT	Serial Out or Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicate





Front USB Connector: JUSB2, JUSB3

This connector, compliant with Intel® I/O Connectivity Design Guide, is ideal for connecting high-speed USB interface peripherals such as **USB HDD, digital cameras, MP3 players, printers, modems and the like.**

Pin Definition

PIN	SIGNAL	PIN	SIGNAL
1	VCC	2	VCC
3	USB0-	4	USB1-
5	USB0+	6	USB1+
7	GND	8	GND
9	Key(no pin)	10	NC



Important

Note that the pins of VCC and GND must be connected correctly to avoid possible damage.

SPI Flash ROM Connector: JSPI1

This connector is used to flash SPI flash ROM.

JSPI1




Pin Definition

Pin	Description	Pin	Description
1	VCC3_SB	2	VCC3_SB
3	SPI_MISO_F	4	SPI_MOSI_F
5	SPI_CS0_F#	6	SPI_CLK_F
7	GND	8	GND
9	SPI_HOLD#	10	NC

TPM Connector: JTPM1 (Optional)

This connector connects to an optional TPM (Trusted Platform Module). Please refer to the TPM security platform manual for more details.

JTPM1



PIN	SIGNAL	DESCRIPTION	PIN	SIGNAL	DESCRIPTION
1	LCLK	LPCclock	2	3V dual/3V_STB	3V dual or 3V standby power
3	LRST#	LPCreset	4	VCC3	3.3V power
5	LAD0	LPC address & data pin0	6	SIRQ	Serial IRQ
7	LAD1	LPC address & data pin1	8	VCC5	5V power
9	LAD2	LPC address & data pin2	10	KEY	No pin
11	LAD3	LPC address & data pin3	12	GND	Ground
13	LFRAME#	LPCFrame	14	GND	Ground

Front Panel Audio Connector: JAUD1

This connector allows you to connect the front panel audio and is compliant with Intel® Front Panel I/O Connectivity Design Guide.



HD Audio Pin Definition

PIN	SIGNAL	DESCRIPTION
1	MIC_L	Microphone - Left channel
2	GND	Ground
3	MIC_R	Microphone - Right channel
4	PRESENCE#	Active low signal-signals BIOS that a High Definition Audio dongle is connected to the analog header. PRESENCE# = 0 when a High Definition Audio dongle is connected
5	LINEout_R	Analog Port - Right channel
6	MIC_JD	Jack detection return from front panel microphone JACK1
7	Front_JD	Jack detection sense line from the High Definition Audio CODEC jack detection resistor network
8	NC	No control
9	LINEout_L	Analog Port - Left channel
10	LINEout_JD	Jack detection return from front panel JACK2

I2C Bus Connector: J21

This connector, known as I²C, is used to connect System Management Bus (SMBus) interface.




Pin Definition

PIN	SIGNAL
1	SMBUS_SDA
2	GND
3	SMBUS_SCL
4	5VCC
5	SMBUS_ALERT#
6	PCIRST#

Front Panel Connector: J22

The mainboard provides one front panel connector for electrical connection to the front panel switches and LEDs.



J22 Pin Definition

PIN	SIGNAL	DESCRIPTION
1	HDD_LED +	HDD LED +
2	PLED	PowerLED
3	HDD_LED -	HDD LED -
4	SLED	SuspendLED
5	FP_RST+	Front Panel Reset +
6	FP_BTN -	Front Panel Button -
7	FP_RST-	Front Panel Reset -
8	GND	Ground
9	NC	No connection
10	KEY	Key
11	SYS_FAULT_H8S	System fault LED
12	ID_LED_H8S	System ID LED
13	NC	No connection
14	LAN1_LED	LAN1 LED
15	NC	No connection
16	LAN2_LED	LAN2 LED

Jumper

BIOS Recovery Jumper: J_BOOT3

Users can short connect pin#2-3 to recover the system BIOS with a Recovery Floppy. When the system is done with the job, the buzzer will beep to remind the user to set the jumper to its normal state (pin#1-2 short connected).



Clear CMOS Jumper: J_CMOS1

There is a CMOS RAM onboard that has a power supply from an external battery to keep the data of system configuration. With the CMOS RAM, the system can automatically boot OS every time it is turned on. If you want to clear the system configuration, set the jumper to clear data.




Important

You can clear CMOS by shorting 2-3 pin while the system is off. Then return to 1-2 pin position. Avoid clearing the CMOS while the system is on; it will damage the mainboard.

Slot

PCI (Peripheral Component Interconnect) Express Slot

The PCI Express slot supports the PCI Express interface expansion card.
The PCI Express x 16 slot supports up to 4.0 GB/s transfer rate.
The PCI Express x 8 slot supports up to 2.0 GB/s transfer rate.




PCI Express x16 Slot



PCI Express x8 Slot

PCI (Peripheral Component Interconnect) Slot

The PCI slot supports LAN card, SCSI card, USB card, and other add-on cards that comply with PCI specifications.



32-bit PCI Slot



Important

When adding or removing expansion cards, make sure that you unplug the power supply first. Meanwhile, read the documentation for the expansion card to configure any necessary hardware or software settings for the expansion card, such as jumpers, switches or BIOS configuration.

PCI Interrupt Request Routing

The IRQ, acronym of interrupt request line and pronounced I-R-Q, are hardware lines over which devices can send interrupt signals to the microprocessor. The PCI IRQ pins are typically connected to the PCI bus pins as follows:

DEVICE	IDSEL	INT A	INT B	INT C	INT D	REQ	GNT
PCI	AD20	PCI_PIRQ#0	PCI_PIRQ#1	PCI_PIRQ#2	PCI_PIRQ#3	PCI_REQ#0	PCI_GNT#0
PCI	AD21	PCI_PIRQ#3	PCI_PIRQ#0	PCI_PIRQ#0	PCI_PIRQ#2	PCI_REQ#1	PCI_GNT#1
IT8213F	AD1921	PCI_PIRQ#2				PCI_REQ#2	PCI_GNT#21

Chapter 3

BIOS Setup

This chapter provides information on the BIOS Setup program and allows you to configure the system for optimum use.

You may need to run the Setup program when:

- ≈ An error message appears on the screen during the system booting up, and requests you to run SETUP.
- ≈ You want to change the default settings for customized features.

Entering Setup

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press key to enter Setup.

Press Del to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system by turning it OFF and On or pressing the RESET button. You may also restart the system by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.



Important

1. The items under each BIOS category described in this chapter are under continuous update for better system performance. Therefore, the description may be slightly different from the latest BIOS and should be held for reference only.
2. Upon boot-up, the 1st line appearing after the memory count is the BIOS version. It is usually in the format:

A9665IMS V1.0 031508 where:

1st digit refers to BIOS maker as A = AMI, W = AWARD, and P = PHOENIX.

2nd - 5th digit refers to the model number.

6th digit refers to the chipset as I = Intel, N = nVidia, and V = VIA.

7th - 8th digit refers to the customer as MS = all standard customers.

V1.0 refers to the BIOS version.

031508 refers to the date this BIOS was released.

Control Keys

<↑>	Move to the previous item
<↓>	Move to the next item
<←>	Move to the item in the left hand
<→>	Move to the item in the right hand
<Enter>	Select the item
<Esc>	Jumps to the Exit menu or returns to the main menu from a submenu
<+/PU>	Increase the numeric value or make changes
<-/PD>	Decrease the numeric value or make changes
<F8>	Load Optimized Defaults
<F9>	Load Fail-Safe Defaults
<F10>	Save all the CMOS changes and exit

Getting Help

After entering the Setup menu, the first menu you will see is the Main Menu.

Main Menu

The main menu lists the setup functions you can make changes to. You can use the arrow keys (↑↓) to select the item. The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Sub-Menu


If you find a right pointer symbol (as shown in the right view) appears to the left of certain fields that means a sub-menu can be launched from this field. A sub-menu contains additional options for a field parameter. You can use arrow keys (↑↓) to highlight the field and press <Enter> to call up the sub-menu. Then you can use the control keys to enter values and move from field to field within a sub-menu. If you want to return to the main menu, just press the <Esc >.

▶ Primary IDE Master
▶ Secondary IDE Master

General Help <F1>

The BIOS setup program provides a General Help screen. You can call up this screen from any menu by simply pressing <F1>. The Help screen lists the appropriate keys to use and the possible selections for the highlighted item. Press <Esc> to exit the Help screen.

The Menu Bar



► Main

Use this menu for basic system configurations, such as time, date etc.

► Advanced

Use this menu to set up the items of special enhanced features.

► Boot

Use this menu to specify the priority of boot devices.

► Security

Use this menu to set supervisor and user passwords.


► Chipset

This menu controls the advanced features of the onboard Northbridge and Southbridge.

► Exit

This menu allows you to load the BIOS default values or factory default settings into the BIOS and exit the BIOS setup utility with or without changes.

Main



► AMI BIOS, Processor, System Memory

These items show the firmware and hardware specifications of your system. Read only.


► System Time

This setting allows you to set the system time. The time format is <Hour> <Minute> <Second>.


► System Date

This setting allows you to set the system date. The date format is <Day>, <Month> <Date> <Year>.

Advanced



► CPU Configuration



► C1E Support

When the C1E Support (Enhanced Halt Powerdown State) is enabled, the processor will transition to a lower core to bus ratio and lower voltage ID driven by the processor to the voltage regulator before entering Halt Powerdown State (C1). Not all processors support Enhanced Halt Powerdown State (C1E).

► Hardware Prefetcher

The processor has a hardware prefetcher that automatically analyzes its requirements and prefetches data and instructions from the memory into the Level 2 cache that are likely to be required in the near future. This reduces the latency associated with memory reads. When enabled, the processor's hardware prefetcher will be enabled and allowed to automatically prefetch data and code for the processor. When disabled, the processor's hardware prefetcher will be disabled.

► Adjacent Cache Line Prefetch

The processor has a hardware adjacent cache line prefetch mechanism that automatically fetches an extra 64-byte cache line whenever the processor requests for a 64-byte cache line. This reduces cache latency by making the next cache line immediately available if the processor requires it as well. When enabled, the processor will retrieve the currently requested cache line, as well as the subsequent cache line. When disabled, the processor will only retrieve the currently requested cache line.

► Max CPUID Value Limit

The Max CPUID Value Limit BIOS feature allows you to circumvent problems with older operating systems that do not support the Intel Pentium 4 processor with Hyper-Threading Technology. When enabled, the processor will limit the maximum CPUID input value to 03h when queried, even if the processor supports a higher CPUID input value. When disabled, the processor will return the actual maximum CPUID input value of the processor when queried.

► Intel(R) Virtualization Tech

Virtualization enhanced by Intel Virtualization Technology will allow a platform to run multiple operating systems and applications in independent partitions. With virtualization, one computer system can function as multiple "virtual" systems.

► CPU TM/Thermal Throttle

Thermal Management throttles the processor back as it reaches its maximum operating temperature. Throttling reduces the number of processing cycles, thereby diminishing the heat dissipation of the CPU. This cools the unit. Once the CPU has reached a safe operating temperature, thermal throttling is automatically disabled, and normal full speed processing begins again.

► Execute Disable Bit Capability

Intel's Execute Disable Bit functionality can prevent certain classes of malicious "buffer overflow" attacks when combined with a supporting operating system. This functionality allows the processor to classify areas in memory by where

application code can execute and where it cannot. When a malicious worm attempts to insert code in the buffer, the processor disables code execution, preventing damage or worm propagation.

► Core Multi-Processing

CMP (Core Multi Processing) is the ability to have many independent processing cores on a single die, each with their own L1 Code & Data caches, Local APICs & thermal controls, while having a shared L2 cache, power management & bus interface. Intel multi-core architecture has a single Intel processor package that contains two or more processor "execution cores," or computational engines to enable enhanced performance and more-efficient simultaneous processing of multiple tasks.


► PECC

This setting controls the Intel PECC (Platform Environment Control Interface) interface in the processor for better thermal management.

► Intel(R) SpeedStep(tm) Tech

EIST (Enhanced Intel SpeedStep Technology) allows the system to dynamically adjust processor voltage and core frequency, which can result in decreased average power consumption and decreased average heat production.

► IDE Configuration




► SATA#1 Configuration, SATA#2 Configuration

These settings specify the operation modes of the SATA ports.

► Configure SATA#1 as

This setting specifies the function of the on-chip SATA controller.

► Primary/Secondary/Third/Fourth/Fifth IDE Master/Slave



[Type]

Press PgUp/<+> or PgDn/<-> to select [Manual], [None] or [Auto] type. Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category. If your hard disk drive type is not matched or listed, you can use [Manual] to define your own drive type manually.

[LBA/Large Mode]

Enabling LBA causes Logical Block Addressing to be used in place of Cylinders, Heads and Sectors

[Block(Multi-Sector Transfer)]

Any selection except Disabled determines the number of sectors transferred per block
Indicates the type of PIO (Programmed Input/Output)

[PIO Mode]

[DMA Mode]


Indicates the type of Ultra DMA

[S.M.A.R.T.]


This allows you to activate the S.M.A.R.T. (Self-Monitoring Analysis & Reporting Technology) capability for the hard disks. S.M.A.R.T is a utility that monitors your disk status to predict hard disk failure. This gives you an opportunity to move data from a hard disk that is going to fail to a safe place before the hard disk becomes offline.

[32 Bit Data Transfer]

Enables 32-bit communication between CPU and IDE controller

► Floppy Configuration**► Floppy A, Floppy B**

This setting allows you to set the type of floppy drives installed.

► Super IO Configuration**► Onboard Floppy Controller**

This setting disables/enables the onboard floppy disk drive controller.

► Serial Port 1 Address, Serial Port 2 Address





Select an address and a corresponding interrupt for the serial port 1/2.



► Serial Port2 Mode

This setting allows you to specify the operation mode for the serial port 2.


► IPMI SDR Hardware Health Information

These items display the current status of all of the monitored hardware devices/ components such as voltages, temperatures and all fans' speeds.



▶ ACPI Configuration**▶ General ACPI Configuration****▶ Suspend Mode**


This item specifies the power saving modes for ACPI function. If your operating system supports ACPI, you can choose to enter the Standby mode in S1 (POS) or S3 (STR) fashion through the setting of this field.

▶ Chipset ACPI Configuration**▶ USB Device Wakeup From S3**

This setting allows the activity of the USB device to wake up the system from the S3 sleep state.

▶ High Performance Event Timer

The High Precision Event Timer (HPET) was developed jointly by Intel and Microsoft to meet the timing requirements of multimedia and other time-sensitive applications. In addition to extending the capabilities and precision of a system, the HPET also improves system performance.

► APM Configuration**► Resume On Ring**

An input signal on the serial Ring Indicator (RI) line (in other words, an incoming call on the modem) awakens the system from a soft off state.

► Resume On LAN

This field specifies whether the system will be awakened from power saving modes when activity or input signal of onboard LAN is detected.


► Resume On PME#

When setting to [Enabled], this setting allows your system to be awakened from the power saving modes through any PME (Power Management Event) on PCI slots.

► Resume On RTC Alarm

When [Enabled], you can set the date and time at which the RTC (real-time clock) alarm awakens the system from suspend mode.

► **Event Log Configuration**



► **View Event Log**

Press [Enter] to view the contents of the DMI event log.


► **Mark All Events As Read**

Press [Enter] and a screen pops up, asking users to confirm whether or not to clear all DMI event logs immediately. Press [Y] and [Enter], the BIOS will clear all DMI event logs right away.

► **Clear Event Log**

When this setting is set to [Yes], the DMI event log will be cleared at next POST stage. Then, the BIOS will automatically set this option to [No].

► IPMI 2.0 Configuration




► Status of BMC, BMC Firmware Version

These settings show the status of the BMC (Baseboard Management Controller) chip and its firmware version. Read only.

► View BMC System Event Log

Use this function to view system event logs recorded by BMC.



► Clear BMC System Event Log

Use this function to clear system event logs recorded by BMC.

► BMC Watch Dog Timer Action

Select the watch-dog timer response.

► Notify BMC FAN Type

This setting selects the BMC fan type.

► BMC LAN Configuration

Use these settings to set up the IP address, gateway, and IP subnet mask for your system network.

LAN Configuration.	
BMC IP Source:	Static IP
Current MAC address in BMC:	00.02.04.06.08.00
Notify BMC IP Source [No change]	
Current IP address in BMC:	192.168.001.007
Current Subnet Mask in BMC:	255.255.255.000
Current Gateway in BMC:	192.168.001.001

► Remote Access Configuration

Advanced	
Configure Remote Access type and parameters	
Remote Access	[Enabled]
Serial port number	[COM1]
Base Address, IRQ	[3F8h, 4]
Serial Port Mode	[115200 B,n,1]
Flow Control	[None]
Redirection After BIOS POST	[Always]
Terminal Type	[ANSI]
VT-UTF8 Combo Key Support	[Enabled]
Sredir Memory Display Delay	[No Delay]

► Remote Access

The setting enables/disables the remote access function. When set to [Enabled], users may configure the following settings for remote access type and parameters.

► Serial Port Number, Base Address, IRQ, Serial Port Mode

Use these settings to configure ports for remote access.

► Flow Control

Flow control is the process of managing the rate of data transmission between two nodes. It's the process of adjusting the flow of data from one device to another to ensure that the receiving device can handle all of the incoming data. This is particularly important where the sending device is capable of sending data much faster than the receiving device can receive it.

► **Redirection After BIOS POST**

This setting determines whether or not to keep terminals' console redirection running after the BIOS POST has booted.

► **Terminal Type**

To operate the system's console redirection, you need a terminal supporting ANSI terminal protocol and a RS-232 null modem cable connected between the host system and terminal(s). This setting specifies the type of terminal device for console redirection.


► **VT-UTF8 Combo Key Support**

This setting enables/disables the VT-UTF8 combination key support for ANSI/VT100 terminals.

► **Sredir Memory Display Delay**

Use this setting to set the delay in seconds to display memory information.


► **Trusted Computing**




► **TCG/TPM Support**

This setting controls the Trusted Platform Module (TPM) designed by the Trusted Computing Group (TCG). TPMs are special-purpose integrated circuits (ICs) built into a variety of platforms to enable strong user authentication and machine attestation—essential to prevent inappropriate access to confidential and sensitive information and to protect against *compromised networks*. TPM Services is now a new feature set in Windows Server "Longhorn" and Windows Vista.

Boot



► Boot Settings Configuration



► Quick Boot

Enabling this setting will cause the BIOS power-on self test routine to skip some of its tests during bootup for faster system boot.

► Quiet Boot

This BIOS feature determines if the BIOS should hide the normal POST messages with the motherboard or system manufacturer's full-screen logo.

When it is enabled, the BIOS will display the full-screen logo during the boot-up sequence, hiding normal POST messages.

When it is disabled, the BIOS will display the normal POST messages, instead of the full-screen logo.

Please note that enabling this BIOS feature often adds 2-3 seconds of delay to the booting sequence. This delay ensures that the logo is displayed for a sufficient amount of time. Therefore, it is recommended that you disable this BIOS feature for a faster boot-up time.

► AddOn ROM Display Mode

This item is used to determine the display mode when an optional ROM is initialized during POST. When set to [Force BIOS], the display mode used by AMI BIOS is used. Select [Keep Current] if you want to use the display mode of optional ROM.

► Bootup Num-Lock

This setting is to set the Num Lock status when the system is powered on.

Setting to [On] will turn on the Num Lock key when the system is powered on.

Setting to [Off] will allow users to use the arrow keys on the numeric keypad.

► PS/2 Mouse Support

Select [Enabled] if you need to use a PS/2-interfaced mouse in the operating system.

► Wait For 'F1' If Error

When this setting is set to [Enabled] and the boot sequence encounters an error, it asks you to press F1. If disabled, the system continues to boot without waiting for you to press any keys.

► Hit 'DEL' Message Display

Set this option to [Disabled] to prevent the message as follows:

Hit Del if you want to run setup


It will prevent the message from appearing on the first BIOS screen when the computer boots. Set it to [Enabled] when you want to run the BIOS Setup Utility.

► Interrupt 19 Capture

Interrupt 19 is the software interrupt that handles the boot disk function. When enabled, this BIOS feature allows the ROM BIOS of these host adaptors to "capture" Interrupt 19 during the boot process so that drives attached to these adaptors can function as bootable disks. In addition, it allows you to gain access to the host adaptor's ROM setup utility, if one is available.

When disabled, the ROM BIOS of these host adaptors will not be able to "capture" Interrupt 19. Therefore, you will not be able to boot operating systems from any bootable disks attached to these host adaptors. Nor will you be able to gain access to their ROM setup utilities.


► **Boot Device Priority**



► **1st Boot Device**

The items allow you to set the sequence of boot devices where BIOS attempts to load the disk operating system. First press <Enter> to enter the sub-menu. Then you may use the arrow keys (↑↓) to select the desired device, then press <+>, <-> or <PageUp>, <PageDown> key to move it up/down in the priority list.


► **Removable Drives**



► **1st Drive**

This setting allows users to set the priority of the removable devices. First press <Enter> to enter the sub-menu. Then you may use the arrow keys (↑↓) to select the desired device, then press <+>, <-> or <PageUp>, <PageDown> key to move it up/down in the priority list.

Security



► Supervisor Password / Change Supervisor Password

Supervisor Password controls access to the BIOS Setup utility. These settings allow you to set or change the supervisor password.

► User Password / Change User Password

User Password controls access to the system at boot. These settings allow you to set or change the user password.


► Chassis Intrusion

The field enables or disables the feature of recording the chassis intrusion status and issuing a warning message if the chassis is once opened. To clear the warning message, set the field to [Reset]. The setting of the field will automatically return to [Enabled] later.


► Boot Sector Virus Protection

This function protects the BIOS from accidental corruption by unauthorized users or computer viruses.

Chipset



▶ North Bridge Configuration



▶ Hyper-Threading Function

Hyper-Threading Technology (HT Technology) provides thread-level parallelism on each processor, resulting in more efficient use of processor resources,

higher processing throughput, and improved performance on today's multithreaded software.

► **Crystal Beach/DMA/IOAT**

Use this setting to enable/disable the I/O Acceleration Technology (IOAT) for fast, scaleable, and reliable networking.

► **MCH Channel Mode**

This setting specifies the MCH memory channel mode.


► **Patrol Scrubbing, Demand Scrubbing**

These settings support demand and patrol scrubbing to detect and repair memory problems. If it encounters a memory problem that cannot be repaired, it marks the bad location so that it will not be used in the future.

► **Read Completion Coalescing**

This setting controls the coalescing mechanism for read operations.

► **South Bridge Configuration**



► **Boot Graphics Adapter Priority**

This item specifies which VGA card is your primary graphics adapter.

► **USB 2.0 Controller**

Set to [Enabled] if you need to use any USB 2.0 device in the operating system that does not support or have any USB 2.0 driver installed, such as DOS and SCO Unix.

► **GbE LAN (82566DM) Controller, GbE LAN (82573V) Controller**

These settings disable/enable the specified LAN controllers.

► **82566DM LAN Boot ROM, 82573V LAN Boot ROM**

The items enable or disable the initialization of the onboard LAN Boot ROMs

during bootup. Selecting [Disabled] will speed up the boot process.

► **82566DM LAN Wake Up From S5**

This field specifies whether the system will be awakened from power saving modes when activity or input signal of onboard LAN is detected.

► **HDA Controller**


This setting controls the High Definition Audio interface integrated in the Southbridge.

► **Restore on AC Power Loss**

This setting specifies whether your system will reboot after a power failure or interrupt occurs. Available settings are:

- [Power Off] Leaves the computer in the power off state.
- [Power On] Leaves the computer in the power on state.
- [Last State] Restores the system to the previous status before power failure or interrupt occurred.

Exit



► Save Changes and Exit

Save changes to CMOS and exit the Setup Utility.

► Discard Changes and Exit

Abandon all changes and exit the Setup Utility.

► Discard Changes

Abandon all changes and continue with the Setup Utility.

► Load Optimal Defaults

Use this menu to load the default values set by the mainboard manufacturer specifically for optimal performance of the mainboard.

► Load Failsafe Defaults

Use this menu to load the default values set by the BIOS vendor for stable system performance.

Appendix A

Intel ICH9R SATA RAID

This appendix will assist users in configuring and enabling RAID functionality on platforms. The ICH9R RAID solution supports RAID level 0 (striping), RAID level 1 (mirroring), RAID level 5 (striping with parity) and RAID level 10 (striping and mirroring).

ICH9R Introduction

The ICH9R provides a hybrid solution that combines 6 independent SATAII ports for support of up to 6 Serial ATAII (Serial ATAII RAID) drives.

Serial ATAII (SATAII) is the latest generation of the ATA interface. SATA hard drives deliver blistering transfer speeds up to 300MB/sec. Serial ATA uses long, thin cables, making it easier to connect your drive and improving the airflow inside your PC. The most outstanding features are:

1. Supports 300MB/s transfers with CRC error checking.
2. Supports Hot-plug-n-play feature.
3. Data handling optimizations including tagged command queuing, elevator seek and packet chain command.

Intel® ICH9R offers RAID level 0 (Striping), RAID level 1 (Mirroring and Duplexing), RAID level 5 (Block Interleaved Distributed Parity), RAID level 10 (A Stripe of Mirrors) and Intel® Matrix Storage Technology.

RAID 0 breaks the data into blocks which are written to separate hard drives. Spreading the hard drive I/O load across independent channels greatly improves I/O performance. RAID 1 provides data redundancy by mirroring data between the hard drives and provides enhanced read performance. RAID 5 Provides data striping at the byte level and also stripe error correction information. This results in excellent performance and good fault tolerance. Level 5 is one of the most popular implementations of RAID. RAID 10 Not one of the original RAID levels, multiple RAID 1 mirrors are created, and a RAID 0 stripe is created over these. Intel Matrix RAID Technology is the advanced ability for two RAID volumes to share the combined space of two hard drives being used in unison.



Important

The least number of hard drives for RAID 0, RAID 1 or Matrix mode is 2. The least number of hard drives for RAID 10 mode is 4. And the least number of hard drives for RAID 5 mode is 3.

All the information/ volumes/ pictures listed in your system might differ from the illustrations in this appendix.

BIOS Configuration

The Intel Matrix Storage Manager Option ROM should be integrated with the system BIOS on all motherboards with a supported Intel chipset. The Intel Matrix Storage Manager Option ROM is the Intel RAID implementation and provides BIOS and DOS disk services. Please use <Ctrl> + <I> keys to enter the "Intel(R) RAID for Serial ATA" status screen, which should appear early in system boot-up, during the POST (Power-On Self Test). Also, you need to enable the RAID function in BIOS to create, delete and reset RAID volumes.

Using the Intel Matrix Storage Manager Option ROM

1. Creating, Deleting and Resetting RAID Volumes:

The Serial ATA RAID volume may be configured using the RAID Configuration utility stored within the Intel RAID Option ROM. During the Power-On Self Test (POST), the following message will appear for a few seconds:



Important

The "Driver Model", "Serial #" and "Size" in the following example might be different from your system.

```

Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation, All Rights Reserved.

RAID Volumes
None defined.

Physical Disks::
Port Device Model Serial # Size Type/Status(Vol ID)
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Non-RAID Disk
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Non-RAID Disk
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Non-RAID Disk
3 HDS722580VLSA80 VNRB3EC20579SL 76.7GB Non-RAID Disk

Press <CTRL-I> to enter Configuration Utility..

```


After the above message shows, press <Ctrl> and <I> keys simultaneously to enter the RAID Configuration Utility.



Important

The following procedure is only available with a newly-built system or if you are reinstalling your OS. It should not be used to migrate an existing system to RAID.

After pressing the <Ctrl> and <I> keys simultaneously, the following window will appear:




(1) Create RAID Volume

1. Select option 1 “Create RAID Volume” and press <Enter> key. The following screen appears. Then in the **Name** field, specify a RAID Volume name and then press the <TAB> or <Enter> key to go to the next field.
2. Use the arrow keys to select the RAID level best suited to your usage model in **RAID Level**.



- 3. In the **Disk** field, press <Enter> key and the following screen appears. Use <Space> key to select the disks you want to create for the RAID volume, then click <Enter> key to finish selection.



- 4. Then select the strip value for the RAID array by using the “upper arrow” or “down arrow” keys to scroll through the available values, and pressing the <Enter> key to select and advance to the next field. The available values range from 4KB to 128 KB in power of 2 increments. The strip value should be chosen based on the planned drive usage. Here are some typical values:
RAID0 – 128KB
RAID10 – 64KB
RAID5 – 64KB
- 5. Then select the capacity of the volume in the **Capacity** field. The default value is the maximum volume capacity of the selected disks.





Important

Since you want to create two volumes (Intel Matrix RAID Technology), this default size (maximum) needs to be reduced. Type in a new size for the first volume. As an example: if you want the first volume to span the first half of the two disks, re-type the size to be half of what is shown by default. The second volume, when created, will automatically span the remainder of two hard drives.

- Then the following screen appears for you to confirm if you are sure to create the RAID volume. Press <Y> to continue.

```

Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.

[ CREATE VOLUME MENU ]

Name: Volume0
RAID Level: RAID5(Parity)
Disks: Select Disks
Strip Size: 64KB
Capacity: 228.0 GB

WARNING: ALL DATA ON SELECTED DISKS WILL BE LOST.
Are you sure you want to create this volume? (Y/N):

Press ENTER to Create the specified volume.

[ ↑ ↓ ]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select
  
```

- Then the following screen appears to indicate that the creation is finished.

```

Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.

[ MAIN MENU ]

1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disk to Non RAID
4. Exit

[ DISK/VOLUME INFORMATION ]

RAID Volumes::
ID Name Level Strip Size Status Bootable
0 Volume0 RAID5(Parity) 64KB 228.0GB Normal Yes

Physical Disks::
Port Device Model Serial # Size Type/Status(Vol ID)
0 HDST722580VLSA80 VNRB3EC20549SL 76.7GB Member Disk(0)
1 HDST722580VLSA80 VNRB3EC20559SL 76.7GB Member Disk(0)
2 HDST722580VLSA80 VNRB3EC20569SL 76.7GB Member Disk(0)
3 HDST722580VLSA80 VNRB3EC20579SL 76.7GB Non-RAID Disk

[ ↑ ↓ ]Change [ESC]-Previous Menu [ENTER]-Select
  
```

(2) Delete RAID Volume


Here you can delete the RAID volume, but please be noted that all data on RAID drives will be lost.



Important

If your system currently boots to RAID and you delete the RAID volume in the Intel RAID Option ROM, your system will become unbootable.


Select option 2 **Delete RAID Volume** from the main menu window and press <Enter> key to select a RAID volume for deletion. Then press <Delete> key to delete the selected RAID volume. The following screen appears.



Press <Y> key to accept the volume deletion.

(3) Reset Disks to Non-RAID

Select option 3 **Reset Disks to Non-RAID** and press <Enter> to delete the RAID volume and remove any RAID structures from the drives. The following screen appears:



Press <Y> key to accept the selection.



Important

1. You will lose all data on the RAID drives and any internal RAID structures when you perform this operation.
2. Possible reasons to 'Reset Disks to Non-RAID' could include issues such as incompatible RAID configurations or a failed volume or failed disk.

Installing Driver

Install Driver in Windows Vista / XP / 2003

† New Windows Vista / XP / 2003 Installation

The following details the installation of the drivers while installing Windows XP / 2003.

1. When you start installing Windows XP and older operating systems, you may encounter a message stating, "Setup could not determine the type of one or more mass storage devices installed in your system". If this is the case, then you are already in the right place and are ready to supply the driver. If this is not the case, then press F6 when prompted at the beginning of Windows setup.
2. Press the "S" key to select "Specify Additional Device".
3. You should be prompted to insert a floppy disk containing the Intel® RAID driver into the A: drive.

Note: For Windows Vista you can use Floppy, CD/DVD or USB.



Important

Please follow the instruction below to make an "Intel® RAID Driver" for yourself.

1. Insert the MSI CD into the CD-ROM drive.
2. Click the "Browse CD" on the Setup screen.
3. Copy all the contents in `\\IDE\\Intel\\ICH9R\\Floppy` to a formatted floppy diskette.
4. The driver diskette for **Intel® ICH9R RAID Controller** is done.

4. For Windows Vista:
During the Operating system installation, after selecting the location to install Vista click on "Load Driver" button to install a third party SCSI or RAID driver.
5. When prompted, insert the floppy disk or media (Floppy, CD/DVD or USB) you created in step 3 and press Enter.
6. Select "Intel(R) ICH8R/ICH9R SATA RAID Controller" and press ENTER.
7. The next screen should confirm that you have selected the Intel® RAID controller. Press ENTER again to continue.
8. You have successfully installed the Intel® Matrix Storage Manager driver, and Windows setup should continue.
9. Leave the disk in the floppy drive until the system reboots itself. Windows setup will need to copy the files from the floppy again after the RAID volume is formatted, and Windows setup starts copying files.

† Existing Windows Vista/XP/2003 Driver Installation

1. Insert the MSI CD into the CD-ROM drive.
2. The CD will auto-run and the setup screen will appear.
3. Under the Driver tab, click on **Intel IAA RAID Edition**.
4. The drivers will be automatically installed.

† **Confirming Windows Vista/XP/2003 Driver Installation**


1. From Windows Vista/XP/2003, open the **Control Panel** from **My Computer** followed by the System icon.
2. Choose the **Hardware** tab, then click the **Device Manager** tab.
3. Click the "+" in front of the **SCSI and RAID Controllers** hardware type. The driver **Intel(R) ICH9R SATA RAID Controller** should appear.

Installing Software

Install Intel Matrix Storage Console

The Intel Application Accelerator RAID Edition driver may be used to operate the hard drive from which the system is booting or a hard drive that contains important data. For this reason, you cannot remove or un-install this driver from the system after installation; however, you will have the ability to un-install all other non-driver components.

Insert the MSI CD and click on the **Intel Matrix Storage Manager** to install the software.




Click on this item


The **InstallShield Wizard** will begin automatically for installation showed as following:




Click on the **Next** button to proceed the installation in the welcoming window.



The window shows the components to be installed. Click **Next** button to continue.



After reading the license agreement in the following window, click **Yes** button to continue.



RAID Migration Instructions

The Intel Matrix Storage Console offers the flexibility to upgrade from a single Serial ATA (SATA) hard drive to RAID configuration when an additional SATA hard drive is added to the system. This process will create a new RAID volume from an existing disk. However, several important steps must be followed at the time the system is first configured in order to take advantage of RAID when upgrading to a second SATA hard drive:

1. BIOS must be configured for RAID before installing Windows on the single SATA hard drive. Refer to **On-Chip ATA Devices** for properly setting of the BIOS.
2. Install the Intel Application Accelerator RAID Driver during Windows Setup. Refer to **Installing Software** for instructions on installing the driver during Windows Setup.
3. Install the Intel Matrix Storage Console after the operating system is installed.


To create a volume from an existing disk, complete the following steps:



Important

*A **Create from Existing Disk** operation will delete all existing data from the added disk and the data cannot be recovered. It is critical to backup all important data on the added disk before proceeding. However, during the migration process, the data on the source disk is preserved.*


After the Intel Matrix Storage Console has been successfully installed and the system has rebooted, click on the Intel Application Accelerator shortcut link (**Start --> All Programs --> Intel Matrix Storage Manager --> Intel Matrix Storage Console**) and the following window will appear:




Create RAID Volume from Existing Disk

To create a RAID volume from an existing disk, choose **Action --> Create RAID Volume from Existing Hard Drive**.

Note: The “Action” button only appears in advance mode. To enable the advance mode, go to **View --> Basic mode** and click it.



The **Create RAID Volume from Existing Hard Drive Wizard** pops up to lead you for the following procedure. Click **Next** to continue.



(1) Step 1: Configure Volume

Here you can configure the new RAID volume by entering the volume name, selecting the RAID level and strip size.



† **RAID Volume Name:**

A desired RAID volume name needs to be typed in where the 'RAID_Volume1' text currently appears above. The RAID volume name has a maximum limit of 16 characters. The RAID volume name must also be in English alphanumeric ASCII characters.

† **RAID Level:**

Select the desired RAID level:

- RAID 0 (Performance)** – A volume optimized for performance will allow you to access your data more quickly.
- RAID 1 (Redundancy)** – A volume optimized for data redundancy will provide you with a realtime duplicate copy of your data. Note: Only half of the available volume space will be available for data storage.
- RAID 5 (Useful)** – RAID 5 can be used on three or more disks, with zero or more spare-disks. The resulting RAID-5 device size will be (N-1)*S, where N is the how many drive, S is the size of the smallest drive in the array. If one of the disks fail, all data are still intact. It can rebuild the disk from the parity information. If spare disks are available, reconstruction will begin immediately after the device failure. If two disks fail simultaneously, all data are lost. RAID-5 can survive one disk failure, but not two or more. Both read and write performance usually increase, but can be hard to predict how much. Reads are similar to RAID-0 reads, writes can be either rather

expensive (requiring read-in prior to write, in order to be able to calculate the correct parity information), or similar to RAID-1 writes. The write efficiency depends heavily on the amount of memory in the machine, and the usage pattern of the array. Heavily scattered writes are bound to be more expensive.

RAID 10 (Mirrored Stripes) – A RAID 1 array of two RAID 0 arrays.

† **Strip Sizes:**

Select the desired strip size setting. As indicated, the optimal setting is 128KB. Selecting any other option may result in performance degradation. Even though 128KB is the recommended setting for most users, you should choose the strip size value which is best suited to your specific RAID usage model. The most typical strip size settings are:

4KB: For specialized usage models requiring 4KB strips

8KB: For specialized usage models requiring 8KB strips

16KB: Best for sequential transfers

32KB: Good for sequential transfers

64KB: Good general purpose strip size


128KB: Best performance for most desktops and workstations

(2) Select the source disk

Then select the source disk that you wish to use and then click “--->” to move it to the **Selected** field. Then click **Next** to continue.

It is very important to note which disk is the source disk (the one containing all of the information to be migrated) and which one is the target disk. On a RAID Ready system, this can be determined by making a note during POST of which port the single disk is attached to.



You can also use the Intel Application Accelerator RAID Edition utility before the second disk is installed to verify the Port and serial number of the drive that contains all the data.



(3) Select Member Hard Drive(s)


Then select the member disk (the target disk) that you wish to use and then click “-->” to move it to the **Selected** field. Then click **Next** to continue.

Please note that the existing data on the selected hard drive(s) will be deleted permanently. Do not forget to back up all the important data before continuing.




(4) Specify Volume Size

Specify the amount of available array space to be used by the new RAID volume. You may enter the amount in the space or use the slider to specify. It is recommended you use 100% of the available space for the optimized usage. For RAID 0 volume, if you do not specify 100% of the hard drive space, the rest hard drive space will be worked as RAID 1 volume, which is the new technology called Intel Matrix RAID. Then click **Next** to continue.



(5) Start Creating RAID Volume from Existing Hard Drive Wizard

Before you continue the procedure of RAID volume creation from existing hard drive, read the dialogue box below carefully. Please note that once you click **Finish**, the existing data on the selected hard drive(s) will be deleted permanently and this operation cannot be undone. It is critical that you backup all important data before selecting **Finish** to start the migration process.



(6) Start Migration

The migration process may take up to two hours to complete depending on the size of the disks being used and the strip size selected. A dialogue window will appear stating that the migration process may take considerable time to complete, meanwhile a popup dialogue at the taskbar will also show the migration status. While you can still continue using your computer during the migration process, once the migration process starts, it cannot be stopped. If the migration process gets interrupted and your system is rebooted for any reason, it will pick up the migration process where it left off. You will be provided with an estimated completion time (the remaining time will depend on your system) once the migration process starts.



The following screen appears if the migration process is completed successfully. Then you have to reboot your system to use the full capacity of the new volume.



Degraded RAID Array

A RAID 1, RAID 5 or RAID 10 volume is reported as degraded when one of its hard drive members fails or is temporarily disconnected, and data mirroring is lost. As a result, the system can only utilize the remaining functional hard drive member. To re-establish data mirroring and restore data redundancy, refer to the procedure below that corresponds to the current situation.

Missing Hard Drive Member

1. Make sure the system is powered off.
2. Reconnect the hard drive.
3. Reboot the system to Windows; the rebuild will occur automatically.

Failed Hard Drive Member

1. Make sure the system is powered off.
2. Replace the failed hard drive with a new one that is of equal or greater capacity.
3. Reboot the system to Intel RAID Option ROM by press <Ctrl> and <I> keys simultaneously during the Power-On Self Test (POST).

```

Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-06 Intel Corporation, All Rights Reserved.

RAID Volumes
ID Name Level Strip Size Status Bootable
0 Volume0 RAID10(RAID0+1) 64KB 153.4GB Degraded Yes

Physical Disks::
Port Device Model Serial # Size Type/Status(Vol ID)
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Member Disk (0)
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Member Disk (0)
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Member Disk (0)
3 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Non-RAID Disk

Press <CTRL+I> to enter Configuration Utility..
  
```

4. Select the port of the destination disk for rebuilding, and then press ENTER.

```

Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-06 Intel Corporation, All Rights Reserved.

[ MAIN MENU ]
[ DEGRADED VOLUME DETECTED ]

Degraded volume and disk available for rebuilding detected. Selecting
a disk initiates a rebuild. Rebuild completes in the operating system.

Select the port of the destination disk for rebuilding [ESC] to exit:


Port Drive Model Serial # Size
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB
3 HDS722580VLSA80 VNRB3EC20578SL 76.7GB

[↑↓] Previous/Next [ENTER] Select [ESC] Exit

Port Device Model Serial # Size Type/Status(Vol ID)
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Member Disk (0)
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Member Disk (0)
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Member Disk (0)
3 HDS722580VLSA80 VNRB3EC20578SL 76.7GB Non-RAID Disk

[↑↓] Change [ESC] Previous Menu [ENTER] Select
  
```

- 5. Exit Intel RAID Option ROM, and then reboot to Windows system.
- 6. When prompted to rebuild the RAID volume, click 'Yes'.
- 7. The Intel(R) Storage Utility will be launched. Right-click the new hard drive and select 'Rebuild to this Disk'. The 'Rebuild Wizard' will be launched which will guide you through the process of rebuilding to the new hard drive.



Appendix B

LSI SAS RAID

This appendix explains how to configure and use the components of the LSI Logic Integrated RAID (IR) software with LSI SAS 1064/1064E & 1068/1068E controllers.

1. Introduction to Integrated RAID

This section provides an overview of the LSI Logic Integrated RAID solution for LSI Logic SAS controllers, its features, and its benefits.

The LSI Logic Integrated RAID solution provides cost benefits for the server or workstation market where the extra performance, storage capacity, and/or redundancy of a RAID configuration are required. The two components of Integrated RAID are:

- ▶ **Integrated Mirroring (IM)**, which provides features of RAID 1 and RAID 1E (RAID 1 Enhanced). RAID 1E is also called *Integrated Mirroring Enhanced (IME)*
- ▶ **Integrated Striping (IS)**, which provides features of RAID 0

By simplifying the IM and IS configuration options and by providing firmware support in its host adapters, LSI Logic can offer the Integrated RAID solution at a lower cost than a hardware RAID implementation.

Fusion-MPT™ firmware supports IM and IS volumes. You can configure IM and IS volumes together on the same LSI Logic SAS controller.

Integrated RAID Benefits and Features

- ▶ Low cost RAID volume creation meets the needs of most internal RAID installations
- ▶ Easy to use - installation and configuration are not complex
- ▶ System can boot from an IM, IME, or IS volume
- ▶ No special OS-specific software required
- ▶ High reliability and data integrity
 - Non-volatile write journaling
 - Physical disks not visible to OS or to application software
- ▶ Low host CPU and PCI bus utilization
- ▶ Fusion-MPT architecture provides processing power
 - Shared memory architecture minimizes external memory requests
 - Functionality is contained in device hardware and firmware

2. Integrated Mirroring Overview

This section provides an overview of the LSI Logic Integrated Mirroring (IM) feature.

2.1 Introduction

As a result of the shift towards Network Attached Storage (NAS), ISPs need a cost effective, fault-tolerant solution to protect the operating systems on small form factor, high-density, rack-mountable servers. The LSI Logic Integrated Mirroring (IM) feature—which includes Integrated Mirroring Enhanced (IME)—provide data protection for the system boot volume to safeguard critical information such as the operating system on servers and high performance workstations. The Integrated Mirroring feature gives customers a robust, high-performance, fault-tolerant solution to their storage needs, at a lower cost than a dedicated RAID controller.

The Integrated Mirroring feature supports simultaneous mirrored volumes with two disks (IM) or three to eight disks (IME), to provide fault-tolerant protection for critical data. (If a hot spare disk is used, the maximum volume size is seven mirrored disks, plus the hot spare disk.) Up to two IM volumes are supported per SAS controller, with up to ten drives total per controller.

- ✓ **Note:** Ten disk drives is the theoretical upper limit, although the SAS controller itself may support fewer drives.

If a disk in an Integrated Mirroring volume fails, the hot swap capability allows the volume to be easily restored by simply swapping disks. The firmware then automatically re-mirrors the swapped disk. Additionally, each SAS controller can have one global hot spare disk available to automatically replace a failed disk in the one or two IM or IME volumes configured on the controller. The hot spare makes the Integrated Mirroring volume even more fault-tolerant.

- ✓ **Note:** You can configure an Integrated Mirroring volume and an Integrated Striping volume on the same LSI Logic SAS controller.

The IM feature uses the same device drivers as the standard LSI Logic Fusion-MPT based controllers, providing seamless and transparent fault tolerance. This eliminates the need for complex backup software or expensive RAID hardware. The IM feature operates independently from the operating system, in order to conserve system resources. The BIOSbased configuration utility makes it easy to configure IM and IME volumes.

The Integrated Mirroring feature is currently available as an optional component of the Fusion-MPT architecture on LSI Logic controller products.

2.2 IM Features

LSI Logic Integrated Mirroring and Integrated Mirroring Enhanced support the following features:


- ▶ Configurations of one or two IM or IME volumes on the same LSI Logic SAS controller. Each volume can consist of two mirrored disks (IM) or three to eight mirrored disks (IME).
- ▶ (Optional) One global hot spare disk per controller. If a global hot spare disk is defined, the upper limit for an IME volume is seven mirrored disks.
- ▶ Mirrored volumes run in optimal mode or in degraded mode (if one mirrored disk fails)
- ▶ Hot swap capability
- ▶ Presents a single virtual drive to the OS for each IM/IME volume
- ▶ Supports both SAS and SATA disks, although the two types of disks cannot be combined on the same LSI Logic SAS controller
- ▶ Fusion-MPT architecture
- ▶ Easy-to-use BIOS-based configuration utility (and DOS-based configuration utility for manufacturing use only)
- ▶ Error notification: OS-specific event log updated by drivers and errors displayed inside the Fusion-MPT BIOS
- ▶ SES status LED support for Integrated Mirroring disks
- ▶ Write journaling, which allows automatic synchronization of potentially inconsistent data after unexpected power-down situations
- ▶ Metadata used to store volume configuration on mirrored disks
- ▶ Automatic background resynchronization while host I/Os continue
- ▶ Background media verification ensures that data on the IM volume is accessible

2.3 IM/IME Description

The LSI Logic Integrated Mirroring (IM) feature supports one or two mirrored volumes on each LSI Logic SAS controller (or one mirrored volume and one Integrated Striping volume). Typically, one of these volumes is the boot volume, as shown in Figure 2.1. This is accomplished through the firmware of the LSI Logic SAS controller that supports the standard Fusion-MPT interface. The runtime mirroring of the boot disk is transparent to the BIOS, drivers, and operating system.


Host-based status software monitors the state of the mirrored disks and reports any error conditions. In Figure 2.1 the system is configured with a second disk as a mirror of the first (primary) disk.

Figure 2.1 Typical Integrated Mirroring Implementation




The advantage of Integrated Mirroring (RAID 1), is that there is always a mirrored copy of the data. The disadvantage is that writes take longer because data must be written twice. On the other hand, performance is actually improved during reads. Figure 2.2 shows the logical view and physical view of an Integrated Mirroring configuration with two disks in the mirrored volume.

Figure 2.2 Integrated Mirroring with Two Disks



An IME volume can be configured with up to eight mirrored disks, or seven mirrored disks and a global hot spare. Figure 2.3 shows the logical view and physical view of an Integrated Mirroring Enhanced (IME) volume with three mirrored disks. Each *mirrored stripe* is written to a disk and mirrored to an adjacent disk. This type of configuration is also called RAID 1E.

Figure 2.3 Integrated Mirroring with More than Two Disks (IME)



LSI Logic provides the BIOS-based configuration utility to enable the user to create IM and IME volumes during initial setup and to reconfigure them in response to hardware failures or changes in the environment.

2.4 Integrated Mirroring Firmware

This section describes features of the LSI Logic Integrated Mirroring (IM) firmware, which supports up to two IM volumes per LSI Logic SAS controller.

2.4.1 Host Interface

The IM host interface uses the Message Passing Interface, as described in the *Fusion-MPT Message Passing Interface Specification*. Through the Fusion-MPT interface, the host OS has access to the IM volume as well as the physical disks.

2.4.2 Resynchronization with Concurrent Host I/O Operation

The IM firmware allows Host I/Os to continue on the IM/IME volume while the volume is being re-synchronized in the background. Resynchronization is attempted after a hot spare is activated due to a physical device failure, or after a hot swap has occurred to a physical disk in the IM or IME volume.

2.4.3 Metadata Support

The firmware supports metadata, which describes the IM/IME logical drive configuration stored on each member disk. When the firmware is initialized, each member disk is queried to read the stored metadata in order to verify the configuration. The usable disk space for each member disk is adjusted down to leave room for this data.

2.4.4 Hot Swapping

The IM firmware supports *hot swapping*. The hot-swapped disk is automatically resynchronized in the background, without any host or user intervention. The firmware detects hot swap removal and disk insertion.

Following a hot swap event, the firmware readies the new physical disk by spinning it up and verifying that it has enough capacity for the mirrored volume. The IM firmware resynchronizes all hot-swapped disks that have been removed, even if the same disk is re-inserted. In a two-disk mirrored volume, the IM firmware marks the hot-swapped disk as the secondary disk and marks the other mirrored disk as the primary disk. The firmware resynchronizes all data from the primary disk onto the new secondary disk.

2.4.5 SMART Support

The IM firmware enables Mode 6 SMART on the member disks in the mirrored volume. Mode 6 SMART requires each physical disk to be polled at regular intervals. If a SMART ASC/ASCQ code is detected on a physical disk in the volume, the firmware processes the SMART data, and the last received SMART ASC/ASCQ is stored in non-volatile memory. The IM/IME volume does not support SMART directly, since it is just a logical representation of the physical disks in the volume.

2.4.6 Hot Spare Disk

One disk can be configured as a *global hot spare* disk, which protects data on the one or two volumes configured on the controller. If the IM firmware fails one of the mirrored disks, the firmware automatically replaces it with the hot spare

disk. The IM firmware then resynchronizes the mirrored data. The IM firmware is automatically notified when the failed disk has been replaced, and the firmware then designates that disk as the new hot spare.

2.4.7 Media Verification

The IM firmware supports a background *media verification feature* that runs at regular intervals when the IM/IME volume is in optimal mode. If the verification command fails for any reason, the other disk's data for this segment is read and written to the failing disk in an attempt to refresh the data. The current Media Verification Logical Block Address is written to non-volatile memory occasionally to allow Media Verification to continue approximately where it left off prior to a power-cycle.

2.4.8 Disk Write Caching

The IM firmware disables disk write caching by default. This is done to increase data integrity, so that the disk write log stored in NVSRAM is always valid. If disk write caching were enabled (not recommended), the disk write log could be invalid.

2.4.9 NVSRAM Usage

For the LSISAS1064/1064E and LSISAS1068/1068E controllers, the IM firmware requires at least a 32K NVSRAM in order to perform write journaling. Write journaling is used to verify that the mirrored disks in the IM/IME volume are synchronized with each other.

2.5 Fusion-MPT Support

The BIOS uses the LSI Logic Fusion-MPT interface to communicate to the SAS controller and firmware to enable Integrated Mirroring. This includes reading the Fusion-MPT configuration to gain access to the parameters that are used to define behavior between the SAS controller and the devices connected to it. The Fusion-MPT drivers for all supported operating systems implement the Fusion-MPT interface to communicate with the controller and firmware.

3. Creating Integrated Mirroring Volumes

This section describes how to create Integrated Mirroring (IM) and Integrated Mirroring Enhanced (IME) volumes using the LSI Logic SAS BIOS Configuration Utility (SAS BIOS CU).

3.1 IM Configuration Overview

You can use the SAS BIOS CU to create one or two IM or IME volumes on each LSI Logic SAS controller, with an optional global hot spare disk. All disks in an IM or IME volume must be connected to the same LSI Logic SAS controller.

Although you can use disks of different size in IM and IME volumes, the smallest disk determines the "logical" size of each disk in the volume. In other words, the excess space of the larger member disk is not used.

Refer to Section 2.2, "IM Features," for more information about Integrated Mirroring volumes.

3.2 Creating IM and IME Volumes

The SAS BIOS CU is part of the Fusion-MPT BIOS. When the BIOS loads during boot and you see the message about the LSI Logic Configuration Utility, press **Ctrl-C** to start the CU. After you do this, the message changes to:

Please wait, invoking SAS Configuration Utility...

After a brief pause, the main menu of the SAS BIOS CU appears. On some systems, however, the following message appears next:

LSI Logic Configuration Utility will load following initialization!

In this case, the SAS BIOS CU will load after the system has completed its power-on self test.

You can configure one or two IM or IME volumes per Fusion-MPT controller. You can also combine IM, IME, and Integrated Striping volumes on the same controller, up to a maximum of 10 physical disk drives.

The following guidelines also apply when creating an IM or IME volume:

- ▶ All physical disks in the volumes must be either SATA (with extended command set support) or SAS (with SMART support). SAS and SATA disks *cannot* be combined in the same volume.
- ▶ Disks must have 512-byte blocks and must not have removable media.
- ▶ An IM volume must have two drives, plus an optional global hot spare. An IME volume. An IME volume can have three to eight drives, or three to seven drives if you also create a global hot spare.

✓ Note: If a disk in an IM or IME volume fails, it is rebuilt on the global hot spare if one

is available. So adding a global hot spare greatly increases the level of data protection. (One global hot spare is allowed for the one or two volumes configured on a controller.)

3.2.1 Creating an IM Volume

Follow these steps to create an IM volume with the SAS BIOS CU:

1. On the Adapter List screen, use the arrow keys to select an LSI Logic SAS adapter.
2. Press **Enter** to go to the Adapter Properties screen, shown in Figure 3.1.

Figure 3.1 Adapter Properties Screen

```

LSI Logic MPT Setup Utility   v6.01.03.00
Adapter Properties -- SAS1068

Adapter                      SAS1068
PCI Slot                     03
PCI Address(Bus/Dev/Func)    03:00:00
MPT Firmware Revision        00.03.23.00-IT
SAS Address                   500605B0:0000C580
Status                       Enabled
Boot Order                   1
Boot Support                  [Enabled BIOS & OS]

RAID Properties

SAS Topology

Advanced Adapter Properties

Esc = Exit Menu             F1/Shift+1 = Help
Enter = Select Item         -/+ = Change Item

```

3. On the Adapter Properties screen, use the arrow keys to select **RAID Properties** on the screen and press **Enter**.
4. When you are prompted to select a volume type, select **Create IM Volume**. The Create New Array screen shows a list of disks that can be added to a volume.
5. Move the cursor to the "RAID Disk" column and select a disk. To add the disk to the volume, change the "No" to "Yes" by pressing the + key, . key, or space bar. When the first disk is added, the SAS BIOS CU prompts you to either keep existing data or overwrite existing data.
6. Press **M** to keep the existing data on the first disk or press **D** to overwrite it. If you keep the existing data, this is called a *migration*. The first disk will be mirrored onto the second disk, so the data you want to keep *must* be on the first disk added to the volume. Any data on the second disk is overwritten. As disks are added the Array Size field changes to reflect the size of the new volume.
7. (optional) Add a global hot spare by moving the cursor to the hot spare column and pressing the + key, . key, or space bar.

Figure 3.2 shows an IM volume configured with a global hot spare disk.

Figure 3.2 Create New Array Screen

```

LSI Logic MPT Setup Utility   v6.01.03.00
Create New Array -- SAS1068

  Array Type:                  IM
  Array Size (MB)              34332

Slot  Device Identifier          RAID  Hot  Drive  Pred  Size
Num   Num                        [Yes] [No]  Spr  Status  Fail  (MB)
  1    1  MAXTOR ATLAS15K2_36SAS BG34  [Yes] [No]  Primary --- 35074
  2    2  MAXTOR ATLAS15K2_36SAS BG34  [Yes] [No]  Secondary --- 35074
  8    8  MAXTOR ATLAS15K2_36SAS BG34  [No]  [Yes] Hot Spare --- 35074
 11   11  MAXTOR ATLAS15K2_36SAS BG34  [No]  [No]  Max Dsks --- 35074

Esc = Exit Menu      F1/Shift+1 = Help
Space/+/- = Select disk for array or hot spare  C = Create array

```

- When the volume has been fully configured, press **C** and then select **Save changes then exit this menu** to commit the changes. The SAS BIOS CU pauses while the array is being created.

3.2.2 Creating an IME Volume

Follow these steps to create an IME volume with the SAS BIOS CU:

- On the Adapter List screen, use the arrow keys to select an LSI Logic SAS adapter.
- Press **Enter** to go to the Adapter Properties screen, shown in Figure 3.1.
- On the Adapter Properties screen, use the arrow keys to select **RAID Properties** on the screen and press **Enter**.
- When you are prompted to select a volume type, select **Create IME Volume**. The Create New Array screen shows a list of disks that can be added to a volume.
- Move the cursor to the "RAID Disk" column and select a disk. To add the disk to the volume, change the "No" to "Yes" by pressing the + key, . key, or space bar.
- Repeat this step to select a total of three to eight disks for the volume (or three to seven disks if you will create a global hot spare). All existing data on all the disks you select will be overwritten. As you add disks, the Array Size field changes to reflect the size of the new volume.
- (optional) Add a global hot spare to the volume by moving the cursor to the hot spare column and pressing the + key, . key, or space bar.
- When the volume has been fully configured, press **C** and then select **Save changes then exit this menu** to commit the changes. The SAS BIOS CU pauses while the array is being created.

3.3 Creating a Second IM or IME Volume

The LSI Logic SAS controllers allow you to configure two IM or IME volumes. If one volume is already configured, and if there are available disk drives, there are two ways to add a second volume.

The first is as follows:

1. In the configuration utility, select an adapter from the Adapter List. Select the **RAID Properties** option. This will display the current volume.
2. Press **C** to create a new volume.
3. Continue with step 4 of the IM or IME creation procedure in the previous section to create a second volume.

The other way in which to add a second volume is as follows:

1. On the Adapter List screen, use the arrow keys to select an LSI Logic SAS adapter.
2. Press **Enter** to go to the Adapter Properties screen, shown in Figure 3.1.
3. On the Adapter Properties screen, use the arrow keys to select **RAID Properties** and press **Enter**.
4. Continue with step 4 of the IM or IME creation procedure in the previous section to create a second volume.

3.4 Managing Hot Spares

You can create one global hot spare disk to protect the one or two IM/IME volumes defined on a SAS controller. Usually, you create the global hot spare at the same time you create the IM/IME volume. Follow these steps to add a global hot spare disk later for the existing IM/IME volumes on the controller:

1. On the View Array screen, select **Manage Array**.
2. Select **Manage Hot Spare** on the Manage Array screen, shown in Figure 3.3.

Figure 3.3 Manage Array Screen

```

LSI Logic MPT Setup Utility   v6.01.03.00
Manage Array -- SAS1068

Identifier                    LSILOGICLogical Volume 3000
Type                          IM
Scan Order                    1
Size (MB)                    34332
Status                        Optimal

Manage Hot Spare

Synchronize Array

Activate Array

Delete Array

Esc = Exit Menu             F1/Shift+1 = Help
Enter = Choose array type to create   Esc = Return to Adapter Properties

```

3. Select a disk from the list by pressing the + key, . key, or space bar.
4. After you select the global hot spare disk, press **C**. An error message appears if the selected disk is not at least as large as the smallest disk used in the IM/IME volume(s). The global hot spare disk must have 512-byte blocks, it cannot have removable media, and the disk type must be either SATA with extended command set support or SAS with SMART support. If SATA disks are used for the IM/IME volume(s), the hot spare disk must also be a SATA disk. If SAS disks are used, the hot spare disk must also be a SAS disk. An error message appears if the selected disk is not the same type as the disks used in the IM/IME volumes.
5. Select **Save changes then exit this menu** to commit the changes. The configuration utility will pause while the global hot spare is being added.

Follow these steps to delete a global hot spare:

1. Select **Manage Hot Spare** on the Manage Array screen.
2. Select **Delete Hot Spare** and then press **C**.
3. Select **Save changes then exit this menu** to commit the changes. The configuration utility will pause while the global hot spare is being removed.

3.5 Other Configuration Tasks

This section explains how to do other tasks related to configuring and maintaining IM and IME volumes.

3.5.1 Viewing Volume Properties

Follow these steps to view the properties of volumes:

1. In the SAS BIOS CU, select an adapter from the Adapter List. Select the **RAID Properties** option. The properties of the current volume are displayed. If a global hot spare is defined, it is also listed.
- ✓ **Note:** If you create one volume using SAS disks, another volume using SATA disks, and a global hot spare disk, the hot spare disk will only appear when you view the volume that has the same type of disks as the hot spare disk.
2. If two volumes are configured, press **Alt+N** to view the other array.
 3. To manage the current array, select the **Manage Array** item and press **Enter**.

3.5.2 Synchronizing an Array

The Synchronize Array command forces the firmware to resynchronize the data on the mirrored disks in the array. It is seldom necessary to use this command, because the firmware automatically keeps the mirrored data synchronized during normal system operation. When you use this command, one disk of the array is placed in the *Degraded* state until the data on the mirrored disks has been resynchronized.

Follow these steps to force the synchronization of a selected array:

1. Select **Synchronize Array** on the Manage Array screen.
2. Press **Y** to start the synchronization, or **N** to cancel it.

3.5.3 Activating an Array

An array can become inactive if, for example, it is removed from one controller or computer and moved to another one. The “Activate Array” option allows you to reactivate an inactive array that has been added to a system. This option is only available when the selected array is currently inactive.

Follow these steps to activate a selected array

1. Select **Activate Array** on the Manage Array screen.
 2. Press **Y** to proceed with the activation, or press **N** to abandon it. After a pause, the array will become active.
- ✓ **Note:** If there is a global hot spare disk on the controller to which you have moved the array, the firmware checks when you activate the array to determine if the hot spare is compatible with the new array. An error message appears if the disks in the activated array are larger than the hot spare disk or if the disks in the activated array are not the same type as the hot spare disk (SATA versus SAS).

3.5.4 Deleting an Array

✓ **CAUTION:** Before deleting an array, be sure to back up all data on the array that you want to keep.

Follow these steps to delete a selected array:

1. Select **Delete Array** on the Manage Array screen.
 2. Press **Y** to delete the array.
After a pause, the firmware deletes the array. If there is another remaining array and a global hot spare disk, the firmware checks the hot spare disk to determine if it is compatible with the remaining array. If the hot spare disk is not compatible (too small or wrong disk type) the firmware deletes it also.
- ✓ **Note:** After a volume has been deleted, it cannot be recovered. When a RAID 1 volume is deleted, the data is preserved on the primary disk. The master boot records (MBR) of other disks in the array are deleted. For other RAID types, the master boot records of all disks are deleted.

3.5.5 Locating a Disk Drive, or Multiple Disk Drives in a Volume

You can use the SAS BIOS CU to locate and identify a specific physical disk drive by flashing the drive's LED. You can also use the SAS BIOS CU to flash the LEDs of all the disk drives in a RAID volume. There are several ways to do this:

- ▶ When you are creating an IM or IME volume, and a disk drive is set to **Yes** as part of the volume, the LED on the disk drive is flashing. The LED is turned off when you have finished creating the volume.
 - ▶ You can locate individual disk drives from the SAS Topology screen. To do this, move the cursor to the name of the disk in the Device Identifier column and press **Enter**. The LED on the disk flashes until the next key is pressed.
 - ▶ You can locate all the disk drives in a volume by selecting the volume on the RAID Properties screen. The LEDs flash on all disk drives in the volume.
- ✓ **Note:** The LEDs on the disk drives will flash as described above if the firmware is correctly configured and the drives or the disk enclosure supports disk location.

3.5.6 Selecting a Boot Disk

You can select a boot disk in the SAS Topology screen. This disk is then moved to scan ID 0 on the next boot, and remains at this position. This makes it easier to set BIOS boot device options and to keep the boot device constant during device additions and removals. There can be only one boot disk.

Follow these steps to select a boot disk:

1. In the SAS BIOS CU, select an adapter from the Adapter List.
 2. Select the **SAS Topology** option.
The current topology is displayed. If the selection of a boot device is supported, the bottom of the screen lists the Alt+B option. This is the key for toggling the boot device. If a device is currently configured as the boot device, the Device Info column on the SAS Topology screen will show the word "Boot."
 3. To select a boot disk, move the cursor to the disk and press **Alt+B**.
 4. To remove the boot designator, move the cursor down to the current boot disk and press **Alt+B**. This controller will no longer have a disk designated as boot.
 5. To change the boot disk, move the cursor to the new boot disk and press **Alt+B**. The boot designator will move to this disk.
- ✓ **Note:** The firmware must be configured correctly in order for the Alt+B feature to work.

4. Integrated Striping Overview

This section provides an overview of the LSI Logic Integrated Striping (IS) feature.

4.1 Introduction

The LSI Logic Integrated Striping (IS) feature is useful for applications that require the faster performance and increased storage capacity of striping. The low-cost IS feature has many of the advantages of a more expensive RAID striping solution. A single IS logical drive may be configured as the boot disk or as a data disk.

The IS feature is implemented with controller firmware that supports the Fusion-MPT Interface. IS provides better performance and more capacity than individual disks, without burdening the host CPU. The firmware splits host I/Os over multiple disks and presents the disks as a single logical drive. In general, striping is transparent to the BIOS, the drivers, and the operating system.

The SAS BIOS CU is used to configure IS volumes, which can consist of two to eight disks.

- ✓ Note: Integrated Mirroring and Integrated Striping volumes can be configured on the same LSI logic SAS controller.

4.2 IS Features

Integrated Striping supports the following features:

- ▶ Support for volumes with two to eight drives
- ▶ Support for two IS volumes, with up to 10 drives total, on a controller. An IS volume can also be combined with an IM or IME volume.
- ✓ Note: Currently available LSI Logic SAS controllers support a maximum of eight drives. All drives in a volume must be connected to the same SAS controller.
- ▶ Presents a single virtual drive to the OS for each configured volume
- ▶ Support for both SAS and SATA drives, although the two types of drives cannot be combined in one volume
- ▶ Fusion-MPT architecture
- ▶ Easy-to-use SAS BIOS configuration utility
- ▶ Error notification
- ▶ Use of metadata to store volume configuration on disks
- ▶ OS-specific event log
- ▶ Error display inside the Fusion-MPT BIOS
- ▶ SES status LED support for drives used in IS volumes

4.3 IS Description

The IS feature writes data across multiple disks instead of onto one disk. This is accomplished by partitioning each disk's storage space into 64 Kbyte stripes. These stripes are interleaved round-robin, so that the combined storage space is composed alternately of stripes from each disk.

For example, as shown in Figure 4.1, segment 1 is written to disk 1, segment 2 is written to disk 2, segment 3 is written to disk 3, and so on. When the system reaches the end of the disk list, it continues writing data at the next available segment of disk 1.

Figure 4.1 Integrated Striping Example





Figure 4.2 shows a logical view and a physical view of Integrated Striping configuration.

Figure 4.2 Integrated Striping - Logical and Physical Views



The primary advantage of IS is speed, because it transfers data to or from multiple disks at once. However, there is no data redundancy; therefore, if one disk fails, that data is lost.

4.4 Integrated Striping Firmware

This section describes features of the LSI Logic Integrated Striping (IS) firmware.

4.4.1 Host Interface

The IS host interface uses the Message Passing Interface, as described in the *Fusion-MPT Message Passing Interface Specification*, including Integrated Striping. Through the Fusion-MPT interface, the host operating system has access to the logical IS drive as well as the physical disks.

4.4.2 Metadata Support

The firmware supports metadata, which describes the IS logical drive configuration stored on each member disk. When the firmware is initialized, each member disk is queried to read the stored metadata to verify the configuration. The usable disk space for each IS member disk is adjusted down to leave room for this data.

4.4.3 SMART Support

The IS firmware enables Mode 6 SMART on the IS member disks. Mode 6 SMART requires each physical disk to be polled at regular intervals. If a SMART ASC/ASCQ code is detected on a physical IS disk, the firmware processes the SMART data, and the last received SMART ASC/ASCQ is stored in non-volatile memory. The IS volume does not support SMART directly, since it is just a logical representation of the physical disks in the volume.

4.4.4 Disk Write Caching

Disk write caching is disabled by default on all IS volumes.

4.5 Fusion-MPT Support

The BIOS uses the LSI Logic Fusion-MPT interface to communicate to the SAS controller and firmware to enable Integrated Striping. This includes reading the Fusion-MPT configuration to gain access to the parameters that are used to define behavior between the SAS controller and the devices connected to it. The Fusion-MPT drivers for all supported operating systems implement the Fusion-MPT interface to communicate with the controller and firmware.

5. Creating Integrated Striping Volumes

This section describes how to create Integrated Striping (IS) volumes using the LSI Logic SAS BIOS Configuration Utility (SAS BIOS CU).

5.1 IS Configuration Overview

You can use the SAS BIOS CU to create multiple IS volumes, with up to 10 drives total on an LSI Logic SAS controller. Each volume can have from 2 to 8 drives. Disks in an IS volume must be connected to the same LSI Logic SAS controller, and the controller must be in the BIOS boot order.

Although you can use disks of different size in IS volumes, the smallest disk determines the "logical" size of each disk in the volume. In other words, the excess space of the larger member disk is not used. Usable disk space for each disk in an IS volume is adjusted down to leave room for metadata. Usable disk space may be further reduced to maximize the ability to interchange disks in the same size classification. The supported stripe size is 64 Kbytes.

Refer to Section 4.2, "IS Features," for more information about Integrated Striping volumes.

5.2 Creating IS Volumes

The SAS BIOS CU is part of the Fusion-MPT BIOS. When the BIOS loads during boot and you see the message about the Setup Utility, press **Ctrl-C** to start it. After you do this, the message changes to:

Please wait, invoking SAS Configuration Utility...

After a brief pause, the main menu of the SAS BIOS CU appears. On some systems, however, the following message appears next:

LSI Logic Configuration Utility will load following initialization!

In this case, the SAS BIOS CU will load after the system has completed its power-on self test.

Follow the steps below to configure an Integrated Striping (IS) volume with the SAS BIOS CU. The procedure assumes that the required controller(s) and disks are already installed in the computer system. You can configure both IM and IS volumes on the same SAS controller.

1. On the Adapter List screen of the SAS BIOS CU, use the arrow keys to select a SAS adapter.

2. Press **Enter** to go to the Adapter Properties screen, shown in Figure 5.1.

Figure 5.1 Adapter Properties Screen

```
LSI Logic MPT Setup Utility   v6.01.03.00
Adapter Properties -- SAS1068

Adapter                      SAS1068
PCI Slot                     03
PCI Address (Bus/Dev/Func)   03:00:00
MPT Firmware Revision        00.03.23.00-IT
SAS Address                   500605B0:0000C580
Status                        Enabled
Boot Order                    1
Boot Support                  [Enabled BIOS & OS]

RAID Properties

SAS Topology

Advanced Adapter Properties

Esc = Exit Menu             F1/Shift+1 = Help
Enter = Select Item         -/+ = Change Item
```

3. On the Adapter Properties screen, use the arrow keys to select **RAID Properties** on the screen and press **Enter**.
4. When you are prompted to select a volume type, select **Create IS Volume**. The Create New Array screen shows a list of disks that can be added to a volume.
5. Move the cursor to the "RAID Disk" column. To add a disk to the volume, change the "No" to "Yes" by pressing the + key, . key, or space bar. As disks are added, the Array Size field changes to reflect the size of the new volume.

There are several limitations when creating an IS (RAID 0) volume:

- All disks must be either SATA (with extended command set support) or SAS (with SMART support).
- Disks must have 512-byte blocks and must not have removable media.
- There must be at least 2 and no more than 8 drives in a valid IS volume. Hot spare drives are not allowed.

Figure 5.2 shows an IS volume configured with two drives.

Figure 5.2 Create New Array Screen

```

LSI Logic MPT Setup Utility      v6.01.03.00
Create New Array -- SAS1068

  Array Type:                      IS
  Array Size(MB)                   70032

Slot  Device Identifier            RAID  Hot   Drive   Pred   Size
Num                                     Disk  Spr   Status Fail   (MB)
  1  MAXTOR ATLAS15K2_36SAS BG34   [Yes] [No]  Ok     ---   35074
  2  MAXTOR ATLAS15K2_36SAS BG34   [Yes] [No]  Ok     ---   35074
  8  MAXTOR ATLAS15K2_36SAS BG34   [No]  [No]  Ok     ---   35074
 11  MAXTOR ATLAS15K2_36SAS BG34   [No]  [No]  Ok     ---   35074

Esc = Exit Menu      Fl/Shift+1 = Help
Space/+/- = Select disk for array or hot spare      C = Create array
    
```

6. When the volume has been fully configured, press **C** and then select **Save changes then exit this menu** to commit the changes. The configuration utility will pause while the array is being created.

✓ Note: Integrated Striping does not provide any data protection in the event of disk failure. It is primarily used to increase speed.

5.3 Creating a Second IS Volume

The LSI Logic SAS controllers allow you to configure two IS volumes, or an IS volume and an IM or IME volume. If one volume is already configured, and if there are available disk drives, there are two ways to add a second volume.

The first is as follows:

1. In the configuration utility, select an adapter from the Adapter List. Select the **RAID Properties** option. This will display the current volume.
2. Press **C** to create a new volume.
3. Continue with step 4 of Section 5.2, "Creating IS Volumes," to create a second IS volume.

The other way in which to add a second volume is as follows:

1. On the Adapter List screen, use the arrow keys to select an LSI Logic SAS adapter.
2. Press **Enter** to go to the Adapter Properties screen, shown in Figure 5.1.

3. On the Adapter Properties screen, use the arrow keys to select **RAID Properties** and press **Enter**.
4. Continue with step 4 of the IS creation procedure in the previous section to create a second volume.

5.4 Other Configuration Tasks

This section explains how to do other tasks related to configuring and maintaining IS volumes.

5.4.1 Viewing IS Volume Properties

Follow these steps to view the properties of IS volumes:

1. In the configuration utility, select an adapter from the Adapter List. Select the **RAID Properties** option. The properties of the current volume are displayed.
2. If more than one volume is configured, press **Alt+N** to view the next array.
3. To manage the current array, press **Enter** when the **Manage Array** item is selected.

5.4.2 Activating an Array

An array can become inactive if, for example, it is removed from one controller or computer and moved to another one. The "Activate Array" option allows you to reactivate an inactive array that has been added to a system. This option is only available when the selected array is currently inactive.

Follow these steps to activate a selected array.

1. Select **Activate Array** on the Manage Array screen.
2. Press **Y** to proceed with the activation, or press **N** to abandon it. After a pause, the array will become active.

5.4.3 Deleting an Array

✓ CAUTION: Before deleting an array, be sure to back up all data on the array that you want to keep.

Follow these steps to delete a selected array:

1. Select **Delete Array** on the Manage Array screen.
 2. Press **Y** to delete the array, or press **N** to abandon the deletion. After a pause, the firmware deletes the array.
- ✓ Note:** Once a volume has been deleted, it cannot be recovered. The master boot records of all disks are deleted.

5.4.4 Locating a Disk Drive, or Multiple Disk Drives in a Volume

You can use the SAS BIOS CU to locate and identify a specific physical disk drive by flashing the drive's LED. You can also use the SAS BIOS CU to flash the LEDs of all the disk drives in a RAID volume. There are several ways to do this:

- ▶ When you are creating an IS volume, and a disk drive is set to **Yes** as part of the volume, the LED on the disk drive is flashing. The LED is turned off when you

have finished creating the volume.

- ▶ You can locate individual disk drives from the SAS Topology screen. To do this, move the cursor to the name of the disk in the Device Identifier column and press **Enter**. The LED on the disk flashes until the next key is pressed.
- ▶ You can locate all the disk drives in a volume by selecting the volume on the RAID Properties screen. The LEDs flash on all disk drives in the volume.
- ✓ **Note:** The LEDs on the disk drives will flash as described above if the firmware is correctly configured and the drives or the disk enclosure supports disk location.

5.4.5 Selecting a Boot Disk

You can select a boot disk in the SAS Topology screen. This disk is then moved to scan ID 0 on the next boot, and remains at this position. This makes it easier to set BIOS boot device options and to keep the boot device constant during device additions and removals. There can be only one boot disk.

Follow these steps to select a boot disk:

1. In the SAS BIOS CU, select an adapter from the Adapter List.
 2. Select the **SAS Topology** option.
The current topology is displayed. If the selection of a boot device is supported, the bottom of the screen lists the Alt+B option. This is the key for toggling the boot device. If a device is currently configured as the boot device, the Device Info column on the SAS Topology screen will show the word "Boot."
 3. To select a boot disk, move the cursor to the disk and press **Alt+B**.
 4. To remove the boot designator, move the cursor down to the current boot disk and press **Alt+B**. This controller will no longer have a disk designated as boot.
 5. To change the boot disk, move the cursor to the new boot disk and press **Alt+B**. The boot designator will move to this disk.
- ✓ **Note:** The firmware must be configured correctly in order for the Alt+B feature to work.