

# X9QRi-F X9QR7-TF X9QR7-TF-JBOD

USER'S MANUAL

Revision 1.1a

The information in this user's manual has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, and makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates. Please Note: For the most up-to-date version of this manual, please see our Website at www.supermicro.com.

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software and documentation, is the property of Supermicro and/or its licensors, and is supplied only under a license. Any use or reproduction of this product is not allowed, except as expressly permitted by the terms of said license.

IN NO EVENT WILL SUPER MICRO COMPUTER, INC. BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPER MICRO COMPUTER, INC. SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between the manufacturer and the customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Supermicro's total liability for all claims will not exceed the price paid for the hardware product.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction manual, may cause harmful interference with radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

<u>California Best Management Practices Regulations for Perchlorate Materials</u>: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate".

<u>WARNING</u>: Handling of lead solder materials used in this product may expose you to lead, a chemical known to the State of California to cause birth defects and other reproductive harm.

Manual Revision 1.1a

Release Date: April 23, 2014

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2014 by Super Micro Computer, Inc. All rights reserved.

Printed in the United States of America

### **Preface**

This manual is written for system integrators, PC technicians and knowledgeable PC users. It provides information for the installation and use of the X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD motherboard.

### **About This Motherboard**

The Super X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD motherboard supports quad Intel E5-4600(v2) (Socket R) series processors that offer QPI (Intel QuickPath Interface) Technology (V.1.1), providing point-to-point connection with a transfer speed of up to 8.0 TG/s. With the C602 chipset built in, the X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD motherboard supports Intel® Manageability Engine (ME), Rapid Storage Technology, Digital Media Interface (DMI), PCI-E Gen. 3.0 and 1600 MHz DDR3 memory. These features will greatly enhance system performance. This motherboard is ideal for HPC/Cluster/Database server platforms. Please refer to our Website (http://www.supermicro.com) for CPU and memory support updates.



**Note**: E5-4600v2 processor support is available when the latest BIOS (BIOS Version 3.0 or later) is used in your system.

# **Manual Organization**

**Chapter 1** describes the features, specifications and performance of the mother-board, and provides detailed information about the Intel C602 chipset.

**Chapter 2** provides hardware installation instructions. Read this chapter when installing the processor, memory modules and other hardware components into the system. If you encounter any problems, see **Chapter 3**, which describes trouble-shooting procedures for video, memory, and system setup stored in the CMOS.

**Chapter 4** includes an introduction to the BIOS, and provides detailed information on running the CMOS Setup utility.

Appendix A provides BIOS Error Beep Codes.

Appendix B lists Software Installation Instructions.

### **Conventions Used in the Manual**

Pay special attention to the following symbols for proper system installation and to prevent damage to the system or injury to yourself:

**Warning:** Important information given to ensure proper system installation or to prevent damage to system components or injury to yourself.



**Note:** Additional information given to differentiate among various models or provides information for correct system setup.

# **Contacting Supermicro**

#### Headquarters

Address: Super Micro Computer, Inc.

980 Rock Ave.

San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000 Fax: +1 (408) 503-8008

Email: marketing@supermicro.com (General Information)

support@supermicro.com (Technical Support)

Web Site: www.supermicro.com

**Europe** 

Address: Super Micro Computer B.V.

Het Sterrenbeeld 28, 5215 ML

's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390 Fax: +31 (0) 73-6416525

Email: sales@supermicro.nl (General Information)

support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)

Web Site: www.supermicro.nl

Asia-Pacific

Address: Super Micro Computer, Inc.

3F, No. 150, Jian 1st Rd.

Zhonghe Dist., New Taipei City 235

Taiwan (R.O.C)

Tel: +886-(2) 8226-3990 Fax: +886-(2) 8226-3992

Email: support@supermicro.com.tw
Web Site: www.supermicro.com.tw

# **Table of Contents**

### Preface

1-1	Overview	1-1
1-2	Processor and Chipset Overview	
1-3	Special Features	
1-4	PC Health Monitoring	
1-5	ACPI Features	1-13
1-6	Power Supply	1-13
1-7	Super I/O	
1-8	Advanced Power Management	
	Intel® Intelligent Power Node Manager (IPNM)	1-14
	Management Engine (ME)	
1-9	Overview of the Nuvoton WPCM450 Controller	1-15
	WPCM450R DDR2 Memory Interface	1-15
	WPCM450R PCI System Interface	1-15
	Other Features Supported by the WPCM BMC Controller	1-15
Cha	pter 2 Installation	
2-1	Standardized Warning Statements	2-1
2-2	Static-Sensitive Devices	
2-3	Processor and Heatsink Installation	2-5
	Installing the LGA2011 Processor	2-5
	Installing a Passive CPU Heatsink	
	Removing the Heatsink	2-10
2-4	Installing and Removing the Memory Modules	2-11
	Installing & Removing DIMMs	
	Removing Memory Modules	2-11
2-5	Motherboard Installation	2-17
	Tools Needed	2-17
	Location of Mounting Holes	2-17
	Installing the Motherboard	2-18
2-6	Control Panel Connectors and I/O Ports	2-19
	Back Panel Connectors and I/O Ports	2-19
	Back Panel I/O Port Locations and Definitions	2-19
	Serial Ports	2-20
	Video Connection	2-20
	Universal Serial Bus (USB)	2-21
	Ethernet Ports	2-22

	ATX PS/2 Keyboard/Mouse Ports	2-23
	Unit Identifier Switch	2-24
	Front Control Panel	2-25
	Front Control Panel Pin Definitions	2-26
	NMI Button	2-26
	Power LED	2-26
	HDD LED	2-27
	NIC1/NIC2 LED Indicators	2-27
	Overheat (OH)/Fan Fail/PWR Fail/UID LED	2-28
	Power Fail LED	2-28
	Reset Button	2-29
	Power Button	2-29
2-7	Connecting Cables	2-30
	Power Connectors	2-30
	Fan Headers	2-31
	Chassis Intrusion	2-31
	Internal Speaker	2-32
	T-SGPIO1/2/3 Headers	2-32
	Standby Power Header	2-33
	DOM Power Connector	2-33
	Power SMB (I <sup>2</sup> C) Connector	2-34
	IPMB Header	2-34
	TPM Header/Port 80	2-35
2-8	Jumper Settings	2-36
	Explanation of Jumpers	2-36
	GLAN Enable/Disable	2-36
	CMOS Clear	2-37
	Watch Dog Enable/Disable	2-37
	VGA Enable	2-38
	BMC Enable	2-38
	Management Engine (ME) Recovery	2-39
	Manufacturer Mode Select	2-39
	SAS Enable	2-40
	I <sup>2</sup> C Bus to PCI-Exp. Slots	2-40
	TPM Enable	2-41
2-9	Onboard LED Indicators	2-42
	GLAN LEDs	2-42
	IPMI Dedicated LAN LEDs	2-42
	BMC Heartbeat LED	2-43

	Unit Identification Switch/LED	2-43
	Onboard Power LED	2-44
2-10	Serial ATA Connections	2-45
	Serial ATA Ports	2-45
	SAS2 Ports	2-45
Chap	oter 3 Troubleshooting	
3-1	Troubleshooting Procedures	3-1
3-2	Technical Support Procedures	3-5
3-3	Battery Removal and Installation	3-6
3-4	Frequently Asked Questions	3-7
3-5	Returning Merchandise for Service	3-8
Chap	oter 4 BIOS	
4-1	Introduction	4-1
4-2	Main Setup	4-2
4-3	Advanced Setup Configurations	4-4
4-4	Event Logs	4-26
4-5	IPMI	4-28
4-6	Boot	4-30
4-7	Security	4-31
4-8	Save & Exit	4-32
Appe	endix A BIOS Error Beep Codes	
A-1	BIOS Error Beep Codes	A-1
Appe	endix B Software Installation Instructions	
B-1	Installing Software Programs	B-1
B-2	Configuring SuperDoctor III (For Window OS Only)	B-2

# Chapter 1

### Overview

#### 1-1 Overview


#### Checklist

Congratulations on purchasing your computer motherboard from an acknowledged leader in the industry. Supermicro boards are designed with the utmost attention to detail to provide you with the highest standards in quality and performance.

Please check that the following items have all been included with your motherboard. If anything listed here is damaged or missing, contact your retailer.

The following items are included in the retail box.

- One (1) Supermicro Mainboard
- Six (6) Serial ATA cables (CBL-0044Lx6) (X9QRi-F)
- Two (2) Serial ATA cables (CBL-0044Lx2) (X9QR7-TF/TF-JBOD)
- Four (4) SAS cables (CBL-097L-03) (X9QR7-TF/TF-JBOD)
- One (1) User's/BIOS Manual (MNL-1370)
- One (1) I/O Shield Bracket (MCP-260-00042-0N)



SMCI product mauals: http://www.supermicro.com/support/manuals/

Product Drivers and utilities: ftp://ftp.supermicro.com/


If you have any questions, please contact our support team at support@supermicro.

# **SUPER** Motherboard Image




Note: All graphics shown in this manual were based upon the latest PCB Revision available at the time of publishing of the manual. The motherboard you've received may or may not look exactly the same as the graphics shown in this manual.

### **Motherboard Layout**



**Note:** For the latest CPU/Memory updates, please refer to our Website at http://www.supermicro.com/products/motherboard/ for details.

### X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD Quick Reference



# Notes:

- See Chapter 2 for detailed information on jumpers, I/O ports and JF1 front panel connections.
- "■" indicates the location of "Pin 1".
- Jumpers/LED Indicators not indicated are for testing only. Components that are not documented are reserved for internal testing only.
- Use only the correct type of onboard CMOS battery as specified by the manufacturer. Do not install the onboard battery upside down to avoid possible explosion.

### X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD Jumpers

Jumper	Description	Default Setting	
JBT1	Clear CMOS	See Chapter 2	
JI <sup>2</sup> C1/JI <sup>2</sup> C2	SMB to PCI-E Slots	Off (Disabled)	
JPB1	BMC Enable	Pins 1-2 (Enabled)	
JPG1	VGA Enable	Pins 1-2 (Enabled)	
JPL1 (X9QRi-F) (Note)	Gigabit LAN Ports 1/2 Enable	Pins 1-2 (Enabled)	
JPME1	Management Engine (ME) Recovery Mode	Pins 1-2 (Normal)	
JPME2	Management Engine (ME) Manufacture Mode	Pins 1-2 (Normal)	
JPS1	SAS Enable for SAS 0~3, SAS 4~7 (JS14/JS15)	Pins 1-2 (Enabled)	
JPS3	SAS Enable for SASA 0~3, SASA 4~7 (JS1/JS2)	Pins 1-2 (Enabled)	
JPT1	TPM (Trusted Platform) Enable	Pins 1-2 (Enabled)	
JPTG1 (X9QR7-TF/TF- JBOD) (See Note)	T_LAN (10G_LAN) Ports Enable	Pins 1-2 (Enabled)	
JWD1	Watch Dog Timer Enable	Pins 1-2 (Reset)	
Note: lumpers IDI 1 and IDTG1 enable or disable onhoard other-			

**Note:** Jumpers JPL1 and JPTG1 enable or disable onboard ethernet LAN ports 1/2. Use JPL1 to enable the GLAN ports 1/2 on the X9QRi-F. Use JPTG1 to enable 10G\_LAN ports 1/2 on the X9QR7-TF/TF-JBOD.

### X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD Connectors

Connectors	Description		
Battery	Onboard Battery (For Proper Battery Disposal, Refer to Chpt.3)		
COM1/COM2	Backplane COM Port1/Front Accessible COM2 Header		
Fan 1~Fan 4, Fan A~ Fan D)	CPU/System Fan Headers (Fan A: Fan 5, Fan B: Fan 6, Fan C: Fan7, and Fan D: Fan 8)		
I-SATA 0/1	Intel SB SATA 3.0 Connectors 0/1 (Color: White)		
I-SATA2~5, 6~9 Intel SB SATA 2.0 Connectors 2~5, 6~9 (Color: Black)			
JF1	Front Panel Control Header		
JL1 Chassis Intrusion			
JIPMB1	4-pin IPMB I <sup>2</sup> C Header (for an IPMI Card)		
JPI <sup>2</sup> C1	Power Supply SMBbus I <sup>2</sup> C Header		
JTPM1	TPM/Port 80 Header		
JPWR1~4	8-Pin SMCI-Proprietary Power Connectors (See Warning on Pg. 1-6.)		

JPWR5	24-Pin SMCI-Proprietary Power Connectors (See Warning on Pg. 1-6.)
JSD1	SATA DOM (Device on Module) Device Power Connector
JSTBY1	Standby Power Connector
LAN1/LAN2	G-bit Ethernet LAN Ports 1/2 (For X9QRi-F Only)
LAN1/LAN2	10G (T)_LAN Ports 1/2 (For X9QR7-TF/TF-JBOD Only)
(IPMI) LAN	IPMI_Dedicated LAN
(PS2) Keyboard/Mouse	PS2 Keyboard/Mouse Connector (Optional)
(L-)SAS0~3, 4~7	First Set of SAS Connections SAS 0~3, SAS 4~7 (JS14/JS15) from the LSI 2308 SAS Controllers
(L-)SASA0~3, 4~7	Second Set of SAS Connections SASA 0~3, SASA 4~7 (JS1/JS2) from the LSI 2308 SAS Controllers
(CPU1) Slot 1	PCI-Express 3.0 x8 in x16 Slot (Available w/CPU1 installed)
(CPU1) Slot 2	PCI-Express 3.0 x16 Slot (Available w/CPU1 installed)
(CPU4) Slots 3/4	PCI-Express 3.0 x16 Slots (Available w/CPU4 installed)
(CPU3) Slots 5/6	PCI-Express 3.0 x16 Slots (Available w/CPU3 installed)
(CPU2) Slots 7/8	PCI-Express 3.0 x16 Slots (Available w/CPU2 installed)
SP1	Internal Speaker/Buzzer
T-SGPIO 1/2/3	Serial_Link General Purpose I/O Headers
UID	Unit Identifier Switch (UIDB1)
USB 0/1, 2/3	Back Panel USB 0/1, 2/3 Ports (JUSB0_1, JUSB2_3)
USB 8, USB 9	Type A USB Connectors for Front Access
USB 4/5, 6/7	Front Accessible USB Connections
VGA	Backpanel VGA Port

#### X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD LED Indicators

LED	Description	State	Status
LED10	Onboard Power LED	On	Power On
LED11	Rear UID (Unit Identification) LED		
LEDM1	BMC Heartbeat LED	Green	BMC Normal

**Warning**: To avoid damaging the power supply or motherboard, be sure to use an SMCI-proprietary power supply that contains a 24-pin and four 8-pin power connectors for your system. Connect these power supply connectors to the 24-pin power connector (JPWR5) and the 8-pin power connectors (JPWR1~4) on the motherboard. Failure to do so will void the manufacturer warranty on your power supply and motherboard.

# **Motherboard Features**


CPU	<ul> <li>Quad Intel® Intel E5-4600(v2) (Socket R-LGA 2011) series processors; each processor supports two full-width Intel QuickPath Interconnect (QPI) links (with support of up to 16 GT/s per direction)</li> <li>Note 1: E5-4600v2 processor support is available when the latest BIOS (BIOS Version 3.0 or later) is used in your system.</li> </ul>
	<b>Note 2</b> : To fully utilize all functionality and features offered by this quad motherboard, be sure to install four CPUs on the motherboard. Without four CPUs installed onboard, some functions or features might not be supported.
Memory	<ul> <li>Integrated memory controller supports 240-pin Registered (RDIMM)/Load Reduced (LRDIMM) ECC or Unbuffered (UDIMM) ECC/Non-ECC DDR3 800/1066/1333/1600/1866 MHz memory modules of up to up to 768 GB in 24 DIMM modules</li> <li>Note 1: To optimize memory performance, please install 16 DIMMs or 24 DIMMs on the motherboard when 4 CPUs are used in the system.</li> </ul>
	<b>Note 2</b> : 1866 memory is available when supported by the processors used in the system with one-DIMM_per-channel configuration.
	<b>Note 3</b> : For UDIMM or other memory support details, please refer to the approved memory list posted on our website at http://www.supermicro.com/products/motherboard.
	<b>Note 4</b> : For the latest CPU/memory updates, please also refer to our website.
Chipset	Intel® C602 Chipset
Expansion	Seven (7) PCI Express 3.0 x16 slots (CPU1_Slot2,
Slots	CPU4_Slots3/4, CPU3_Slots5/6, CPU2_Slots7/8),
	One (1) PCI Express 3.0 x8 in x 16 slot (CPU1_Slot1)  Newstern (Mishand) PMO Nishan Contaction (Mathematical Contactions)
Graphics	Nuvoton (Winbond) BMC Video Controller (Matrox G200eW)


Network	<ul> <li>One Intel i350 Gigabit (10/100/1000 Mb/s) Ethernet Dual-Channel Controller for LAN 1/LAN 2 ports for X9QRi-F;</li> <li>One Intel X540 10G Ethernet Dual-Channel Controller</li> </ul>			
		for TLAN 1/TLAN 2 ports for X9QR7-TF/TF-JBOD.		
			450 Base-board Controller (BMC)	
	SU	ipports IPMI_L/	AN 2.0	
I/O Devices		SATA Connec	tions	
	• S/	ATA Ports	Two (2) SATA 3.0 Ports (I-SATA 0/1),	
			Eight (8) SATA 2.0 Ports (I-SA-TA 2~5, I-SATA 6~9 from SCU)	
	RAID 0, 1, 5, 10 (Windows or Linux w/latest kernel)			
		<b>SAS</b> Connect	ions	
	• S/	AS3.0 Ports	L-SAS 0~3, L-SAS 4~7 (JS14/15);	
			L-SASA 0~3, L-SASA 4~7 (JS1/2)	
	• S/	AS Controller	LSI 2308 SAS Controller	
	• R	RAID Support RAID 0, 1, 10 (Software RAID)		
	IPMI 2.0			
	IPMI 2.0 supported by the WPCM450 BMC			
	Serial (COM) Port			
		Super I/O		
	• W	inbond Super I	/O 83527	
Peripheral	USB Devices			
Devices	Four (4) USB ports on the rear I/O panel (USB 0/1, USB 2/3),			
	<ul> <li>Four (4) USB connections for front access: dual-port connectors (USB 4/5, USB 6/7)</li> </ul>			
	Two (2) Type A USB connections for front access (USB 8, USB 9)			
BIOS	• 64	Mb AMI BIOS	® SM Flash EEPROM BIOS	
		<ul> <li>APM 1.2, PCI 2.3, ACPI 1.0/2.0/3.0/4.0, USB Key- board, Plug &amp; Play (PnP) and SMBIOS 2.3</li> </ul>		

Power	ACPI/ACPM Power Management		
Config.	Main switch override mechanism		
	Keyboard Wake-up from Soft-Off		
	Power-on mode for AC power recovery		
PC Health	CPU Monitoring		
Monitoring	<ul> <li>Onboard voltage monitors for memory voltage, chip- set voltage, +3.3V, 3.3V Standby, +5V, +12V, and battery voltage.</li> </ul>		
	CPU 5+1-Phase switching voltage regulator		
	CPU/System overheat LED and control		
	CPU Thermal Trip support		
	Thermal Monitor with 3-zone support		
	Intel® Manageability Engine (ME)		
	<ul> <li>Intel® Intelligent Power Node Manager (NM) (Available when supporting firmware and power supply cables are installed onboard. See Section 1-8 for details.)</li> </ul>		
	Fan Control		
	Fan status monitoring with firmware thermal manage- ment via IPMI 2.0		
	Low noise fan speed control		
System Management	<ul> <li>PECI (Platform Environment Configuration Interface)</li> <li>2.0 support</li> </ul>		
	System resource alert via SuperDoctor® III		
	SuperoDoctor® III, Watch Dog, NMI		
	Chassis Intrusion Header and Detection		
Dimensions	• 17.00" (L) x 17.00" (W) (431.80 mm x 431.80 mm)		

# Notes:

- 1. For IPMI Configuration Instructions, please refer to the Embedded IPMI Configuration User's Guide available @ http://www.supermicro.com/support/manuals/.
- 2. For the latest CPU/memory updates, please refer to our Website at http://www.supermicro.com/products/motherboard.





### System Block Diagram

Note: This is a general block diagram and may not exactly represent the features on your motherboard. See the Motherboard Features pages for the actual specifications of each motherboard.

### 1-2 Processor and Chipset Overview

Built upon the functionality and the capability of Intel E5-4600 (v2) (Socket R) series processors and the C602 chipset, the X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD motherboard provides the performance and feature sets required for quad\_processor-based HPC/Cluster/Database servers.

With support of Intel QuickPath interconnect (QPI) Technology, the X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD offers point-to-point serial interconnect interface with a transfer speed of up to 16.0 GT/s per direction, providing superb system performance.

The C602 chipset provides extensive IO support, including the following functions and capabilities:

- PCI-Express Rev. 2.0 support
- PCI-Express Gen. 3 uplink supported by some SKUs
- ACPI Power Management Logic Support Rev. 3.0b or Rev. 4.0
- USB host interface backplane and front access support
- Intel Rapid Storage Technology supported
- Intel Virtualization Technology for Directed I/O (Intel VT-d) supported
- Intel Trusted Execution Technology supported
- Serial Peripheral Interface (SPI) Supported
- Digital Media Interface (DMI) supported
- Advanced Host Controller Interface (AHCI) supported
  - Note: E5-4600v2 processor support is available when the latest BIOS (BIOS Version 3.0 or later) is used in your system.

# 1-3 Special Features

### Recovery from AC Power Loss

The Basic I/O System (BIOS) provides a setting that determines how the system will respond when AC power is lost and then restored to the system. You can choose for the system to remain powered off (in which case you must press the power switch to turn it back on), or for it to automatically return to the power-on state. See the Advanced BIOS Setup section for this setting. The default setting is **Last State**.

# 1-4 PC Health Monitoring

This section describes the features of PC health monitoring of the motherboard. This motherboard has an onboard System\_Hardware\_Monitor chip that supports PC health monitoring. An onboard voltage monitor will scan the following onboard voltages continuously: memory voltage, chipset voltage, +3.3V, 3.3V Standby, +5V, +12V, and battery voltage. Once a voltage becomes unstable, a warning is given, or an error message is sent to the screen. The user can adjust the voltage thresholds to define the sensitivity of the voltage monitor.

#### Fan Status Monitor with Firmware Control

The PC health monitoring chip can check the RPM status of a cooling fan. The onboard CPU and chassis fans are controlled by Firmware Thermal Management via IPMI interface

# **Environmental Temperature Control**

A thermal control sensor monitors the CPU temperature in real time and will turn on the thermal control fan whenever the CPU temperature exceeds a user-defined threshold. Once the CPU temperature reach the temperature threshold, it will automatically turn on the thermal fan control to prevent the CPU from overheating. The onboard chassis thermal circuitry can monitor the overall system temperature and alert the user when the chassis temperature is too high.



**Note**: To avoid possible system overheating, please be sure to provide adequate airflow to your system.

# **System Resource Alert**

This feature is available when used with SuperDoctor III in the Windows OS environment or used with SuperDoctor II in Linux. SuperDoctor is used to notify the user of certain system events. For example, you can configure SuperDoctor

to provide you with warnings when the system temperature, CPU temperatures, voltages, and fan speeds go beyond a predefined range.

### 1-5 ACPI Features

ACPI stands for Advanced Configuration and Power Interface. The ACPI specification defines a flexible and abstract hardware interface that provides a standard way to integrate power management features throughout a PC system, including its hardware, operating system and application software. This enables the system to automatically turn on and off peripherals such as CD-ROMs, network cards, hard disk drives and printers.

In addition to operating\_system-directed power management, ACPI also provides a generic system event mechanism for Plug and Play, and an operating system-independent interface for configuration control. ACPI leverages the Plug and Play BIOS data structures, while providing a processor architecture-independent implementation that is compatible with Windows 7, Windows Vista and Windows 2008 Operating Systems.

### Slow Blinking LED for Suspend-State Indicator

When the CPU goes into a suspend state, the chassis power LED will start blinking to indicate that the CPU is in suspend mode. When the user presses any key, the CPU will "wake up," and the LED will automatically stop blinking and remain on.

# 1-6 Power Supply

As with all computer products, a stable power source is necessary for proper and reliable operation. It is even more important for processors that have high CPU clock rates.

The X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD motherboard accommodates 24-pin ATX power supplies. Although most power supplies generally meet the specifications required by the CPU, some are inadequate. In addition, four 12V 8-pin power connections are also required to ensure adequate power supply to the system. Your power supply must also supply 1.5A for the Ethernet ports.

**Warning:** To avoid damaging the power supply or motherboard, be sure to use an SMCI-proprietary power supply that contains a 24-pin and four 8-pin power connectors. Connect these power supply connectors to the 24-pin power connector (JPWR5) and the 8-pin power connectors (JPWR1~4) on the motherboard. Failure to do so will void the manufacturer warranty on your power supply and motherboard.

It is strongly recommended that you use a high quality power supply that meets ATX power supply Specification 2.02 or above. It must also be SSI compliant. (For more information, please refer to the Website at http://www.ssiforum.org/). Additionally, in areas where noisy power transmission is present, you may choose to install a line filter to shield the computer from noise. It is recommended that you also install a power surge protector to help avoid problems caused by power surges.

# 1-7 Super I/O

The Super I/O supports two high-speed, 16550 compatible serial communication ports (UARTs). Each UART includes a 16-byte send/receive FIFO, a programmable baud rate generator, complete modem control capability, and a processor interrupt system. Both UARTs provide legacy speed with baud rate of up to 115.2 Kbps as well as an advanced speed with baud rates of 250 K, 500 K, or 1 Mb/s, which support higher speed modems.

The Super I/O provides functions that comply with ACPI (Advanced Configuration and Power Interface), which includes support of legacy and ACPI power management through an SMI or SCI function pin. It also features auto power management to reduce power consumption.

# 1-8 Advanced Power Management

The new advanced power management features supported by this motherboard include IPNM and ME. Please note that you will need to do following to use these two new features:

- Use a power supply that supports PMBus 1.1 or 1.2.
- Install the NMView software in your system. NMView is optional and can be purchased from Supermicro.

# Intel® Intelligent Power Node Manager (IPNM)

The Intel® Intelligent Power Node Manager (IPNM) provides your system with real-time thermal control and power management for maximum energy efficiency. Although IPNM is supported by the BMC (Baseboard Management Controller), your system must also have IPNM-compatible Management Engine (ME) firmware installed in your system for IPNM support.

**Note**: Support for IPNM Specification Version 1.5 or Vision 2.0 depends on the power supply used in the system.

### Management Engine (ME)

The Management Engine, which is an ARC controller embedded in the PCH, provides Server Platform Services (SPS) to your system. The services provided by SPS are different from those provided by the ME on client platforms.

### 1-9 Overview of the Nuvoton WPCM450 Controller

The Nuvoton WPCM450R Controller, a Baseboard Management Controller (BMC), supports 2D/VGA-compatible Graphic Cores with PCI interface, creating multi-media virtualization via Keyboard/Video/Mouse Redirection (KVMR). The WPCM450R Controller is ideal for remote system management.

The WPCM450R Controller interfaces with the host system via PCI connections to communicate with the graphics cores. It supports USB 2.0 and 1.1 for remote keyboard/mouse/virtual media emulation. It also provides LPC interface support to control Super IO functions. The WPCM450R Controller is connected to the network via an external Ethernet PHY module or shared NCSI connections.

The WPCM450R communicates with onboard components via six SMBus interfaces, PECI (Platform Environment Control Interface) buses, and General Purpose I/O ports.

### WPCM450R DDR2 Memory Interface

The WPCM450R supports a 16-bit DDR2 memory module with a speed of up to 220 MHz. For best signal integrity, the WPCM450R provides point-to-point connection.

# WPCM450R PCI System Interface

The WPCM450R provides 32-bit, 33 MHz 3.3V PCI interface, which is compliant with the PCI Local Bus Specification Rev. 2.3. The PCI system interface connects to the onboard PCI Bridge used by the graphics controller.

# Other Features Supported by the WPCM BMC Controller

The WPCM450R supports the following features:

- IPMI 2 0
- Serial over LAN
- KVM over LAN
- LAN Alerting-SNMP Trap

- Event Log
- X-Bus parallel interface for I/O expansion
- Multiple ADC inputs, Analog and Digital Video outputs
- SPI Flash Host BIOS and firmware bootstrap program supported
- Reduced Media Independent Interface (RMII)
- OS (Operating System) Independency
- Provides remote Hardware Health Monitoring via IPMI. Key features
- Provides Network Management Security via remote access/console redirection.
- Supports the following Management tools: IPMIView, CLI (Command Line Interface)
- RMCP+ protocol supported

# Chapter 2

### Installation

# 2-1 Standardized Warning Statements

The following statements are industry-standard warnings, provided to warn the user of situations which have the potential for bodily injury. Should you have questions or experience difficulty, contact Supermicro's Technical Support department for assistance. Only certified technicians should attempt to install or configure components.

Read this section in its entirety before installing or configuring components in the Supermicro chassis.

### **Battery Handling**



### Warning!

There is a danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions

#### 雷池の取り扱い

電池交換が正しく行われなかった場合、破裂の危険性があります。 交換する電池はメーカーが推奨する型、または同等のものを使用下さい。 使用済電池は製造元の指示に従って処分して下さい。

#### 警告

电池更换不当会有爆炸危险。请只使用同类电池或制造商推荐的功能相当的电池更 换原有电池。请按制造商的说明处理废旧电池。

### 警告

電池更換不當會有爆炸危險。請使用製造商建議之相同或功能相當的電池更換原有電池。請按照製造商的說明指示處理廢棄舊電池。

#### Warnung

Bei Einsetzen einer falschen Batterie besteht Explosionsgefahr. Ersetzen Sie die Batterie nur durch den gleichen oder vom Hersteller empfohlenen Batterietyp. Entsorgen Sie die benutzten Batterien nach den Anweisungen des Herstellers.

#### Attention

Danger d'explosion si la pile n'est pas remplacée correctement. Ne la remplacer que par une pile de type semblable ou équivalent, recommandée par le fabricant. Jeter les piles usagées conformément aux instructions du fabricant.

#### ¡Advertencia!

Existe peligro de explosión si la batería se reemplaza de manera incorrecta. Reemplazar la batería exclusivamente con el mismo tipo o el equivalente recomendado por el fabricante. Desechar las baterías gastadas según las instrucciones del fabricante.

אותרות ! קייימה מכנות פיצויץ של המוללה בפירה והוואלפה בדרך לא הקינוב. יש להוולקה את המוללה בנאן, התואנו מווכרת יצרץ מומלצוו.

טילוק הטיללות ופנשונקשות יש לבצצ לפי ופראות היצוין.

هناك خطر من انتجل في حالة استبدال البطارية بطريقة غير مسجحة قطيك استبدال البطارية فقط بنفس النوع أو ما يحلالها كما أوصت به التوكة المستحة تخلص من البطاريات المستحلة وفقا التعلمات التوكة الصافحة

#### 경고!

배터리가 올바르게 교체되지 않으면 폭발의 위험이 있습니다. 기존 배터리와 동일 하거나 제조사에서 권장하는 동등한 종류의 배터리로만 교체해야 합니다. 제조사 의 안내에 따라 사용된 배터리를 처리하여 주십시오.

#### Waarschuwing

Er is ontploffingsgevaar indien de batterij verkeerd vervangen wordt. Vervang de batterij slechts met hetzelfde of een equivalent type die door de fabrikant aanbevolen wordt. Gebruikte batterijen dienen overeenkomstig fabrieksvoorschriften afgevoerd te worden.

### **Product Disposal**



#### Warning!

Ultimate disposal of this product should be handled according to all national laws and regulations.

#### 製品の廃棄

この製品を廃棄処分する場合、国の関係する全ての法律・条例に従い処理する必要があります。

#### 警告

本产品的废弃处理应根据所有国家的法律和规章进行。

#### 警告

本產品的廢棄處理應根據所有國家的法律和規章進行。

#### Warnung

Die Entsorgung dieses Produkts sollte gemäß allen Bestimmungen und Gesetzen des Landes erfolgen.

#### ¡Advertencia!

Al deshacerse por completo de este producto debe seguir todas las leyes y reglamentos nacionales.

#### Attention

La mise au rebut ou le recyclage de ce produit sont généralement soumis à des lois et/ou directives de respect de l'environnement. Renseignez-vous auprès de l'organisme compétent.

טילוק המוצר

אחתרה ! מילוק סופי של סרצר זה חייב להיות בהתאם להנחיית וחוקי הקרינה.



Waarschuwing

De uiteindelijke verwijdering van dit product dient te geschieden in overeenstemming met alle nationale wetten en reglementen.

### 2-2 Static-Sensitive Devices

Electrostatic Discharge (ESD) can damage electronic components. To avoid damaging your system board, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

#### **Precautions**

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing the board from the antistatic bag.
- Handle the board by its edges only; do not touch its components, peripheral chips, memory modules or gold contacts.
- When handling chips or modules, avoid touching their pins.
- Put the motherboard and peripherals back into their antistatic bags when not in use.
- For grounding purposes, make sure that your system chassis provides excellent conductivity between the power supply, the case, the mounting fasteners and the motherboard.

### Unpacking

The motherboard is shipped in antistatic packaging to avoid static damage. When unpacking the board, make sure that the person handling it is static protected.

### 2-3 Processor and Heatsink Installation

Warning: When handling the processor package, avoid placing direct pressure on the label area.

### Notes:


- Always connect the power cord last, and always remove it before adding, removing or changing any hardware components.
- Make sure that you install the processor into the CPU socket before you install the CPU heatsink. If only one CPU is used, be sure to install in CPU socket 1
- If you buy a CPU separately, make sure that you use an Intel-certified multidirectional heatsink only.
- Make sure to install the system board into the chassis before you install the CPU heatsink.
- When receiving a server board without a processor pre-installed, make sure that the plastic CPU socket cap is in place and none of the socket pins are bent; otherwise, contact your retailer immediately.

Refer to the Supermicro website for updates on CPU support.


Note: For best system performance, we recommend that a pair of CPUs (CPU1/CPU2) or two pairs of CPUs (CPU1/CPU2/CPU3/CPU4) be installed on the motherboard. Using 3 CPUs is not recommended. Please install your memory modules according to the number of CPUs used in your system.

# Installing the LGA2011 Processor


 There are two load levers on the LGA2011 socket. To open the socket cover, first press and release the load lever labeled 'Open 1st'.




Press the second load lever labeled 'Close 1st' to release the load plate that covers the CPU socket from its locking position.




 With the lever labeled 'Close 1st' fully retracted, gently push down on the lever marked 'Open 1st' to open the load plate. Lift the load plate to open it completely.




1. Use your index fingers to loosen the lever and open the load plate.



Use your thumb and index finger to hold the CPU on its edges. Align the CPU keys, which are semi-circle cutouts, against the socket keys.




Once they are aligned, carefully lower the CPU straight down into the socket.
 (Do not drop the CPU on the socket. Do not move the CPU horizontally or vertically. Do not rub the CPU against the surface or against any pins of the socket to avoid damaging the CPU or the socket.)




Warning: You can only install the CPU inside the socket in one direction. Make sure that it is properly inserted into the CPU socket before closing the load plate. If it doesn't close properly, do not force it as it may damage your CPU. Instead, open the load plate again and double-check that the CPU is aligned properly.

- 4. With the CPU inside the socket, inspect the four corners of the CPU to make sure that the CPU is properly installed.
- Close the load plate with the CPU inside the socket. Lock the lever labeled 'Close 1st' first, then lock the lever labeled 'Open 1st' second. Use your thumb to gently push the load levers down to the lever locks.



### Installing a Passive CPU Heatsink

- Do not apply any thermal grease to the heatsink or the CPU die -- the required amount has already been applied.
- Place the heatsink on top of the CPU so that the four mounting holes are aligned with those on the Motherboard's and the Heatsink Bracket underneath.
- 3. Screw in two diagonal screws (i.e., the #1 and the #2 screws) until just snug (-do not over-tighten the screws to avoid possible damage to the CPU.)
- 4. Finish the installation by fully tightening all four screws.




Heatsink for 4U Systems

### Removing the Heatsink

**Warning:** We do not recommend that the CPU or the heatsink be removed. However, if you do need to uninstall the heatsink, please follow the instructions below to uninstall the heatsink to prevent damage done to the CPU or the CPU socket.

- Unscrew the heatsink screws from the motherboard in the sequence as shown in the illustration below.
- Gently wriggle the heatsink to loosen it from the CPU. (Do not use excessive force when wriggling the heatsink!)
- 3. Once the CPU is loosened, remove the CPU from the CPU socket.
- 4. Remove the used thermal grease and clean the surface of the CPU and the heatsink, Reapply the proper amount of thermal grease on the surface before reinstalling the CPU and the heatsink.



# 2-4 Installing and Removing the Memory Modules


Note: Check Supermicro's Website for recommended memory modules.

#### CAUTION

Exercise extreme care when installing or removing DIMM modules to prevent any possible damage.

### Installing & Removing DIMMs

- Insert the desired number of DIMMs into the memory slots, starting with P1-DIMM #1A. (For best performance, please use the memory modules of the same type and speed in the same bank.)
- 2. Push the release tabs outwards on both ends of the DIMM slot to unlock it.



- Align the key of the DIMM module with the receptive point on the memory slot
- 4. Align the notches on both ends of the module against the receptive points on the ends of the slot.
- Use two thumbs together to press the notches on both ends of the module straight down into the slot until the module snaps into place.
- Press the release tabs to the locking positions to secure the DIMM module into the slot.

Press both notches straight down into the memory slot at the same time.

# **Removing Memory Modules**

Press both notches on the ends of the DIMM module to unlock it. Once the DIMM module is loosened, remove it from the memory slot.

### Memory Support for the X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD Motherboard

The X9QRi-F/X9QR7-TF/X9QR7-TF-JBOD Motherboard supports up to 768 GB Registered (RDIMM)/Load Reduced (LRDIMM) ECC and Unbuffered (UDIMM) ECC/Non-ECC DDR3 of up to 800/1066/1333/1600/1866 MHz memory in 24 DIMM slots.

Notes: 1. 1866 MHz memory is available when supported by the processors installed in your system using the one-DIMM\_per-channel memory configuration. 2. For best system performance, we recommend that a pair of CPUs (CPU1/CPU2) or two pairs of CPUs (CPU1/CPU2/CPU3/CPU4) be installed. Using three CPUs is not recommended. Please install your DIMM modules according to the number of CPUs used in the system. 3. For UDIMM or other memory support details, please refer to the approved memory list posted on our website. 4. To optimize memory performance, please install 16 DIMMs or 24 DIMMs on the motherboard when 4 CPUs are used in the system.

# Processor & Memory Module Population Configuration

	Processors and their Corresponding Memory Modules									
CPU#	Corresponding DIMM Modules									
CPU 1	P1-A1	P1-A2	P1-B1	P1-B2	P1-C1	P1-C2	P1-D1	P1-D2		
CPU2	P2-E1	P2-E2	P2-F1	P2-F2	P2-G1	P2-G2	P2-H1	P2-H2		
CPU3	P3-J1		P3-K1		P3-L1		P3-M1			
CPU4	P4-N1		P4-P1		P4-R1		P4-T1			

	Processor and Memory Module Population		
Number of CPUs+DIMMs	CPU and Memory Population Configuration Table (For memory to work properly, please follow the instructions below.)		
1 CPU & 2 DIMMs	CPU1 P1-DIMMA1/P1-DIMMB1		
1 CPU & 4 DIMMs	CPU1 P1-DIMMA1/P1-DIMMB1, P1-DIMMC1/P1-DIMMD1		
1 CPU & CPU1 P1-DIMMS P1-DIMMC1/P1-DIMMD1, P1-DIMMA2/P1-DIMMB2, P1-DIMMC2/P1-DIMMD2			
2 CPUs & CPU1 + CPU2 P1-DIMMS P1-DIMMB1, P2-DIMME1/P2-DIMMF1			
2 CPUs & 6 DIMMs	CPU1 + CPU2 P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1, P2-DIMME1/P2-DIMMF1		
2 CPUs & 8 DIMMs	CPU1 + CPU2 P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1, P2-DIMME1/P2-DIMMF1/P2- DIMMG1/P2-DIMMH1		
2 CPUs & 10 DIMMs	CPU1/CPU2 P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1, P1-DIMMA2/P1-DIMMB2, P2-DIMME1/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1		
2 CPUs & 10~16 DIMMs	CPU1/CPU2 P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1, P1-DIMMA2/P1-DIMMB2, P1-DIMMC2/P1-DIMMD2, P2-DIMME1/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1, P2-DIMME2/P2-DIMMF2/P2-DIMMG2/P2-DIMMH2		
4 CPUs & 16~24 DIMMs	CPU1/CPU2/CPU3/CPU4 P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1, P1-DIMMA2/P1-DIMMB2, P1-DIMMC2/P1-DIMMD2, P2-DIMME1/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1, P2-DIMME2/P2-DIMMF2/P2-DIMMG2/P2-DIMMH1, P3-DIMME1/P3-DIMMJ1, P4-DIMMP1/P4-DIMMN1		

# Populating UDIMM (ECC/Non-ECC) Memory Modules

**Note:** For UDIMM memory support details, please refer to the recommended memory list posted on our website.

	Intel E5	-4600 S	Series P	rocess	or UDIMM I	Memor	y Sup <sub>l</sub>	port			
Ranks Per DIMM &				Speed (MT/s) and Voltage Validated by Slot per Channel (SPC) and DIMM Per Channel (DPC)							
Data Width				1 Slot	Per Channel		2 Slots F	er Chani	nel		
				1DPC	1D	PC	2DPC				
			1.35V	1.5V	1.35V	1.5V	1.35V	1.5V			
SRx8 Non-ECC	1GB	2GB	4GB	NA	1066, 1333, 1600	NA	1066, 1333	NA	1066, 1333		
DRx8 Non-ECC	2GB	4GB	8GB	NA	1066, 1333, 1600	NA	1066, 1333	NA	1066, 1333		
SRx16 Non-ECC	512MB	1GB	2GB	NA	1066, 1333, 1600	NA	1066, 1333	NA	1066, 1333		
SRx8 ECC	1GB	2GB	4GB	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333	1066	1066, 1333		
DRx8 ECC	2GB	4GB	8GB	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333	1066	1066, 1333		

**Note**: For detailed information on memory support and updates, please refer to the SMC Recommended Memory List posted on our website at http://www.supermicro.com/support/resources/mem.cfm.

	Intel E	5-460	0v2 S	eries P	rocess	or UD	IMM N	lemory	Suppo	ort		
Ranks Per		ry Capa er DIMM	city	Speed (MT/s) and Voltage Validated by Slot per Channel (SPC) and DIMM Per Channel (DPC)								
DIMM & Data	(See the	Note be	elow)	1 Slot	or 2 Slot	s Per Ch	annel	3	Slots Pe	r Channe	el	
Width	, , ,			1DPC		2DPC (2 Slots Per Channel only)		1DPC		2DPC		
				1.35V	1.5V	1.35V	1.5V	1.35V	1.5V	1.35V	1.5v	
SRx8 Non- ECC	1GB	2GB	4GB	NA	1066, 1333, 1600, 1866	NA	1066, 1333, 1600	N/A	1066, 1333, 1600, 1866	N/A	1066, 1333, 1600	
DRx8 Non- ECC	2GB	4GB	8GB	NA	1066, 1333, 1600, 1866	NA	1066, 1333, 1600	N/A	1066, 1333, 1600, 1866	N/A	1066, 1333, 1600	
SRx16 Non- ECC	512MB	1GB	2GB	NA	1066, 1333, 1600, 1866	NA	1066, 1333, 1600	N/A	1066, 1333, 1600, 1866	N/A	1066, 1333, 1600	
SRx8 ECC	1GB	2GB	4GB	1066, 1333	1066, 1333, 1600, 1866	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600, 1866	1066, 1333	1066, 1333, 1600	
DRx8 ECC	2GB	4GB	8GB	1066, 1333	1066, 1333, 1600, 1866	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600, 1866	1066, 1333	1066, 1333, 1600	

**Note:** For detailed information on memory support and updates, please refer to the SMC Recommended Memory List posted on our website at http://www.supermicro.com/support/resources/mem.cfm.

# Populating RDIMM (ECC) Memory Modules

	Inte	el E5-4	600 Se	ries P	rocessor R	DIMM	Memory Su	ıpport		
Ranks Per	Memory Capacity Per DIMM			Speed (MT/s) and Voltage Validated by Slot per Channel (SPC) and DIMM Per Channel (DPC)						
DIMM & Data	(See t	he Note I	Below)	1 Slot	Per Channel		2 Slots Pe	r Channe	1	
Width				1DPC			1DPC	:	2DPC	
			1.35V	1.5V	1.35V	1.5V	1.35V	1.5V		
SRx8	1GB	2GB	4GB	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	
DRx8	2GB	4GB	8GB	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	
SRx4	2GB	4GB	8GB	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	
DRx4	4GB	8GB	16GB	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	1066, 1333	1066, 1333, 1600	
QRx4	8GB	16GB	32GB	800	1066	800	1066	800	800	
QRx8	4GB	8GB	16GB	800	1066	800	1066	800	800	

**Note:** For detailed information on memory support and updates, please refer to the SMC Recommended Memory List posted on our website at http://www.supermicro.com/support/resources/mem.cfm.

		In	tel E5	-4600v2	2 Serie	s Proc	essor F	RDIMM	Memo	ry Sup	port			
Ranks				Speed (	Speed (MT/s) and Voltage Validated by Slot per Channel (SPC) and DIMM Per Channel (DPC)									
			1 Slot or 2 Slots Per Channel					3	Slots Pe	r Channe	ı			
					Per C	2DPC (2 Slots Per Channel only)		1 DPC		2DPC		3DPC		
				1.35V	1.5V	1.35V	1.5V	1.35V	1.5V	1.35V	1.5V	1.35V	1.5V	
SRx8	1GB	2GB	4GB	1 0 6 6 , 1333	1 0 6 6 , 1333, 1600, 1866	1 0 6 6 , 1333	1066, 1333, 1600	1066, 1333	1 0 6 6 , 1333, 1600, 1866	1066, 1333	1 0 6 6 , 1333, 1600	800	800, 1066	
DRx8	2GB	4GB	8GB	1 0 6 6 , 1333	1 0 6 6 , 1333, 1600, 1866	1 0 6 6 ,	1066, 1333, 1600	1066, 1333	1 0 6 6 , 1333, 1600, 1866	1066, 1333	1 0 6 6 , 1333, 1600	800	800, 1066	
SRx4	2GB	4GB	8GB	1 0 6 6 , 1333	1 0 6 6 , 1333, 1600, 1866	1 0 6 6 , 1333	1066, 1333, 1600	1066, 1333	1 0 6 6 , 1333, 1600, 1866	1066, 1333	1 0 6 6 , 1333, 1600	800	800, 1066	
DRx4	4GB	8GB	16GB	1 0 6 6 , 1333	1 0 6 6 , 1333, 1600, 1866	1 0 6 6 , 1333	1066, 1333, 1600	1066, 1333	1 0 6 6 , 1333, 1600, 1866	1066, 1333	1 0 6 6 , 1333, 1600	800	800, 1066	
QRx4	8GB	16GB	32GB	800	800 1066	800	800	800	800, 1066	800	800	N/A	N/A	
QRx8	4GB	8GB	16GB	800	800 1066	800	800	800	800, 1066	800	800	N/A	N/A	

Note: For detailed information on memory support and updates, please refer to the SMC Recommended Memory List posted on our website at http://www.supermicro.com/support/resources/mem.cfm.

### Populating LRDIMM (ECC) Memory Modules

Intel E5-4600 Series Processor LRDIMM Memory Support							
Ranks Per DIMM & Data Width	Memory Capacity Per DIMM		Speed (MT/s) and Voltage Validated by Slot per Channel (SPC) and DIMM Per Channel (DPC)				
(See the Note Below)				ot Per annel	2 Slots Per Channel		
			10	PC	1DPC and 2DPC		
			1.35V	1.5V	1.35V	1.5V	
QRx4 (DDP)	16GB	32GB	1066, 1333	1066, 1333	1066	1066, 1333	
QRx8 (P)	8GB 16GB		1066, 1333	1066, 1333	1066	1066, 1333	

Note: For detailed information on memory support and updates, please refer to the SMC Recommended Memory List posted on our website at http://www.supermicro.com/support/resources/mem.cfm.

	Ir	itel E5	-4600v2	2 Serie	s Proc	essor	LRDIM	M Mei	nory S	uppor	t		
Ranks Memory Per Capacity		Spee	Speed (MT/s) and Voltage Validated by Slot per Channel (SPC) and DIMM Per Channel (DPC)										
DIMM &	Perl	DIMM	1 Slot or 2 Slots Per Channel					3	Slots Pe	r Channe	əl		
Data Width	(		1DI			2DPC (2 Slots Per Channel only)		1DPC		2DPC		3DPC	
			1.35V	1.5V	1.35V	1.5V	1.35V	1.5V	1.35V	1.5V	1.35V	1.5V	
QRx4 (DDP)	16GB	32GB	1066, 1333, 1600	1066, 1333, 1600, 1866	1066, 1333, 1600	1066, 1333, 1600	1066, 1333, 1600	1066, 1333, 1600, 1866	1066, 1333, 1600	1066, 1333, 1600	1066	1066	
8Rx4 (QDP)	32GB	64GB	1066	1066	1066	1066	1066	1066	1066	1066	1066	1066	

**Note:** For detailed information on memory support and updates, please refer to the SMC Recommended Memory List posted on our website at http://www.supermicro.com/support/resources/mem.cfm.



#### Other Important Notes and Restrictions

- For the memory modules to work properly, please install DIMM modules of the same type, same speed and same operating frequency on the motherboard.
   Mixing of RDIMMs, UDIMMs or LRDIMMs is not allowed. Do not install both ECC and Non-ECC memory modules on the same motherboard.
- Using DDR3 DIMMs with different operating frequencies is not allowed. All channels in a system will run at the lowest common frequency.

# 2-5 Motherboard Installation


All motherboards have standard mounting holes to fit different types of chassis. Make sure that the locations of all the mounting holes for both motherboard and chassis match. Although a chassis may have both plastic and metal mounting fasteners, metal ones are highly recommended because they ground the motherboard to the chassis. Make sure that the metal standoffs click in or are screwed in tightly. Then use a screwdriver to secure the motherboard onto the motherboard tray.

#### **Tools Needed**

- Philips Screwdriver
- Pan head screws (17 pieces)
- Standoffs (17 pieces, if needed)

# **Location of Mounting Holes**


There are thirteen (17) mounting holes on this motherboard indicated by the arrows.




**Warning:** 1) To avoid damaging the motherboard and its components, please do not use a force greater than 8 lb/inch on each mounting screw during motherboard installation. 2) Some components are very close to the mounting holes. Please take precautionary measures to prevent damage to these components when installing the motherboard to the chassis.

# Installing the Motherboard


1. Install the I/O shield into the chassis.




- 2. Locate the mounting holes on the motherboard.
- Locate the matching mounting holes on the chassis. Align the mounting holes on the motherboard against the mounting holes on the chassis.
- Install standoffs in the chassis as needed.



- 5. Install the motherboard into the chassis carefully to avoid damaging mother-board components.
- Using the Phillips screwdriver, insert a Pan head #6 screw into a mounting hole on the motherboard and its matching mounting hole on the chassis.




- 7. Repeat Step 5 to insert #6 screws into all mounting holes.
- 8. Make sure that the motherboard is securely placed in the chassis.



# 2-6 Control Panel Connectors and I/O Ports

The I/O ports are color coded in conformance with the PC 99 specification. See the picture below for the colors and locations of the various I/O ports.





**Back Panel I/O Port Locations and Definitions** 


1.	COM Port 1 (Turquoise)
2.	Back Panel USB Port 3
3.	Back Panel USB Port 2
4.	IPMI_Dedicated LAN
5.	Back Panel USB Port 1
6.	Back Panel USB Port 0
7.	PS2 Keyboard/Mouse (Optional)
8.	GLAN 1 (X9QRi-F), 10G_LAN 1 (X9QR7-TF/TF-JBOD)
9.	GLAN 2 (X9QRi-F), 10G_LAN 2 (X9QR7-TF/TF-JBOD)
10	. Back Panel VGA (Blue)
11.	UID Switch

#### **Serial Ports**

Two COM co COM2) are lo board. COM1 plane I/O pane the CPU1 Slot support. See t pin definitions.


onnections (COM1 &	Pin#	Definition	Pin #	Definition
ocated on the mother-	1	DCD	6	DSR
is located on the Back-	2	RXD	7	RTS
el. COM2, located next to	_		,	
t 1, provides front access	3	TXD	8	CTS
the table on the right for	4	DTR	9	RI
are table on the right for	5	Ground	10	N/A

Serial COM) Ports Pin Definitions



#### **Video Connection**

A Video (VGA) port is located next to LAN1 on the I/O backplane. Refer to the board layout below for the location.



#### **Universal Serial Bus (USB)**

Four Universal Serial Bus ports (USB 2/3, USB 0/1) are located on the I/O back panel. Four USB headers (USB 4/5 and USB 6/7) provide front-accessible USB connections. In addition, two Type A USB headers (USB 8, USB 9) are also located on the motherboard to provide front USB support. (Cables are not included). See the tables on the right for pin definitions.


(Ú	Type A USB (USB 8, 9) Pin Definitions					
Pin#	Definition					
1	+5V					
2	PO-					
3	PO+					
4	Ground					
5	NA					

В	Backplane Accessible USB Connectors Pin Definitions								
USE Pin a		USB 1/3 Pin # Definition							
1	+5V	1	+5V						
2	PO-	2	PO-						
3	PO+	3	PO+						
4	Ground	4	Ground						
5	NC	5	Key						

(NC= No connection)

FP Dual_Port USB (USB 4/5, 6/7) Pin Definitions			
USB 4, 6 USB 5, 7 Pin # Definition Pin # Definition			
1	+5V	1	+5V
2	PO-	2	PO-
3	PO+	3	PO+
4	Ground	4	Ground
5	NC	5	Key

(NC= No connection)



- 1. Backpanel USB 3
- 2. BP USB 2
- 3. BP USB 1
- 4. BP USB 0
- 5. Front USB: USB4/5
- 6. Front USB: USB 6/7
- 7. Type A USB: USB 8
- 8. Type A USB: USB 9




#### **Ethernet Ports**

Two Ethernet ports (LAN1, LAN2) are located on the I/O backplane on the motherboard. These ethernet ports support Gigabit LAN connections on the X9QRi-F and 10G LAN connections on the X9QR7-TF/TF-JBOD. In addition, an IPMI\_Dedicated LAN is located above USB 2/3 ports on the backplane to provide KVM support for IPMI 2.0. All these ports accept RJ45 type cables. Please refer to the LED Indicator Section for LAN LED information.

(1G) LAN Ports Pin Definition				
Pin#	Definition Pin# Definition		Definition	
1	TRCT2	10	TRD4+	
2	TRD2+	11	TRD4-	
3	TRD2-	12	TRCT4	
4	TRD3+	13	LED1 (Green)	
5	TRD3-	14	LED1	
6	TRCT3	15	LED2 (Yellow)	
7	TRCT1	16	Common	
8	TRD1+	17	LED2 (Green)	
9	TRD1-			

10G_LAN Ports Pin Definition			
Pin#	Definition	Pin#	Definition
1	TRCT2	12	TRCT4
2	TRD2+	13	IETCT
3	TRD2-	14	IET+
4	TRD3+	15	IET-
5	TRD3-	16	LED1 (Green)
6	TRCT3	17	LED1
7	TRCT1	18	Ground
8	TRD1+	19	LED2 (Yellow)
9	TRD1-	20	Common
10	TRD4+	21	LED2 (Green)
11	TRD4-		



- 1. LAN1 (GLAN for X9QRi-F, 10G\_LAN for X9QR7-TF/TF-JBOD)
- 2. LAN2 (GLAN for X9QRi-F, 10G\_LAN for X9QR7-TF/TF-JBOD)
- 3. IPMI LAN



# ATX PS/2 Keyboard/Mouse Ports

The ATX PS/2 keyboard and PS/2 mouse are located next to the Back Panel LAN ports 1/2 on the motherboard. See the table at right for pin definitions.

PS/2 Keyboard/Mouse Pin Definitions				
PS2 Keyboard PS2 Mouse		ouse		
Pin#	Definition	Pin#	Definition	
1	KB Data	1	Mouse Data	
2	No Connection	2	No Connection	
3	Ground	3	Ground	
4	Mouse/KB VCC (+5V)	4	Mouse/KB VCC (+5V)	
5	KB Clock	5	Mouse Clock	
6	No Connection 6 No Connection		No Connection	
VCC: with 1.5A PTC (current limit)				



#### Notes:


This motherboard offers three Keyboard/Mouse connection options as shown in the graphic below.

- Connect a keyboard cable or a mouse cable to the PS2 KB/Mouse port.
- Connect an Y cable that includes a KB cable and a mouse cable to the PS2 KB/Mouse port.
- Connect a KB cable and a mouse cable to any USB ports.



#### 1. Keyboard/Mouse

(for a keyboard cable, a Mouse cable, or a Y cable) (optional) 2/3 For a KB cable and a Mouse Cable in any USB ports ) (optional)



#### **Unit Identifier Switch**


A Unit Identifier Switch (UIDB1) and two LED Indicators are located on the motherboard. The UID Switch is located next to the LAN ports on the backplane. The Rear UID LED (LED11) is located next to the UID Switch. The Front Panel UID LED is located at Pins 7/8 of the Front Control Panel at JF1. Connect a cable to Pin 8 on JF1 for Front Panel UID LED indication. When you press the UID switch, both Rear UID LED and Front Panel UID LED Indicators will be turned on. Press the UID switch again to turn off both LED Indicators. These UID Indicators provide easy identification of a system unit that may be in need of service.


9	Not	e: UIE	can a	so be tr	iggered	via
	IPM	II on th	ne moth	nerboard	d. For m	ore
	info	rmatic	n on IF	MI, ple	ase refe	r to
	the	IPMI	User's	Guide	posted	on
	our	Webs	ite @h	ttp://ww	w.super	mi-
	cro.	com.				

UID Switch	
Pin#	Definition
1	Ground
2	Ground
3	Button In
4	Ground

UID LED Status			
Color/State OS Status			
Blue: On	Windows OS	Unit Identified	
Blue: Blinking	Linux OS	Unit Identified	


- 1. UID Switch
- 2. Rear UID LED (LED11)
- 3. Front UID LED






#### **Front Control Panel**

JF1 contains header pins for various buttons and indicators that are normally located on a control panel at the front of the chassis. These connectors are designed specifically for use with Supermicro's server chassis. See the figure below for the descriptions of the various control panel buttons and LED indicators. Refer to the following section for descriptions and pin definitions.





#### **Front Control Panel Pin Definitions**

#### **NMI Button**

The non-maskable interrupt button header is located on pins 19 and 20 of JF1. Refer to the table on the right for pin definitions.


NMI Button Pin Definitions (JF1)	
Pin#	Definition
19	Control
20	Ground

#### **Power LED**

The Power LED connection is located on pins 15 and 16 of JF1. Refer to the table on the right for pin definitions.

Power LED Pin Definitions (JF1)	
Pin#	Definition
15	3.3V
16	PWR LED

# A. NMI B. PWR LED



#### HDD LED


The HDD LED connection is located on pins 13 and 14 of JF1. Attach a cable here to indicate HDD activity. See the table on the right for pin definitions

HDD LED Pin Definitions (JF1)	
Pin#	Definition
13	UID/3.3V Standby
14	HDD Active

#### NIC1/NIC2 LED Indicators

The NIC (Network Interface Controller) LED connection for Ethernet LAN Port 1 is located on pins 11 and 12 of JF1, and the LED connection for Ethernet LAN Port 2 is on Pins 9 and 10. Attach the NIC LED cables here to display network activity. Refer to the table on the right for pin definitions.

GLAN1/2 LED Pin Definitions (JF1)		
Pin#	Definition	
9	NIC 2 Act. LED	
10	NIC 2 Link LED	
11	NIC 1 Act. LED	
12	NIC 1 Link LED	



#### Overheat (OH)/Fan Fail/PWR Fail/ UID LED

Connect an LED cable to pins 7 and 8 of Front Control Panel to use the Overheat/Fan Fail/Power Fail and UID LED connections. The Red LED on pin 7 provides warnings of overheat, fan failure or power failure. The Blue LED on pin 8 works as the front panel UID LED indicator. The Red LED takes precedence over the Blue LED by default. Refer to the table on the right for pin definitions.

OH/Fan Fail/ PWR Fail/Blue_UID LED Pin Definitions (JF1)	
Pin# Definition	
7	Red_LED-Cathode/OH/Fan Fail/ Power Fail5.5V.SB
8	Blue_UID LED

OH/Fan Fail/PWR Fail LED Status (Red LED)			
State	Definition		
Off	Normal		
On	Overheat		
Flashing Fan Fail			


#### **Power Fail LED**

The Power Fail LED connection is located on pins 5 and 6 of JF1. Refer to the table on the right for pin definitions.

PWR Fail LED Pin Definitions (JF1)		
Pin#	Definition	
5	3.3V	
6	PWR Supply Fail	

A. OH/Fail/PWR Fail LED

B. PWR Supply Fail



#### **Reset Button**

The Reset Button connection is located on pins 3 and 4 of JF1. Attach it to a hardware reset switch on the computer case. Refer to the table on the right for pin definitions.

Reset Button Pin Definitions (JF1)	
Pin#	Definition
3	Reset
4	Ground


#### **Power Button**

The Power Button connection is located on pins 1 and 2 of JF1. Momentarily contacting both pins will power on/off the system. This button can also be configured to function as a suspend button (with a setting in the BIOS - See Chapter 5). To turn off the power when the system is in suspend mode, press the button for 4 seconds or longer. Refer to the table on the right for pin definitions.

Power Button Pin Definitions (JF1)		
Pin#	Definition	
1	Signal	
2	Ground	

A. Reset Button

B. PWR Button




# 2-7 Connecting Cables

#### **Power Connectors**

A 24-pin main power supply connector(JPWR5) and four 8-pin CPU PWR connectors (JPW2/3/4/5) are located on the motherboard. These power connectors are specially designed to support SMCI-proprietary power supplies. To avoid damaging the power supply or motherboard, be sure to use an appropriate SMCI power supply that contains a 24-pin and four 8-pin power connectors. Connect these PS connectors to the 24-pin power connector (JPWR5) and the 8-pin power connectors (JPWR1~4) on the motherboard to ensure adequate power supply to your system. Failure to do so will void the manufacturer warranty on your power supply and motherboard.

ATX Power 24-pin Connector Pin Definitions				
Pin#	Definition	Pi	in#	Definition
13	+3.3V		1	+3.3V
14	-12V		2	+3.3V
15	GND		3	GND
16	PS_ON		4	+5V
17	GND		5	GND
18	GND		6	+5V
19	GND		7	GND
20	-5V		8	PWR_OK
21	+5V		9	5VSB
22	+5V		10	+12V
23	+5V		11	+12V
24	GND		12	+3.3V

8-pin PWR Header Pin Definitions			
Pin#	Definition	Pin#	Definition
1	GND	5	+12V
2	GND	6	+12V
3	GND	7	+12V
4	GND	8	+12V



A.JPWR5: 24-pin ATX PWR (Reg'd)

B. JPWR1: 8-pin PWR (Reg'd)

C. JPWR2: 8-pin PWR (Req'd)

D. JPWR3: 8-pin PWR (Reg'd)

E. JPWR4: 8-pin PWR (Reg'd)

#### **Fan Headers**


This motherboard has eight system/CPU fan headers (Fan1~Fan4, Fan A, Fan B, Fan C and Fan D) on the motherboard. All these 4-pin fans headers are backward compatible with the traditional 3-pin fans. However, fan speed control is available for 4-pin fans only. The fan speeds are controlled by firmware thermal management via IPMI Interface. See the table on the right for pin definitions.

	Fan Header Pin Definitions
Pin#	Definition
1	Ground
2	+12V
3	Tachometer
4	Pulse Width Modulation (PWM)

#### **Chassis Intrusion**

A Chassis Intrusion header is located at JL1 on the motherboard. Attach an appropriate cable from the chassis to inform you of a chassis intrusion when the chassis is opened.

Chassis Intrusion Pin Definitions			
Pin#	Definition		
1	Intrusion Input		
2 Ground			




A. Fan 1
B. Fan 2
C. Fan 3
D. Fan 4
E. Fan A
F. Fan B
G. Fan C
H. Fan D
I. Chassis Intrusion

### Internal Speaker

The Internal Speaker, located at SP1, can be used to provide audible indications for various beep codes. See the table on the right for pin definitions. Refer to the layout below for the locations of the Internal Buzzer.

Internal Buzzer Pin Definition			
Pin#		Definitions	
Pin 1	Pos. (+)	Beep In	
Pin 2	Neg. (-) Alarm Speaker		




#### T-SGPIO1/2/3 Headers

Three SGPIO (Serial-Link General Purpose Input/Output) headers (T-SGPIO1/2/3) are located on the motherboard. These headers support Serial\_Link interface for onboard SATA connections. See the table on the right for pin definitions.

T-SGPIO Pin Definitions			
Pin#	Definition	Pin	Definition
2	NC	1	NC
4	Ground	3	Data
6	Load	5	Ground
8	Clock	7	NC

Note: NC= No Connection



A. Internal Speaker (Buzzer) B. T-SGPIO1 C. T-SGPIO2 D. T-SGPIO3

## **Standby Power Header**


The Standby Power header is located at JSTBY1 on the motherboard. See the table on the right for pin definitions.

Standby Power Pin Definitions			
Pin#	Definition		
1	+5V Standby		
2	2 Ground		
3	Wake-up		

#### **DOM Power Connector**

A power connector for SATA DOM (Disk\_On\_Module) devices is located at JSD1. Connect an appropriate cable here to provide power support for your DOM devices.

DOM PWR Pin Definitions		
Pin#	Definition	
1	+5V	
2	Ground	
3 Ground		



#### Power SMB (I2C) Connector


Power System Management Bus (I<sup>2</sup>C) Connector (JPI<sup>2</sup>C1) monitors power supply, fan and system temperatures. See the table on the right for pin definitions.

PWR SMB Pin Definitions		
Pin#	Definition	
1	Clock	
2	Data	
3	PWR Fail	
4	Ground	
5	+3.3V	

#### **IPMB** Header

A System Management Bus header for IPMI 2.0 is located at JIPMB1. Connect the appropriate cable here to use the IPMB I<sup>2</sup>C connection on your system.

IPMB Header Pin Definitions		
Pin#	Definition	
1	Data	
2	Ground	
3	Clock	
4	No Connection	




A. JPI<sup>2</sup>C1 B. JIPMB1

#### **TPM Header/Port 80**

A Trusted Platform Module/Port 80 header is located at JTPM1 to provide TPM support and Port 80 connection. Use this header to enhance system performance and data security. See the table on the right for pin definitions.

TPM/Port 80 Header Pin Definitions			
Pin#	Definition	Pin #	Definition
1	LCLK	2	GND
3	LFRAME#	4	<(KEY)>
5	LRESET#	6	+5V (X)
7	LAD 3	8	LAD 2
9	+3.3V	10	LAD1
11	LAD0	12	GND
13	SMB_CLK4	14	SMB_DAT4
15	+3V_DUAL	16	SERIRQ
17	GND	18	CLKRUN# (X)
19	LPCPD#	20	LDRQ# (X)




A. JTPM1

# 2-8 Jumper Settings

# **Explanation of Jumpers**

To modify the operation of the motherboard, jumpers can be used to choose between optional settings. Jumpers create shorts between two pins to change the function of the connector. Pin 1 is identified with a square solder pad on the printed circuit board. See the motherboard layout pages for jumper locations.






**Note:** On two pin jumpers, "Closed" means the jumper is on and "Open" means the jumper is off the pins.

#### **GLAN Enable/Disable**

Use JPL1 to enable GLAN Port1/Port2 on X9QRi-F. Use JPTG1 to enable 10G\_LAN Ports 1/2 on the X9QR7-TF/TF-JBOD . These two jumpers share the same component. See the table on the right for jumper settings. The default setting is Enabled.

Ethernet LAN 1/2 Enable Jumper Settings		
Jumper Definition		
1-2	Enabled (default)	
2-3 Disabled		



A. JPL1: GLAN1/2 Enable (X9QRi-F). B. JPTG1: 10G\_ LAN1/2 Enable (X9QR7-TF/TF-JBOD)

#### **CMOS Clear**

JBT1 is used to clear CMOS. Instead of pins, this "jumper" consists of contact pads to prevent accidental clearing of CMOS. To clear CMOS, use a metal object such as a small screwdriver to touch both pads at the same time to short the connection. Always remove the AC power cord from the system before clearing CMOS.



Note 1: For an ATX power supply, you must completely shut down the system, remove the AC power cord, and then short JBT1 to clear CMOS.


**Note 2:** Be sure to remove the onboard CMOS Battery before you short JBT1 to clear CMOS.

Note 3: Clearing CMOS will also clear all passwords.

# Watch Dog Enable/Disable

Watch Dog (JWD1) is a system monitor that will reboot the system when a software application hangs. Close Pins 1-2 to reset the system if an application hangs. Close Pins 2-3 to generate a non-maskable interrupt signal for the application that hangs. See the table on the right for jumper settings. Watch Dog must also be enabled in the BIOS.

Watch Dog Jumper Settings		
Jumper Setting Definition		
Pins 1-2	Reset (default)	
Pins 2-3	NMI	
Open	Disabled	



A. Clear
CMOS
B. Watch Dog
Enable

#### **VGA** Enable


Jumper JPG1 allows the user to enable the onboard VGA connector. The default setting is 1-2 to enable the connection. See the table on the right for jumper settings.

VGA Enable Jumper Settings		
Jumper Setting	Definition	
1-2	Enabled (Default)	
2-3	Disabled	

#### **BMC Enable**

Jumper JPB1 allows you to enable the embedded WPCM 450 BMC (Baseboard Management) Controller to provide IPMI 2.0/KVM support on the motherboard. See the table on the right for jumper settings.

BMC Enable Jumper Settings		
Jumper Setting Definition		
Pins 1-2	BMC Enable	
Pins 2-3	Normal (Default)	



A. VGA Enabled

B. BMC Enabled

#### Management Engine (ME) Recovery


Use Jumper JPME1 to select ME Firmware Recovery mode, which will limit resource allocation for essential system operation only in order to maintain normal power operation and management. In the single operation mode, online upgrade will be available via Recovery mode. See the table on the right for jumper settings.

ME Recovery Jumper Settings		
Jumper Setting Definition		
1-2	Normal (Default)	
2-3	ME Recovery	

#### Manufacturer Mode Select

Close Pin 2 and Pin 3 of Jumper JPME2 to bypass SPI flash security and force the system to operate in the Manufacturer mode, allowing the user to flash the system firmware from a host server for system setting modifications. See the table on the right for jumper settings.

ME Mode Select Jumper Settings		
Jumper Setting Definition		
1-2	Normal (Default)	
2-3	Manufacture Mode	



A. JPME1 B. JPME2

#### SAS Enable


JPS1 enables/disables L-SAS 0~3/4~7 support located at JS14/JS15; while JPS3 enables/disables L-SASA 0~3/4~7 connections located at JS1/JS2. See the table on the right for jumper settings. The default setting is enabled.

SAS Support Enable Jumper Settings		
Jumper Setting Definition		
Pins 1/2	SAS Enabled (Default)	
Pins 2/3	SAS Disabled	

### I2C Bus to PCI-Exp. Slots

Use Jumpers JI<sup>2</sup>C1 and JI<sup>2</sup>C2 to connect the System Management Bus (I<sup>2</sup>C) to PCI-Express slots to improve PCI slot performance. These two jumpers are to be set at the same time. The default setting is Closed to enable the connections. See the table on the right for jumper settings.

I <sup>2</sup> C to PCI-E slots Jumper Settings		
Jumper Setting	Definition	
Closed	Enabled (Default)	
Open	Disabled	




A. JPS1: SAS Enable for SAS 0~3. 4~7 @ JS14/JS15
B. JPS3: SAS Enable for SASa 0~3. 4~7 @ JS1/JS2
C. JI<sup>2</sup>C1
D. JI<sup>2</sup>C2

#### **TPM Enable**

Jumper JPT1 allows the user to enable the onboard TPM Chip U437 for TPM (Trusted Platform Module) support to enhance data security. See the table on the right for jumper settings.

TPM Enable Jumper Settings		
Jumper Setting	Definition	
1-2	Enabled (Default)	
2-3	Disabled	



A. TPM Enabled

### 2-9 Onboard LED Indicators

Link Speed LED





#### **GLAN LEDs**

There are two ethernet LAN ports on the motherboard. Each Ethernet LAN port has two LEDs. The Yellow LED on the right indicates connection and activity. The Link LED on the left side may be green, amber or off to indicate the speed of the connection. 10G\_LAN support is available on the X9QR7-TF/TF-JBOD only. See the tables at right for more information.

# **Rear View** (when facing the rear side of the chassis)

GLAN Activity Indicator (Right) LED Settings		
Color	Status	Definition
Off	No Connections	
Yellow	Flashing	Active

GLAN Link Speed Indicator LED Settings (Left)	
LED Color Definition	
Off	No Connection, 10 or 100 Mbps
Green	10 Gb (for X9QR7-TF/TF-JBOD only)
Amber	1 Gbps


#### **IPMI Dedicated LAN LEDs**

In addition to LAN 1/LAN 2, an IPMI Dedicated LAN is also located on the I/O Backplane of the motherboard. The amber LED on the right indicates connection and activity, while the green LED on the left indicates the speed of the connection. See the tables at right for more information

#### IPMI LAN



	IPMI LAN Link Speed LED (Left) & Connection Activity LED (Right)	
LED Color/State Definit		Definition
Off	Off	No Connection
Activity	Amber: Blinking	Active
Speed	Green	100 Mbps



# A. LAN1/2 LEDs B. IPMI LAN LEDs



#### **BMC Heartbeat LED**


A BMC Heartbeat LED is located at LEDM1 on the motherboard. When LEDM1is blinking, BMC functions normally. See the table at right for more information

	artbeat LED atus
Color/State	Definition
Green: Blinking	BMC: Normal

#### Unit Identification Switch/LED

A Unit Identifier switch (UIDB1) and a rear UID LED indicator (LED11) are located next to the VGA port on the back of the chassis. When the user pushes the rear UID switch, the front UID LED indicator and the rear UID LED (LED11) will be turned on. Push the UID switch again to turn off both UID LED indicators. The UID switch provides easy identification of a system unit that may be in need of service. See the tables on the right for more information.

UID LED (LED11) Status		
Color/State OS Status		
Blue: On	Windows OS	Unit Identified
Blue: Blinking	Linux OS	Unit Identified




A.BMC LED B. UID LED

#### **Onboard Power LED**

An Onboard Power LED is located at LED10 on the motherboard. When this LED is lit, the system is on. Be sure to turn off the system and unplug the power cord before removing or installing components. See the tables at right for more information.

On	board PWR LED State
State/Color	Definition
Off	System Off (PWR cable not connected)
Green	System Power On



A. PWR LED

#### 2-10 Serial ATA Connections

#### Serial ATA Ports


Eight Serial ATA 2.0 Ports (I-SATA2~5 from ACHI, I-SATA6~9 from SCU) and two SATA 3.0 (I-SATA0/1 from ACHI) are located on the motherboard. These ports provide serial-link signal connections, which are faster than the connections of Parallel ATA. See the table on the right for pin definitions.

SAS2	Po	rts
------	----	-----

Two sets of eight Serial\_Attached\_SCSI Ports (SAS 3.0 0~3, 4~7) are located at JS1/JS2 and JS14/JS15 on the motherboard to provide serial link connections. These ports are supported by the LSI 2308 SAS Controllers. See the table on the right for pin definitions.

Serial ATA/SAS Pin Definitions	
Pin#	Definition
1	Ground
2	TX_P
3	TX_N
4	Ground
5	RX_N
6	RX_P
7	Ground

Note: For more information on SATA or SAS RAID configuration, please refer to the Intel SATA HostRAID and LSI SAS MegaRAID User's Guides on our Website @ http://www.supermicro.com..



A. I-SATA0 (SATA 3.0)
B. I-SATA1 (SATA 3.0)
C. I-SATA2 (SATA 2.0)
D. I-SATA3 (SATA 2.0)
E. I-SATA4 (SATA 2.0)
F. I-SATA5 (SATA 2.0)
G. I-SATA6 (SATA 2.0)
H. I-SATA7 (SATA 2.0)
J. I-SATA8 (SATA 2.0)
J. I-SATA9 (SATA 2.0)
K. L-SAS 0~3 (JS1)
L. L-SAS 0~3 (JS14)
N. L-SAS 4~7 (JS15)

# **Notes**

# **Chapter 3**

# **Troubleshooting**

# 3-1 Troubleshooting Procedures

Use the following procedures to troubleshoot your system. If you have followed all of the procedures below and still need assistance, refer to the 'Technical Support Procedures' and/or 'Returning Merchandise for Service' section(s) in this chapter. Note: Always disconnect the power cord before adding, changing or installing any hardware components.

#### **Before Power On**

- Make sure that there are no short circuits between the motherboard and chassis
- Disconnect all ribbon/wire cables from the motherboard, including those for the keyboard and mouse.
- 3. Remove all add-on cards.
- Install CPU 1 first (making sure it is fully seated) and connect the front panel connectors to the motherboard

#### No Power

- Make sure that there are no short circuits between the motherboard and the chassis.
- 2. Make sure that the ATX power connectors are properly connected
- Check that the 115V/230V switch on the power supply is properly set, if available.
- 4. Turn the power switch on and off to test the system, if applicable.
- The battery on your motherboard may be old. Check to verify that it still supplies ~3VDC. If it does not, replace it with a new one.

#### No Video

- If the power is on, but you have no video, remove all the add-on cards and cables.
- Use the speaker to determine if any beep codes exist. Refer to Appendix A for details on beep codes.

## **System Boot Failure**

If the system does not display POST or does not respond after the power is turned on, check the following:

- 1. Check for any error beep from the motherboard speaker.
- If there is no error beep, try to turn on the system without DIMM modules installed. If there is still no error beep, try to turn on the system again with only one processor installed in CPU Socket#1. If there is still no error beep, replace the motherboard
- If there are error beeps, clear the CMOS settings by unplugging the power cord and contracting both pads on the CMOS Clear Jumper]. (Refer to Section 2-8 in Chapter 2.)
- Remove all components from the motherboard, especially the DIMM modules. Make sure that the system's power is on, and memory error beeps are activated
- Turn on the system with only one DIMM module installed. If the system boots, check for bad DIMM modules or slots by following the Memory Errors Troubleshooting procedure in this Chapter.

# Losing the System's Setup Configuration

- Make sure that you are using a high quality power supply. A poor quality power supply may cause the system to lose the CMOS setup information. Refer to Section 2-7 for details on recommended power supplies.
- 2. The battery on your motherboard may be old. Check to verify that it still supplies ~3VDC. If it does not, replace it with a new one.
- If the above steps do not fix the Setup Configuration problem, contact your vendor for repairs.

# **Memory Errors**

When a No-Memory Beep Code is issued by the system, check the following:

- Make sure that the memory modules are compatible with the system and that the DIMM modules are properly and fully installed. (For memory compatibility, refer to the Memory Compatibility Chart posted on our Website @ http://www. supermicro.com.)
- Check if different speeds of DIMMs have been installed. It is strongly recommended that you use the same RAM speed for all DIMMs in the system.
- Make sure that you are using Registered (RDIMM)/Load Reduced (LRDIMM) ECC or Unbuffered (UDIMM) ECC-Non ECC DDR3 modules as recommended by the manufacturer.
- Check for bad DIMM modules or slots by swapping a single module among all memory slots and check the results.
- Make sure that all memory modules are fully seated in their slots. Follow the instructions given in Section 2-4 in Chapter 2.
- Please follow the instructions given in the DIMM Population Tables listed in Section 2-4 to install your memory modules.

# When the System Becomes Unstable

# A. The system becomes unstable during or after the OS installation

The system becomes unstable during or after the OS installation, check the following:

- CPU/BIOS support: Make sure that your CPU is supported, and you have the latest BIOS installed in your system.
- Memory support: Make sure that the memory modules are supported by testing the modules using memtest86 or a similar utility.
  - **Note**: Refer to the product page on our website http://www.supermicro.com for memory and CPU support and updates.
- HDD support: Make sure that all hard disk drives (HDDs) work properly. Replace the bad HDDs with good ones.

- 4. System cooling: Check system cooling to make sure that all heatsink fans, and CPU/system fans, etc., work properly. Check Hardware Monitoring settings in the BIOS to make sure that the CPU and System temperatures are within the normal range. Also check the front panel Overheat LED, and make sure that the Overheat LED is not on.
- Adequate power supply: Make sure that the power supply provides adequate power to the system. Make sure that all power connectors are connected. Please refer to our website for more information on minimum power requirement
- 6. Proper software support: Make sure that the correct drivers are used.

# B. The system becomes unstable before or during the OS installation

When the system becomes unstable before or during OS installation, check the following:

- Source of installation: Make sure that the devices used for installation are working properly, including boot devices such as CD/DVD disc, CD/DVD-ROM
- Cable connection: Check to make sure that all cables are connected and working properly.
- 3. Using minimum configuration for troubleshooting: Remove all unnecessary components (starting with add-on cards first), and use minimum configuration (with a CPU and a memory module installed) to identify the trouble areas. Refer to the steps listed in Section A above for proper troubleshooting procedures
- 4. Identifying bad components by isolating them: If necessary, remove a component in question from the chassis, and test it in isolation to make sure that it works properly. Replace a bad component with a good one.
- Check and change one component at a time instead of changing several items at the same time. This will help isolate and identify the problem.
- 6. To find out if a component is good, swap this component with a new one to see if the system will work properly. If so, then the old component is bad. You can also install the component in question in another system. If the new system works, the component is good and the old system has problems.

# 3-2 Technical Support Procedures

Before contacting Technical Support, please take the following steps. Also, please note that as a motherboard manufacturer, Supermicro also sells motherboards through its channels, so it is best to first check with your distributor or reseller for troubleshooting services. They should know of any possible problem(s) with the specific system configuration that was sold to you.

- Please go through the 'Troubleshooting Procedures' and 'Frequently Asked Question' (FAQ) sections in this chapter or see the FAQs on our website (<a href="http://www.supermicro.com/">http://www.supermicro.com/</a>) before contacting Technical Support.
- BIOS upgrades can be downloaded from our website (<a href="http://www.supermicro.com">http://www.supermicro.com</a>).
- 3. If you still cannot resolve the problem, include the following information when contacting Supermicro for technical support:
- Motherboard model and PCB revision number
- BIOS release date/version (This can be seen on the initial display when your system first boots up.)
- System configuration
- An example of a Technical Support form is on our website at (<a href="http://www.supermicro.com/RmaForm/">http://www.supermicro.com/RmaForm/</a>).
- Distributors: For immediate assistance, please have your account number ready
  when placing a call to our technical support department. We can be reached by
  e-mail at support@supermicro.com.

# 3-3 Battery Removal and Installation

# **Battery Removal**

To remove the onboard battery, follow the steps below:

- 1. Power off your system and unplug your power cable.
- 2. Locate the onboard battery as shown below.
- Using a tool such as a pen or a small screwdriver, push the battery lock outwards to unlock it. Once unlocked, the battery will pop out from the holder.
- 4. Remove the battery.


# **Proper Battery Disposal**

**Warning:** Please handle used batteries carefully. Do not damage the battery in any way; a damaged battery may release hazardous materials into the environment. Do not discard a used battery in the garbage or a public landfill. Please comply with the regulations set up by your local hazardous waste management agency to dispose of your used battery properly.

# **Battery Installation**

- To install an onboard battery, follow the steps 1& 2 above and continue below:
- 2. Identify the battery's polarity. The positive (+) side should be facing up.
- Insert the battery into the battery holder and push it down until you hear a click to ensure that the battery is securely locked.

**Warning:** When replacing a battery, be sure to only replace it with the same type.



# 3-4 Frequently Asked Questions

Question: What are the various types of memory that my motherboard can support?

**Answer:** The motherboard supports Registered/Load Reduced ECC or Unbuffered ECC/Non-ECC DDR3 DIMM modules. To enhance memory performance, do not mix memory modules of different speeds and sizes. Please follow all memory installation instructions given on Section 2-4 in Chapter 2.

Question: How do I update my BIOS?

It is recommended that you <u>do not</u> upgrade your BIOS if you are not experiencing any problems with your system. Updated BIOS files are located on our website at <a href="http://www.supermicro.com">http://www.supermicro.com</a>. Please check our BIOS warning message and the information on how to update your BIOS on our website. Select your motherboard model and download the BIOS file to your computer. Also, check the current BIOS revision to make sure that it is newer than your BIOS before downloading. You can choose from the zip file and the .exe file. If you choose the zip BIOS file, please unzip the BIOS file onto a bootable USB device. Run the batch file using the format AMI.bat filename.rom from your bootable USB device to flash the BIOS. Then, your system will automatically reboot.

**Warning**: Do not shut down or reset the system while updating the BIOS to prevent possible system boot failure!)



**Note**: The SPI BIOS chip used on this motherboard cannot be removed. Send your motherboard back to our RMA Department at Supermicro for repair. For BIOS Recovery instructions, please refer to the AMI BIOS Recovery Instructions posted at http://www.supermicro.com.

Question: How do I handle the used battery?

**Answer:** Please handle used batteries carefully. Do not damage the battery in any way; a damaged battery may release hazardous materials into the environment. Do not discard a used battery in the garbage or a public landfill. Please comply with the regulations set up by your local hazardous waste management agency to dispose of your used battery properly. Refer to Section 3-3 on Page 3-6.

# 3-5 Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning the motherboard to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton, and the shipping package is mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete. For faster service, You can also request a RMA authorization online (http://www.supermicro.com).

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alternation, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

# Chapter 4

# **BIOS**

# 4-1 Introduction

This chapter describes the AMI BIOS Setup utility for the X9QRi-F/X9QR7-TF/ X9QR7-TF-JBOD. It also provides the instructions on how to navigate the AMI BIOS Setup utility screens. The AMI ROM BIOS is stored in a Flash EEPROM and can be easily updated.

# Starting BIOS Setup Utility

To enter the AMI BIOS Setup utility screens, press the <Del> key while the system is booting up.

Note: In most cases, the <Del> key is used to invoke the AMI BIOS setup screen. There are a few cases when other keys are used, such as <F3>, <F4>, etc.

Each main BIOS menu option is described in this manual. The Main BIOS setup menu screen has two main frames. The left frame displays all the options that can be configured. Grayed-out options cannot be configured. Options in blue can be configured by the user. The right frame displays the key legend. Above the key legend is an area reserved for informational text. When an option is selected in the left frame, it is highlighted in white. Often, informational text about the option will display on the right.

Note: The AMI BIOS has default informational messages built in. The manufacturer retains the option to include, omit, or change any of these messages.

The AMI BIOS Setup utility uses a key-based navigation system called "hot keys." Most of the AMI BIOS setup utility "hot keys" can be used at any time during setup navigation. These keys include <F3>, <F4>, <Enter>, <ESC>, arrow keys, etc.

Note 1: In this section, options printed in Bold are default settings.

**Note 2**: <F3> is used to load optimal default settings. <F4> is used to save the settings and exit the setup utility.

# **How To Change the Configuration Data**

The configuration data that determines the system parameters may be changed by entering the AMI BIOS Setup utility. This Setup utility can be accessed by pressing <Delete> at the appropriate time during system boot.



**Note**: For AMI UEFI BIOS Recovery, please refer to the UEFI BIOS Recovery User Guide posted @http://www.supermicro.com/support/manuals/.

# Starting the Setup Utility

Normally, the only visible Power-On Self-Test (POST) routine is the memory test. As the memory is being tested, press the <Delete> key to enter the main menu of the AMI BIOS Setup utility. From the main menu, you can access the other setup screens. An AMI BIOS identification string is displayed at the left bottom corner of the screen below the copyright message.

**Warning:** Do not upgrade the BIOS unless your system has a BIOS-related issue. Flashing the wrong BIOS can cause irreparable damage to the system. In no event shall the manufacturer be liable for direct, indirect, special, incidental, or consequential damage arising from a BIOS update. If you have to update the BIOS, do not shut down or reset the system while the BIOS is being updated to avoid possible boot failure.

# 4-2 Main Setup

When you first enter the AMI BIOS Setup utility, you will enter the Main setup screen. You can always return to the Main setup screen by selecting the Main tab on the top of the screen. The Main BIOS Setup screen is shown below.

The AMI BIOS main menu displays the following information:



# System Date

This item displays the system date in Day MM/DD/YY format (e.g. Wed 10/12/2012).

# System Time

This item displays the system time in HH:MM:SS format (e.g. 15:32:52).

# Supermicro X9QR7-TF

#### Version

This item displays the SMC version of the BIOS ROM used in this system.

#### **Build Date**

This item displays the date that the BIOS ROM was built.

# **Memory Information**

# **Total Memory**

This displays the amount of memory that is available in the system.

# 4-3 Advanced Setup Configurations

Use the arrow keys to select Advanced Setup and press <Enter> to access the following submenu items.



# **▶**Boot Features

# Quiet Boot

This feature allows the user to select bootup screen display between POST messages and the OEM logo. Select Disabled to display the POST messages. Select Enabled to display the OEM logo instead of the normal POST messages. The options are **Enabled** and Disabled.

#### AddOn ROM Display Mode

Use this item to set the display mode for the Option ROM. Select Keep Current to use the current AddOn ROM Display setting. Select Force BIOS to use the Option ROM display mode set by the system BIOS. The options are **Force BIOS** and Keep Current.

#### **Bootup Num-Lock**

Use this feature to set the Power-on state for the Numlock key. The options are Off and **On**.

#### Wait For 'F1' If Error

Select Enabled to force the system to wait until the 'F1' key is pressed if an error occurs. The options are Disabled and **Enabled**.

# **Interrupt 19 Capture**

Interrupt 19 is the software interrupt that handles the boot disk function. When this item is set to Immediate, the ROM BIOS of the host adaptors will immediately "capture" Interrupt 19 at bootup and allow the drives that are attached to these host adaptors to function as bootable disks. If this item is set to Postponed, the ROM BIOS of the host adaptors will capture Interrupt 19 during a legacy boot. The options are **Immediate** and Postponed.

# **Power Configuration**

## Watch Dog Function

If enabled, the Watch Dog timer will allow the system to automatically reboot when a non-recoverable error occurs that lasts for more than five minutes. The options are Enabled and **Disabled**.

#### **Power Button Function**

If this feature is set to Instant Off, the system will power off immediately as soon as the user presses the power button. If this feature is set to 4 Seconds Override, the system will power off when the user presses the power button for 4 seconds or longer. The options are **Instant Off** and 4 Seconds Override.

#### Restore on AC Power Loss

Use this feature to set the power state after a power outage. Select Stay Off for the system power to remain off after a power loss. Select Power On for the system power to be turned on after a power loss. Select Last State to allow the system to resume its last state before a power loss. The options are Power On, Stay Off, and Last State

# **CPU Configuration**

This submenu displays the information of the CPU as detected by the BIOS. It also allows the user to configure CPU settings.

# ► Socket 1 CPU Information/Socket 2 CPU Information/ Socket 3 CPU Information/ Socket 4 CPU Information

This submenu displays the following information regarding the CPUs installed in Socket 1, Socket 2, Socket 3, and Socket 4.

- Type of CPU
- CPU Signature

- Microcode Patch
- CPU Stepping
- Maximum CPU Speed
- Minimum CPU Speed
- Processor Cores
- Intel HT (Hyper-Threading) Technology
- Intel VT-x Technology
- Intel SMX Technology
- I 1 Data Cache
- L1 Code Cache
- L2 Cache
- L3 Cache

#### **CPU Speed**

This item displays the speed of the CPU installed in the Socket selected.

#### 64-bit

This item indicates if 64-bit technology is supported by the CPU installed in the Socket selected.

# **Clock Spread Spectrum**

Select Enable to enable Clock Spectrum support, which will allow the BIOS to monitor and attempt to reduce the level of Electromagnetic Interference caused by the components whenever needed. The options are **Disabled** and Enabled.

# RTID (Record Types IDs)

This feature displays the total number of Record Type IDs for local and remote pools. The options are **Optimal** and Alternate.

#### Hyper-threading

Select Enabled to support Intel Hyper-threading Technology to enhance CPU performance. The options are **Enabled** and Disabled.

#### **Active Processor Cores**

Set to Enabled to use a processor's second core and above. (Please refer to Intel's website for more information.) The options are **All,** 1, 2, and 4.

#### Limit CPUID Maximum

This feature allows the user to set the maximum CPU ID value. Enable this function to boot the legacy operating systems that cannot support processors with extended CPUID functions. The options are Enabled and **Disabled** (for the Windows OS).

# Execute-Disable Bit (Available if supported by the OS & the CPU)

Select Enabled to enable the Execute Disable Bit which will allow the processor to designate areas in the system memory where an application code can execute and where it cannot, thus preventing a worm or a virus from flooding illegal codes to overwhelm the processor or damage the system during an attack. The default is **Enabled**. (Refer to Intel and Microsoft Web sites for more information.)

#### Intel® AES-NI

Select Enable to use the Intel Advanced Encryption Standard (AES) New Instructions (NI) to ensure data security. The options are **Enabled** and Disabled.

# MLC Streamer Prefetcher (Available when supported by the CPU)

If set to Enabled, the MLC (mid-level cache) streamer prefetcher will prefetch streams of data and instructions from the main memory to the L2 cache to improve CPU performance. The options are Disabled and **Enabled**.

#### MLC Spatial Prefetcher (Available when supported by the CPU)

If this feature is set to Disabled, The CPU prefetches the cache line for 64 bytes. If this feature is set to Enabled the CPU fetches both cache lines for 128 bytes as comprised. The options are Disabled and **Enabled**.

# DCU Streamer Prefetcher (Available when supported by the CPU)

Select Enabled to support Data Cache Unit (DCU) prefetch of L1 data to speed up data accessing and processing in the DCU to enhance CPU performance. The options are Disabled and **Enabled**.

# **DCU IP Prefetcher**

Select Enabled for DCU (Data Cache Unit) IP Prefetcher support, which will prefetch IP addresses to improve network connectivity and system performance. The options are **Enabled** and Disabled.

## Intel® Virtualization Technology (Available when supported by the CPU)

Select Enabled to support Intel Virtualization Technology, which will allow one platform to run multiple operating systems and applications in independent partitions, creating multiple "virtual" systems in one physical computer. The options are **Enabled** and Disabled.



Note: If there is any change to this setting, you will need to power off and restart the system for the change to take effect. Please refer to Intel's website for detailed information.)

# **▶** CPU Power Management Configuration

This submenu allows the user to configure the following CPU Power Management settings.

## **Power Technology**

Select Energy Efficiency to support power-saving mode. Select Custom to customize system power settings. Select Disabled to disable power-saving settings. The options are Disabled, **Energy Efficient**, and Custom. If the option is set to Custom, the following items will display:

## EIST (Available when Power Technology is set to Custom)

EIST (Enhanced Intel SpeedStep Technology) allows the system to automatically adjust processor voltage and core frequency to reduce power consumption and heat dissipation. The options are Disabled (GV3 Disabled), and **Enabled (GV3 Enabled)**. (**Note**: GV3 is Intel Speedstep support used on older platforms. Please refer to Intel's website for detailed information.)

#### Turbo Mode

This feature allows processor cores to run faster than marked frequency in specific conditions. The options are Disabled and **Enabled.** 

# C1E Support (Available when Power Technology is set to Custom)

Select Enabled to enable Enhanced C1 Power State to boost system performance. The options are **Enabled** and Disabled.

# CPU C3 Report (Available when Power Technology is set to Custom)

Select Enabled to allow the BIOS to report the CPU C3 State (ACPI C2) to the operating system. During the CPU C3 State, the CPU clock generator is turned off. The options are Enabled and **Disabled.** 

# CPU C6 Report (Available when Power Technology is set to Custom)

Select Enabled to allow the BIOS to report the CPU C6 State (ACPI C3) to the operating system. During the CPU C6 State, the power to all cache is turned off. The options are **Enabled** and Disabled.

#### CPU C7 Report (Available when Power Technology is set to Custom)

Select Enabled to allow the BIOS to report the CPU C7 State (ACPI C3) to the operating system. CPU C7 State is a processor-specific low C-State. The options are **Enabled** and Disabled.

# Package C-State limit (Available when Power Technology is set to Custom)

This feature allows the user to set the limit on the C-State package register. The options are C0, C2, **C6**, and No Limit.

## **Energy Performance Bias**

Use this feature to select an appropriate fan setting to achieve maximum system performance (with maximum cooling) or maximum energy efficiency with maximum power saving). The fan speeds are controlled by the firmware management via IPMI 2.0. The options are Performance, **Balanced Performance**, Balanced Energy, and Energy Efficient.

# **Factory Long Duration Power Limit**

This item displays the power limit (in watts) set by the manufacturer during which long duration power is maintained.

#### Long Duration Power Limit

This item displays the power limit (in watts) set by the user during which long duration power is maintained. The default setting is **0**.

#### **Factory Long Duration Maintained**

This item displays the period of time (in seconds) set by the manufacturer during which long duration power is maintained.

# Long Duration Maintained

This item displays the period of time (in seconds) during which long duration power is maintained. The default setting is **0**.

#### Recommended Short Duration Power Limit

This item displays the short duration power settings (in watts) recommended by the manufacturer.

# **Short Duration Power Limit**

This item displays the time period during which short duration power (in watts) is maintained. The default setting is **0**.

# **▶**Chipset Configuration

# ► North Bridge

This feature allows the user to configure the settings for the Intel North Bridge.

# ►Integrated IO Configuration

#### Intel VT-d

Select Enabled to enable Intel Virtualization Technology support for Direct I/O VT-d by reporting the I/O device assignments to the VMM (Virtual Machine Monitor) through the DMAR ACPI Tables. This feature offers fully-protected I/O resource sharing across Intel platforms, providing greater reliability, security and availability in networking and data-sharing. The options are **Enabled** and Disabled

#### Data Direct I/O

Select Enabled to enable Intel I/OAT (I/O Acceleration Technology), which significantly reduces CPU overhead by leveraging CPU architectural improvements and freeing the system resource for other tasks. The options are Disabled and **Enabled** 

# **DCA Support**

When set to Enabled, this feature uses Intel's DCA (Direct Cache Access) Technology to improve data transfer efficiency. The default is **Enabled** and can not be changed.

#### **IOH Resource Selection Type**

When set to Default, PCI resource allocation across multiple IOHs is optomized automatically based on the PCI device present. When set to Manual, the user can force the PCI resource allocation across multiple IOHs based on the ratios selected. The options are **Default** and Manual.

#### CPU2 Slot8 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU2 and the PCI-e port. The options are x4, and x8, and x16.

# CPU2 Slot8 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 8. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 8. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 8. The options are GEN1, GEN2, and **GEN3**.

#### CPU2 Slot7 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU2 and the PCI-e port. The options are x4, x8, and x16.

## CPU2 Slot7 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 7. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 7. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 7. The options are GEN1, GEN2, and **GEN3**.

#### CPU1 Slot2 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU1 and the PCI-e port. The options are x4, and x8, and x16.

# CPU1 Slot2 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 2. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 2. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 2. The options are GEN1, GEN2, and **GEN3**.

#### CPU1 Slot1 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU1 and the PCI-e port. The options are x4, and x8.

# CPU1 Slot1 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 1. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 1. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 1. The options are GEN1, GEN2, and **GEN3**.

#### CPU3 Slot6 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU2 and the PCI-e port. The options are x4, x8, and x16.

#### CPU3 Slot6 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 7. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 7. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 7. The options are GEN1, GEN2, and **GEN3**.

# CPU3 Slot5 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU2 and the PCI-e port. The options are x4, x8, and x16.

# CPU3 Slot5 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 7. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 7. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 7. The options are GEN1, GEN2, and **GEN3**.

#### CPU4 Slot4 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU2 and the PCI-e port. The options are x4, x8, and x16.

# CPU4 Slot4 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 7. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 7. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 7. The options are GEN1, GEN2, and **GEN3**.

#### CPU4 Slot3 PCI-E Link Width

This feature allows the user to set the PCI-Exp bus speed between CPU2 and the PCI-e port. The options are x4, x8, and x16.

# CPU4 Slot3 PCI-E Link Speed

Select GEN1 to enable PCI-Exp Generation 1 support for Slot 7. Select GEN2 to enable PCI-Exp Generation 2 support for Slot 7. Select GEN3 to enable PCI-Exp Generation 3 support for Slot 7. The options are GEN1, GEN2, and **GEN3**.

# **▶**QPI Configuration

#### **Current QPI Link**

This item displays the current status of the QPI Link.

## Current QPI Frequency

This item displays the frequency of the QPI Link.

#### Isoc

Select Enabled to enable Isochronous support to meet QoS (Quality of Service) requirements. This feature is especially important for virtualization technology. The options are Enabled and **Disabled**.

## QPI (Quick Path Interconnect) Link Speed Mode

Use this feature to select data transfer speed for QPI Link connections. The options are **Fast** and Slow.

## **QPI Link Frequency Select**

Use this feature to select the desired QPI frequency. The options are **Auto**, 6.4 GT/s, 7.2 GT/s, 8.0 GT/s, and 16.0 GT/s.

# **▶**DIMM Configuration

This section displays the following DIMM information.

# **Current Memory Mode**

This item displays the current memory mode.

### **Current Memory Speed**

This item displays the current memory speed.

## Mirroring

This item displays if memory mirroring is supported by the motherboard. Memory mirroring creates a duplicate copy of the data stored in the memory to enhance data security.

### Sparing

This item displays if memory sparing is supported by the motherboard. Memory sparing enhances system performance.

## **▶** DIMM Information

This section displays the status of the memory modules as detected by the BIOS.

# **Memory Mode**

When Independent is selected, all DIMMs are available to the operating system. When Mirroring is selected, the motherboard maintains two identical copies of all data in memory for data backup. When Lockstep is selected, the motherboard uses two areas of memory to run the same set of operations in parallel. The default setting is **Independent**.

# **DRAM RAPL Mode**

RAPL (Running Average Power Limit) provides mechanisms to enforce power consumption limits on supported processors The options are DRAM RAPL MODE0, DRAM RAPL MODE1, and Disabled.

## **DDR Speed**

Use this feature to force a DDR3 memory module to run at a frequency other than what is specified by the manufacturer. The options are **Auto**, Force DDR3-800, Force DDR3-1066, Force DDR3-1333, Force DDR3-1600 and Force SPD.

# Channel Interleaving

This feature selects from the different channel interleaving methods. The options are **Auto**, 1 Way, 2 Way, 3, Way, and 4 Way.

# Rank Interleaving

This feature allows the user to select a rank memory interleaving method. The options are **Auto**, 1 Way, 2 Way, 4, Way, and 8 Way.

#### **Patrol Scrub**

Patrol Scrubbing is a process that allows the CPU to correct correctable memory errors detected on a memory module and send the correction to the requestor (the original source). When this item is set to Enabled, the IO hub will read and write back one cache line every 16K cycles, if there is no delay caused by internal processing. By using this method, roughly 64 GB of memory behind the IO hub will be scrubbed every day. The options are **Enabled** and Disabled.

#### **Demand Scrub**

Demand Scrubbing is a process that allows the CPU to correct correctable memory errors found on a memory module. When the CPU or I/O issues a demand-read command, and the read data from memory turns out to be a correctable error, the error is corrected and sent to the requestor (the original source). Memory is updated as well. Select Enabled to use Demand Scrubbing for ECC memory correction. The options are Enabled and **Disabled**.

#### **Data Scrambling**

Select Enabled to enable data scrambling to ensure data security and integrity. The options are Disabled and **Enabled**.

#### **Device Tagging**

Select Enabled to support device tagging. The options are **Disabled** and Enabled.

### Thermal Throttling

Throttling improves reliability and reduces power consumption in the processor via automatic voltage control during processor idle states. The options are Disabled and **CLTT** (Closed Loop Thermal Throttling).

# **▶** South Bridge Configuration

This feature allows the user to configure the settings for the Intel PCH chip.

#### **PCH Information**

This feature displays the following PCH information.

Name: This item displays the name of the PCH chip.

Stepping: This item displays the PCH stepping.

**USB Devices**: This item displays the USB devices detected by the BIOS.

#### **All USB Devices**

This feature enables all USB ports/devices. The options are Disabled and Enabled.

# EHCI Controller 1, EHCI Controller 2 (Available when All USB Devices is set to Enabled)

Select Enabled to enable EHCI (Enhanced Host Controller Interface) Controller 1 or Controller 2. The options are Disabled and **Enabled**.

## Legacy USB Support (Available when USB Functions is not Disabled)

Select Enabled to support legacy USB devices. Select Auto to disable legacy support if USB devices are not present. Select Disabled to have USB devices available for EFI (Extensive Firmware Interface) applications only. The settings are Disabled, **Enabled** and Auto

#### Port 60/64 Emulation

Select Enabled to enable I/O port 60h/64h emulation support for the legacy USB keyboard so that it can be fully supported by the operating systems that does not recognize a USB device. The options are Disabled and **Enabled**.

#### **EHCI Hand-Off**

This item is for operating systems that do not support Enhanced Host Controller Interface (EHCI) hand-off. When enabled, EHCI ownership change will be claimed by the EHCI driver. The options are **Disabled** and Enabled.

# **▶**SATA Configuration

When this submenu is selected, the AMI BIOS automatically detects the presence of IDE or SATA devices and displays the following items.

**SATA Port0~SATA Port9**: The AMI BIOS displays the status of each SATA port as detected by the BIOS.

#### **SATA Mode**

Use this feature to configure SATA mode for a selected SATA port. The options are Disabled, IDE Mode, **AHCI Mode** and RAID Mode. The following are displayed depending on your selection:

#### **IDE Mode**

The following items are displayed when IDE Mode is selected:

## Serial-ATA (SATA) Controller 0~1

Use this feature to activate or deactivate the SATA controller, and set the compatibility mode. The options are Disabled, Enhanced, and Compatible. The default for SATA Controller 0 is **Compatible**. The default of SATA Controller 1 is **Enhanced**.

#### **AHCI Mode**

The following items are displayed when the AHCI Mode is selected.

# **Aggressive Link Power Management**

When Enabled, the SATA AHCI controller manages the power usage of the SATA link. The controller will put the link in a low power mode during extended periods of I/O inactivity, and will return the link to an active state when I/O activity resumes. The options are **Enabled** and Disabled.

#### Port 0~9 Hot Plua

Select Enabled to enable hot-plug support for a particular port, which will allow the user to change a hardware component or device without shutting down the system. The options are **Enabled** and Disabled.

# Staggered Spin Up

Select Enabled to enable Staggered Spin-up support to prevent excessive power consumption caused by multiple HDDs spinning-up simultaneously. The options are Enabled and **Disabled**.

#### **RAID Mode**

The following items are displayed when RAID Mode is selected:

#### Port 0~9 Hot Plug

Select Enabled to enable hot-plug support for the particular port. The options are **Enabled** and Disabled.

# ►SCU (Storage Control Unit) Configuration

# Storage Controller Unit

Select Enabled to enable PCH SCU storage devices. The options are Disabled and **Enabled**.

# **OnChip SCU Option ROM**

Select Enabled to support the onboard SCU Option ROM to boot up the system via a storage device. The options are Disabled, **Legacy Option ROM**, and EFI Driver.

# ▶PCle/PCl/PnP Configuration

# **PCI ROM Priority**

Use this feature to select the Option ROM to boot the system when there are multiple Option ROMs available in the system. The options are EFI Compatible ROM and Legacy ROM.

# **PCI Latency Timer**

Use this feature to set the latency Timer of each PCI device installed on a PCI bus. Select 64 to set the PCI latency to 64 PCI clock cycles. The options are 32, **64**, 96, 128, 160, 192, 224 and 248.

# Above 4G Decoding (Available if the system supports 64-bit PCI decoding)

Select Enabled to decode a PCI device that supports 64-bit in the space above 4G Address. The options are Enabled and **Disabled**.

#### **PERR#** Generation

Select Enabled to allow a PCI device to generate a PERR number for a PCI Bus Signal Error Event. The options are Enabled and **Disabled**.

#### **SERR#** Generation

Select Enabled to allow a PCI device to generate an SERR number for a PCI Bus Signal Error Event. The options are Enabled and **Disabled**.

# **Maximum Payload**

Select Auto to allow the system BIOS to automatically set the maximum payload value for a PCI-E device to enhance system performance. The options are **Auto**, 128 Bytes and 256 Bytes, 512 Bytes, 1024 Bytes, 2048 Bytes, and 4096 Bytes.

## Maximum Read Request

Select Auto to allow the system BIOS to automatically set the maximum Read Request size for a PCI-E device to enhance system performance. The options are **Auto**, 128 Bytes, 256 Bytes, 512 Bytes, 1024 Bytes, 2048 Bytes, and 4096 Bytes.

## **ASPM Support**

This feature allows the user to set the Active State Power Management (ASPM) level for a PCI-E device. Select Force L0s to force all PCI-E links to operate at L0s state. Select Auto to allow the system BIOS to automatically set the ASPM level for the system. Select Disabled to disable ASPM support. The options are **Disabled**, Force L0s, and Auto.

Warning: Enabling ASPM support may cause some PCI-E devices to fail!

CPU1 Slot1 PCI-E 3.0 x8 OPROM, CPU1 Slot2 PCI-E 3.0 x16 OPROM, CPU4 Slot3 PCI-E 3.0 x16 OPROM, CPU4 Slot4 PCI-E 3.0 x16 OPROM, CPU3 Slot5 PCI-E 3.0 x16 OPROM, CPU3 Slot6 PCI-E 3.0 x16 OPROM, CPU2 Slot7 PCI-E 3.0 x16 OPROM, CPU2 Slot8 PCI-E 3.0 x16 OPROM

Select Enabled to enable Option ROM support to boot the computer using a device installed on the slot specified above. The options are **Enabled** and Disabled.

# **Onboard LAN Option ROM Select**

Select iSCSI to use the iSCSI Option ROM to boot the computer using a network device. Select PXE (Preboot Execution Environment) to use an PXE Option ROM to boot the computer using a network device. The options are **PXE** and iSCSI.

#### Load Onboard LAN1 OPROM, Load Onboard LAN2 OPROM

Select Enabled to enable the onboard LAN1/LAN2 Option ROM. This is to boot the computer using a network device. The default setting for LAN1 Option ROM is **Enabled**, and the default setting for LAN2 Option ROM is **Disabled**.

# Load Onboard LSI SAS (CPU1) OPROM, Load Onboard LSI SAS (CPU2) OPROM

Select Enabled to enable the onboard LSI SAS Option ROM. This is to boot the computer using a SAS device. The default setting for LSI SAS Option ROM is **Enabled** 

#### **VGA Priority**

This feature allows the user to select the graphics adapter to be used as the primary boot device. The options are **Onboard**, and Offboard.

#### **Network Stack**

Select Enabled enable PXE (Preboot Execution Environment) or UEFI (Unified Extensible Firmware Interface) for network stack support. The options are Enabled and **Disabled**.

### IPv4 PXE Support (Available when Network Stack is set to Enabled)

Set this item to Enabled to activate IPv4 PXE Support. The options are **Enabled** and Disabled

#### IPv6 PXE Support (Available when Network Stack is set to Enabled)

Set this item to Enabled to activate IPv6 PXE Support. The options are Enabled and **Disabled** 

# ► Super IO Configuration

Super IO Chip: This item displays the Super IO chip used in the motherboard.

# ► Serial Port 1 Configuration

#### Serial Port

Select Enabled to enable a serial port specified by the user. The options are **Enabled** and Disabled.

# **Device Settings**

This item displays the settings of Serial Port 1.

#### **Change Settings**

This option specifies the base I/O port address and the Interrupt Request address of Serial Port 1. Select Disabled to prevent the serial port from accessing any system resources. When this option is set to Disabled, the serial port becomes unavailable. The options are **Auto**, IO=3F8h; IRQ=4; IO=3F8h; IRQ=3; IO=2F8h; IRQ=3; IO=2E8h; IRQ=5; IO=2E8h; IRQ=7; IO=3F8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12; IO=2F8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12; IO=3E8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12; and IO=2E8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12;

#### **Device Mode**

Use this feature to select the desired mode for a serial port specified. The options are **Normal** and High Speed.

# ► Serial Port 2 Configuration

#### **Serial Port**

Select Enabled to enable a serial port specified by the user. The options are **Enabled** and Disabled.

#### **Device Settings**

This item displays the settings of Serial Port 2.

#### **Change Settings**

This option specifies the base I/O port address and the Interrupt Request address of Serial Port 2. Select Disabled to prevent the serial port from accessing any system resources. When this option is set to Disabled, the serial port becomes unavailable. The options are **Auto**, IO=3F8h; IRQ=4; IO=3F8h; IRQ=3; IO=2F8h; IRQ=3; IO=2E8h; IRQ=5; IO=2E8h; IRQ=7; IO=3F8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12; IO=2F8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12; IO=3E8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12; and IO=2E8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12;

#### **Device Mode**

Use this feature to select the desired mode for a serial port specified. The options are **Normal** and High Speed.

## Serial Port 2 Attribute

Use this feature to select the attribute for serial port 2. The options are **SOL** (Serial On LAN), and COM.

# ► Serial Port Console Redirection

## COM 1, SOL

These two submenus allow the user to configure the following Console Redirection settings for a COM Port specified by the user.

#### Console Redirection

Select Enabled to use a COM Port selected by the user for Console Redirection. The options are Enabled and Disabled. The default setting for COM1 is **Disabled**, and for SOL is **Enabled**.

# ► Console Redirection Settings

This feature allows the user to specify how the host computer will exchange data with the client computer, which is the remote computer used by the user.

# **Terminal Type**

This feature allows the user to select the target terminal emulation type for Console Redirection. Select VT100 to use the ASCII Character set. Select VT100+ to add color and function key support. Select ANSI to use the Extended ASCII Character Set. Select VT-UTF8 to use UTF8 encoding to map Unicode characters into one or more bytes. The options are ANSI, VT100, VT100+, and VT-UTF8.

#### Bits Per second

Use this feature to set the transmission speed for a serial port used in Console Redirection. Make sure that the same speed is used in the host computer and the client computer. A lower transmission speed may be required for long and busy lines. The options are 9600, 19200, 38400, 57600 and **115200** (bits per second).

#### **Data Bits**

Use this feature to set the data transmission size for Console Redirection. The options are 7 Bits and 8 Bits.

## Parity

A parity bit can be sent along with regular data bits to detect data transmission errors. Select Even if the parity bit is set to 0, and the number of 1's in data bits is even. Select Odd if the parity bit is set to 0, and the number of 1's in data bits is odd. Select None if you do not want to send a parity bit with your data bits in transmission. Select Mark to add a mark as a parity bit to be sent along with the data bits. Select Space to add a Space as a parity bit to be sent with your data bits. The options are **None**, Even, Odd, Mark and Space.

## Stop Bits

A stop bit indicates the end of a serial data packet. Select 1 Stop Bit for standard serial data communication. Select 2 Stop Bits if slower devices are used. The options are 1 and 2.

#### Flow Control

This feature allows the user to set the flow control for Console Redirection to prevent data loss caused by buffer overflow. Send a "Stop" signal to stop sending data when the receiving buffer is full. Send a "Start" signal to start sending data when the receiving buffer is empty. The options are **None** and Hardware RTS/CTS.

## VT-UTF8 Combo Key Support

Select Enabled to enable VT-UTF8 Combination Key support for ANSI/VT100 terminals. The options are **Enabled** and Disabled.

## **Recorder Mode**

Select Enabled to capture the data displayed on a terminal and send it as text messages to a remote server. The options are **Disabled** and Enabled.

#### Resolution 100x31

Select Enabled for extended-terminal resolution support. The options are Disabled and **Enabled**.

#### Legacy OS Redirection Resolution

Use this feature to select the number of rows and columns used in Console Redirection for legacy OS support. The options are 80x24 and **80x25**.

#### **Putty KeyPad**

This feature selects Function Keys and KeyPad settings for Putty, which is a terminal emulator designed for the Windows OS. The options are **VT100**, LINUX, XTERMR6, SC0, ESCN, and VT400.

# Serial Port for Out-of-Band Management/Windows Emergency Management Services (EMS)

The submenu allows the user to configure Console Redirection settings to support Out-of-Band Serial Port management.

# Console Redirection (for EMS)

Select Enabled to use a COM Port selected by the user for Console Redirection. The options are **Enabled** and Disabled.

# ▶ Console Redirection Settings (for EMS)

This feature allows the user to specify how the host computer will exchange data with the client computer, which is the remote computer used by the user.

# **Out-of-Band Management Port**

The feature selects a serial port used by the Microsoft Windows Emergency Management Services (EMS) to communicate with a remote server. The options are **COM1** and COM2

# **Terminal Type**

This feature allows the user to select the target terminal emulation type for Console Redirection. Select VT100 to use the ASCII character set. Select VT100+ to add color and function key support. Select ANSI to use the extended ASCII character set. Select VT-UTF8 to use UTF8 encoding to map Unicode characters into one or more bytes. The options are ANSI, VT100, VT100+, and VT-UTF8.

#### Bits Per Second

This item sets the transmission speed for a serial port used in Console Redirection. Make sure that the same speed is used in the host computer and the client computer. A lower transmission speed may be required for long and busy lines. The options are 9600, 19200, 57600, and **115200** (bits per second).

#### Flow Control

This feature allows the user to set the flow control for Console Redirection to prevent data loss caused by buffer overflow. Send a "Stop" signal to stop sending data when the receiving buffer is full. Send a "Start" signal to start sending data when the receiving buffer is empty. The options are **None**, Hardware RTS/CTS, and Software Xon/Xoff.

## Data Bits, Parity, Stop Bits

The setting for each of these features is displayed.

# ► ACPI Settings

Use this feature to configure Advanced Configuration and Power Interface (ACPI) power management settings for your system.

# **ACPI Sleep State**

Use this feature to select the ACPI State when the system is in sleep mode. Select S1 (CPU Stop Clock) to erase all CPU caches and stop executing instructions. Power to the CPU(s) and RAM is maintained, but RAM is refreshed. Select Suspend Disabled to use power-reduced mode. Power will only be supplied to limited components (such as RAMs) to maintain the most critical functions of the system. The options are S1 (CPU Stop Clock), and Suspend Disabled.

#### **NUMA (NON-Uniform Memory Access)**

This feature enables the Non-Uniform Memory Access ACPI support. The options are **Enabled** and Disabled.

#### **High Precision Event Timer**

Select Enabled to activate the High Precision Event Timer (HPET) that produces periodic interrupts at a much higher frequency than a Real-time Clock (RTC) does in synchronizing multimedia streams, providing smooth playback, reducing the dependency on other timestamp calculation devices, such as an x86 RDTSC Instruction embedded in the CPU. The High Performance Event Timer is used to replace the 8254 Programmable Interval Timer. The options are **Enabled** and Disabled.

# ▶ Trusted Computing (Available when a TPM device is detected by the BIOS)

# Configuration

# **TPM Support**

Select Enabled on this item and enable the TPM jumper on the motherboard to enable TPM support to improve data integrity and network security. The options are **Enabled** and Disabled.

#### **TPM State**

Select Enabled to enable TPM security settings to improve data integrity and network security. The options are Disabled and **Enabled**.

## **Pending Operation**

Use this item to schedule an operation for the security device. The options are **None**, Enable Take Ownership, Disable Take Ownership, and TPM Clear.

Note: During restart, the computer will reboot in order to execute the pending operation and change the state of the security device.

**Current Status Information:** This item displays the information regarding the current TPM status.

#### **TPM Enable Status**

This item displays the status of TPM Support to indicate if TPM is currently enabled or disabled

#### **TPM Active Status**

This item displays the status of TPM Support to indicate if TPM is currently active or deactivated.

#### **TPM Owner Status**

This item displays the status of TPM Ownership.

# ▶Intel TXT (LT-SX) Configuration

# Intel TXT (LT-SX) Hardware Support

This feature indicates if the following hardware components support Intel TXT (Trusted Execution Technology).

**CPU**: TXT Feature

Chipset: TXT Feature

# Intel TXT (LT-SX) Configuration

This feature displays the following TXT configuration setting.

**TXT Support:** This item indicates if the Intel TXT support is enabled or disabled. The default setting is **Disabled**.

# Intel TXT (LT-SX) Dependencies

This feature displays the features that need to be enabled for the Intel Trusted Execution Technology to work properly in the system.

VT-d Support: Intel Virtualization Technology with Direct I/O support

VT Support: Intel Virtualization Technology support

TPM Support: Trusted Platform support

TPM State: Trusted Platform state

# ►ME Subsystem

This feature displays the following ME Subsystem Configuration settings.

- ME BIOS Interface Version
- ME Version

# 4-4 Event Logs

Use this feature to configure Event Log settings.



# ▶ Change SMBIOS Event Log Settings

This feature allows the user to configure SMBIOS Event settings.

# **Enabling/Disabling Options**

## **SMBIOS Event Log**

Select Enabled to enable SMBIOS (System Management BIOS) Event Logging during system boot. The options are **Enabled** and Disabled.

# **Runtime Error Logging Support**

Select Enabled to support Runtime Error Logging. The options are **Enabled** and Disabled.

#### Memory Correctable Error Threshold

This feature allows the user to enter the threshold value for correctable memory errors. The default setting is 10.

# **PCI Error Logging Support**

Select Enabled to support error event logging for PCI slots. The options are Enabled and **Disabled**.

# **Erasing Settings**

## **Erase Event Log**

Select Enabled to erase the SMBIOS (System Management BIOS) Event Log, which is completed before an event logging is initialized upon system reboot. The options are **No**, Yes, next reset, and Yes, every reset.

# When Log is Full

Select Erase Immediately to immediately erase SMBIOS error event logs that exceed the limit when the SMBIOS event log is full. Select Do Nothing for the system to do nothing when the SMBIOS event log is full. The options are **Do Nothing** and Erase Immediately.

# **SMBIOS Event Log Standard Settings**

## Log System Boot Event

Select Enabled to log system boot events. The options are **Disabled** and Enabled.

# **MECI (Multiple Event Count Increment)**

Enter the increment value for the multiple event counter. Enter a number between 1 to 255. The default setting is 1.

# **METW (Multiple Event Count Time Window)**

This item allows the user to decide how long (in minutes) should the multiple event counter wait before generating a new event log. Enter a number between 0 to 99. The default setting is **60**.

# **View SMBIOS Event Log**

This item allows the user to view an event in the SMBIOS event log. Select this item and press <Enter> to view the status of an event in the log.

Date/Time/Error Code/Severity


# View System Event Log

This item allows the user to view an event in the System event log. Select this item and press <Enter> to view the status of an event in the log.

Date/Time/Error Code/Severity

# 4-5 IPMI

Use this feature to configure Intelligent Platform Management Interface (IPMI) settings.



#### **IPMI Firmware Revision**

This item indicates the IPMI firmware revision used in your system.

#### Status of BMC

This item indicates the status of the IPMI firmware installed in your system.

# ► System Event Log

#### **Enabling/Disabling Options**

# **SEL Components**

Select Enabled for all system event logging at bootup. The options are **Enabled** and Disabled.

# **Erasing Settings**

## **Erase SEL**

Select Yes, On next reset to erase all system event logs upon next system reboot. Select Yes, On every reset to erase all system event logs upon each system reboot. Select No to keep all system event logs after each system reboot. The options are **No**, Yes, On next reset, and Yes, On every reset.

#### When SEL is Full

This feature allows the user to decide what the BIOS should do when the system event log is full. Select Erase Immediately to erase all events in the log when the system event log is full. The options are **Do Nothing** and Erase Immediately.

# **Custom EFI Logging Options**

#### Log EFI Status Codes

Select Enabled to log EFI (Extensible Firmware Interface) Status Codes, Error Codes or Progress Codes. The options are **Enabled** and Disabled.

**Note**: After making changes on a setting, be sure to reboot the system for the changes to take effect.

# **▶BMC Network Configuration**

LAN Channel 1: This feature allows the user to configure the settings for LAN1.

# **Update IPMI LAN Configuration**

This feature allows the BIOS to implement any IP/MAC address changes at the next system boot. If the option is set to Yes, any changes made to the settings below will take effect when the system is rebooted. The options are **No** and Yes..

# **Configuration Address Source**

This feature allows the user to select the source of the IP address for this computer. If Static is selected, you will need to know the IP address of this computer and enter it to the system manually in the field. If DHCP is selected, the BIOS will search for a DHCP (Dynamic Host Configuration Protocol) server in the network that it is attached to and request the next available IP address for this computer. The options are **DHCP** and Static.

# Station IP Address

This item displays the Station IP address for this computer. This should be in decimal and in dotted quad form (i.e., 192.168.10.253).

#### Subnet Mask

This item displays the sub-network that this computer belongs to. The value of each three-digit number separated by dots should not exceed 255.

## Station MAC Address


This item displays the Station MAC address for this computer. Mac addresses are 6 two-digit hexadecimal numbers.

# **Gateway IP Address**

This item displays the Gateway IP address for this computer. This should be in decimal and in dotted guad form (i.e., 192.168.10.253).

# 4-6 Boot

This submenu allows the user to configure the following boot settings for the system.



# **Boot Option Priorities**

#### Boot Option #1/ Boot Option #2/ Boot Option #3, etc.

Use this feature to specify the sequence of boot device priority.

# Network Device BBS Priorities, Hard Drive BBS Priorities

This option sets the order of the legacy network and hard disk devices detected by the motherboard.

# ► Delete Boot Option

This feature allows the user to select a boot device to delete from the boot priority list.

# **Delete Boot Option**

Select the desired boot device to delete.

# 4-7 Security

This menu allows the user to configure the following security settings for the system.



#### **Administrator Password**


Use this feature to set the Administrator Password which is required to enter the BIOS setup utility. The length of the password should be from 3 characters to 20 characters long.

## **User Password**

Use this feature to set a User Password which is required to log into the system and to enter the BIOS setup utility. The length of the password should be from 3 characters to 20 characters long.

# 4-8 Save & Exit

This submenu allows the user to configure the Save and Exit settings for the system.



# **Discard Changes and Exit**

Select this option to quit the BIOS Setup without making any permanent changes to the system configuration, and reboot the computer. Select Discard Changes and Exit, and press <Enter>. When the dialog box appears, asking you if you want to exit the BIOS setup without saving, select **Yes** to quit BIOS without saving the changes, or select No to quit the BIOS and save changes.

# Save Changes and Reset

When you have completed the system configuration changes, select this option to save the changes and reboot the computer so that the new system configuration settings can take effect. Select Save Changes and Exit, and press <Enter>. When the dialog box appears, asking you if you want to exit the BIOS setup without saving, select **Yes** to quit BIOS without saving the changes, or select No to quit the BIOS and save changes.

# **Save Options**

#### Save Changes

Select this option and press <Enter> to save all changes you've done so far and return to the AMI BIOS utility Program. When the dialog box appears, asking you if you want to save configuration, select **Yes** to save the changes, or select No to return to the BIOS without making changes.

## **Discard Changes**

Select this feature and press <Enter> to discard all the changes and return to the BIOS setup. When the dialog box appears, asking you if you want to load previous values, select **Yes** to load the values previous saved, or select No to keep the changes you've made so far.

# **Restore Optimized Defaults**

Select this feature and press <Enter> to load the optimized default settings that help optimize system performance. When the dialog box appears, asking you if you want to load optimized defaults, select **Yes** to load the optimized default settings, or select No to abandon optimized defaults.

#### Save as User Defaults

Select this feature and press <Enter> to save the current settings as the user's defaults. When the dialog box appears, asking you if you want to save values as user's defaults, select **Yes** to save the current values as user's default settings, or select No to keep the defaults previously saved as the user's defaults.

#### **Restore User Defaults**

Select this feature and press <Enter> to load the user's defaults previously saved in the system. When the dialog box appears, asking you if you want to restore user's defaults, select **Yes** to restore the user's defaults previously saved in the system, or select No to abandon the user's defaults that were previously saved.

#### **Boot Override**

This feature allows the user to override the Boot Option Priorities setting in the Boot menu, and instead immediately boot the system with one of the listed devices. This is a one-time override

# **Notes**

# Appendix A

# **BIOS Error Beep Codes**

During the POST (Power-On Self-Test) routines, which are performed at each system boot, errors may occur.

**Non-fatal errors** are those which, in most cases, allow the system to continue to boot. The error messages normally appear on the screen.

**Fatal errors** will not allow the system to continue with bootup procedure. If a fatal error occurs, you should consult with your system manufacturer for possible repairs.

These fatal errors are usually communicated through a series of audible beeps. The numbers on the fatal error list correspond to the number of beeps for the corresponding error.

# A-1 BIOS Error Beep Codes

X9 Motherboard BIOS Error Beep Codes		
Beep Code/LED	Error Message	Description
1 beep	Refresh	Ready to boot
5 short beeps + 1 long beep	Memory error	No memory detected in the system
5 beeps	No Con-In or No Con-Out devices	Con-In includes USB or PS/2 keyboard, PCI or Serial Con- sole Redirection, IPMI KVM or SOL. Con-Out includes Video Con- troller, PCI or Serial Console Redirection, IPMI SOL.
1 beep per device	Refresh	1 beep for each USB device
X9 IPMI Error Codes		
1 Continuous Beep	System OH	System Overheat

# **Notes**


# Appendix B

# Software Installation Instructions

# **B-1 Installing Software Programs**

After you've installed the operating system, a screen as shown below will appear. You are ready to install software programs and drivers that have not yet been installed. To install these programs, click the icons to the right of these items.

**Note:** To install the Windows OS, please refer to the instructions posted on our Website at http://www.supermicro.com/support/manuals/.



**Driver/Tool Installation Display Screen** 

**Note 1:** Click the icons showing a hand writing on the paper to view the readme files for each item. Click a computer icon to the right of an item to install an item (from top to the bottom) one at a time. After installing each item, you must reboot the system before proceeding with the next item on the list. The bottom icon with a CD on it allows you to view the entire contents of the CD.

**Note 2:** When making a storage driver diskette by booting into a Driver CD, please set the SATA Configuration to "Compatible Mode" and configure SATA as IDE in the BIOS Setup. After making the driver diskette, be sure to change the SATA settings back to your original settings.

# B-2 Configuring SuperDoctor III (For Window OS Only)

The SuperDoctor® III program is a Web-based management tool that supports remote management capability. It includes Remote and Local Management tools. The local management is called the SD III Client. The SuperDoctor® III program included on the CDROM that came with your motherboard allows you to monitor the environment and operations of your system. SuperDoctor® III displays crucial system information such as CPU temperature, system voltages and fan status. See the Figure below for a display of the SuperDoctor® III interface.



Note 1: The default user name and password are ADMIN.

Note 2: In the Windows OS environment, the SuperDoctor® III settings take precedence over the BIOS settings. When first installed, SuperDoctor® III adopts the temperature threshold settings previously set in BIOS. Any subsequent changes to these thresholds must be made within SuperDoctor®, since the SD III settings override the BIOS settings. For the Windows OS to adopt the BIOS temperature threshold settings, please change the SDIII settings to be the same as those set in BIOS.

## SuperDoctor® III Interface Display Screen-I (Health Information)



# SuperDoctor® III Interface Display Screen-II (Remote Control)



Note: SD III Software Revision 1.0 can be downloaded from our Website at: ftp://ftp.Supermicro.com/utility/SuperDoctor\_III/. You can also download SDIII User's Guide at: http://www.supermicro.com/PRODUCT/Manuals/SDIII/UserGuide.pdf. For Linux, we will still recommend that you use SuperDoctor® II.

# **Notes**

